

Bentley **V10.01** Diagnostics List (Note:For reference only)

Year	System Type	Protocol Type	Systems	Functions
			01 Engine electronics	
			11 Engine electronics 2	
			21 Engine electronics 3	
			02 Transmission Electronics	
			03 Brake Electronics	
			08 AC/Heating electronics	
			25 Immobilizer	
			47 Soundsystem	
			12 Clutch electronics	
			34 Self leveling suspension	
			15 Airbags	
			16 Steering Wheel Electronics	
			44 Steering assistance	
			35 Central Locking	
			14 Wheel damping electronics	
			17 Instrument Cluster	
			18 Aux heating	
			13 Distance control	
			19 Gateway data bus	
			26 Electric roof control	
			29 Left light control	
			39 Right light control	
			37 Navigation	
			45 Interior Monitoring	
			46 Central Control Module	
			49 Auto. Lighting switch	
			51 Electric drive	

BOSCH

61 Battery control	
75 Emergency call module	
76 Parking aid	
09 Electronic Ctrl Electronics	
22 4WD Electronics	
24 Drive slip control	
36 Driver`s side seat adj.	
41 Diesel pump electronics	
55 Headlight range control	
56 Radio	
65 Tyre pressure monitoring	B01: Control Unit Info
66 Seat-/mirror adjust.	B02: Read Fault Codes
71 Battery charger	B03: Clear Fault Codes
42 DRIVER-DOOR ELECT.	B04: Measuring Blocks
52 PASSE.-DOOR ELECT.	(Live Data)
62 LR-DOOR ELECTRONI.	B05: Read FreFrame
72 RR-DOOR ELECTRONI.	B06: Readiness
23 BRAKER BOOSTER	B07: identification services
43 BRAKER BOOST.ASSI.	B08: Single Reading
63 DRVS BOARDING ASS1	S01: Output Tests
73 DRVS BOARDING ASS2	S02: Basic Settings
54 Rear spoiler	S03: Adaptation
05 ACCESS & PERMISSI.	S04: Login
06 PASSENE. SEAT ADJ.	S05: Access permission
07 DISPLAY-/CNTL UNIT	S06: Coding II
27 DIS./CTL UNIT REAR	S07: Code Module
57 TV-TUNER	S08: Long Code
67 VOICE CONTROL	S09: Chassis Number
77 TELEPHONE	adjustment
38 ROOF ELECTRONICS	

48 DRVS SEAT ADJ.REAR
68 WIPER ELECTRONICS
78 SLIDING DOOR
59 TOWING PROTECTION
69 TRAILER FUNCTION
28 Climate Control Unit Rear
31 Engine Electronics Conjunct.
32 Locking Electronisc
53 Parking Brake
58 Auxiliary Fuel Tank
64 Stabilizers
1C Vehicle Position Detection
2D Voice Amplification
3D Special Function
6E Roof Display/Control Head
7E Ind.Unit in Inst.Panel Ins.
0D Sliding Door Left
7D Auxiliary Heater
0F Radio Tuner-Digital
1F Radio Satellite
2F TV Tuner-Digital
04 Steering Position
74 Vehicle Control System
3C Lane Departure Assistance System
4C Tyre Pressure Monitor II
5C Lane Keeping Assistance System
6C Rear Camera
5D Opertion
6D Electronic Equipment of Trunk Lid
0B Auxiliary Air Heater

Without CAN
BUS

5F Information Electronic Equipment 1
6F Confort Central Control Unit II
1B Power-Assisted Steering
10 Parking Assist System 2
BF Sliding Door Right
01 Engine electronics
11 Engine electronics 2
21 Engine electronics 3
02 Transmission Electronics
03 Brake Electronics
08 AC/Heating electronics
25 Immobilizer
47 Soundsystem
12 Clutch electronics
34 Self leveling suspension
15 Airbags
16 Steering Wheel Electronics
44 Steering assistance
35 Central Locking
14 Wheel damping electronics
17 Instrument Cluster
18 Aux heating
13 Distance control
19 Gateway data bus
26 Electric roof control
29 Left light control
39 Right light control
37 Navigation
45 Interior Monitoring
46 Central Control Module

before
2007

KWP 2000

49 Auto. Lighting switch	
51 Electric drive	
61 Battery control	
75 Emergency call module	
76 Parking aid	
09 Electronic Ctrl Electronics	
22 4WD Electronics	
24 Drive slip control	
36 Driver`s side seat adj.	
41 Diesel pump electronics	
55 Headlight range control	
56 Radio	
65 Tyre pressure monitoring	
66 Seat-/mirror adjust.	
71 Battery charger	
42 DRIVER-DOOR ELECT.	
52 PASSE.-DOOR ELECT.	01 Control Unit Info
62 LR-DOOR ELECTRONI.	02 Read Fault Codes
72 RR-DOOR ELECTRONI.	08 Measuring Blocks (Live Data)
23 BRAKER BOOSTER	
43 BRAKER BOOST.ASSI.	05 Clear Fault Codes
63 DRVS BOARDING ASS1	04 Basic Settings
73 DRVS BOARDING ASS2	03 output tests
54 Rear spoiler	10 adaptation
05 ACCESS & PERMISSI.	11 code module
06 PASSENE. SEAT ADJ.	16 Access permission
07 DISPLAY-/CNTL UNIT	
27 DIS./CTL UNIT REAR	
57 TV-TUNER	
67 VOICE CONTROL	

77 TELEPHONE
38 ROOF ELECTRONICS
48 DRVS SEAT ADJ.REAR
68 WIPER ELECTRONICS
78 SLIDING DOOR
59 TOWING PROTECTION
69 TRAILER FUNCTION
28 Climate Control Unit Rear
31 Engine Electronics Conjunct.
32 Locking Electronisc
53 Parking Brake
58 Auxiliary Fuel Tank
64 Stabilizers
1C Vehicle Position Detection
2D Voice Amplification
3D Special Function
6E Roof Display/Control Head
7E Ind.Unit in Inst.Panel Ins.
0D Sliding Door Left
7D Auxiliary Heater
0F Radio Tuner-Digital
1F Radio Satellite
2F TV Tuner-Digital
04 Steering Position
74 Vehicle Control System
3C Lane Departure Assistance System
4C Tyre Pressure Monitor II
5C Lane Keeping Assistance System
6C Rear Camera
5D Opertion

6D Electronic Equipment of Trunk Lid
0B Auxiliary Air Heater
5F Information Electronic Equipment 1
6F Confort Central Control Unit II
1B Power-Assisted Steering
10 Parking Assist System 2
BF Sliding Door Right
01 Engine electronics
11 Engine electronics 2
44 Steering assistance
05 ACCESS & PERMISSI.
21 Engine electronics 3
31 Engine Electronics Conjunct.
61 Battery control
02 Transmission Electronics
22 4WD Electronics
42 DRIVER-DOOR ELECT.
52 PASSE.-DOOR ELECT.
62 LR-DOOR ELECTRONI.
72 RR-DOOR ELECTRONI.
03 Brake Electronics
13 Distance control
53 Parking Brake
34 Self leveling suspension
15 Airbags
25 Immobilizer
55 Headlight range control
65 Tyre pressure monitoring
75 Emergency call module
06 PASSENE. SEAT ADJ.

CAN BUS

CAN BUS

16 Steering Wheel Electronics	
26 Electric roof control	
36 Driver`s side seat adj.	
46 Central Control Module	
56 Radio	
66 Seat-/mirror adjust.	B01: Control Unit Info
76 Parking aid	B02: Read Fault Codes
1D Driver identification	B03: Clear Fault Codes
3D Special Function	B04: Measuring Blocks
07 DISPLAY-/CNTL UNIT	(Live Data)
17 Instrument Cluster	B05: Read FreFrame
37 Navigation	B06: Readiness
47 Soundsystem	B07: identification services
57 TV-TUNER	B08: Single Reading
67 VOICE CONTROL	S01: Output Tests
77 TELEPHONE	S02: Basic Settings
0E Media player position 1	S03: Adaptation
1E Media player position 2	S04: Login
2E Media player position 3	S05: Access permission
3E Media player position 4	S06: Coding II
4E Control head RR	S07: Code Module
5E Control head LR	S08: Long Code
7E Ind.Unit in Inst.Panel Ins.	S09: Chassis Number
08 AC/Heating electronics	adjustment
18 Aux heating	
28 Climate Control Unit Rear	
38 ROOF ELECTRONICS	
7D Auxiliary Heater	
09 Electronic Ctrl Electronics	
19 Gateway data bus	

		69 TRAILER FUNCTION
		0F Radio Tuner-Digital
		1F Radio Satellite
		2F TV Tuner-Digital
		4F Electronic central electric II
		04 Steering Position
		74 Vehicle Control System
		3C Lane Departure Assistance System
		4C Tyre Pressure Monitor II
		5C Lane Keeping Assistance System
		6C Rear Camera
		5D Opertion
		6D Electronic Equipment of Trunk Lid
		0B Auxiliary Air Heater
		5F Information Electronic Equipment 1
		6F Confort Central Control Unit II
		1B Power-Assisted Steering
		10 Parking Assist System 2
		20 High Beam Assistance Device
		30 Special Function 2
		BF Sliding Door Right
	CAN BUS	Collection services

NOTE:The final interpretation of the products belongs to LAUNCH TECH CO.,LTD

Bentley V10.01 诊断车型列表(注:仅供参考)

车型	年份	底盘	系统	功能
Bentley	All	DC	01 Engine electronics	B01,B02,B03,B04,S01,S02,S03,S05,S06
			02 Transmission Electronics	B01,B02,B03,B04,S01,S02,S03,S05,S06
			03 Brake Electronics	B01,B02,B03,B04,S01,S02,S03,S05,S06
			05 ACCESS & PERMISSI.	B01,B02,B03,B04,S01,S02,S03,S05,S06
			06 PASSENE. SEAT ADJ.	B01,B02,B03,B04,S01,S02,S03,S05,S06
			07 DISPLAY-/CNTL UNIT	B01,B02,B03,B04,S01,S02,S03,S05,S06
			08 AC/Heating electronics	B01,B02,B03,B04,S01,S02,S03,S05,S06
			09 Electronic Ctrl Electronics	B01,B02,B03,B04,S01,S02,S03,S05,S06
			11 Engine electronics 2	B01,B02,B03,B04,S01,S02,S03,S05,S06
			13 Distance control	B01,B02,B03,B04,S01,S02,S03,S05,S06
			15 Airbags	B01,B02,B03,B04
			16 Steering Wheel Electronics	B01,B02,B03,B04,S01,S02,S03,S05,S06
			17 Instrument Cluster	B01,B02,B03,B04,S01,S02,S03,S05,S06
			18 Aux heating	B01,B02,B03,B04,S01,S02,S03,S05,S06
			19 Gateway data bus	B01,B02,B03,B04,S01,S02,S03,S05,S06
			23 BRAKER BOOSTER	B01,B02,B03,B04,S01,S02,S03,S05,S06
			27 DIS./CTL UNIT REAR	B01,B02,B03,B04,S01,S02,S03,S05,S06
			28 Climate Control Unit Rear	B01,B02,B03,B04,S01,S02,S03,S05,S06
			29 Left light control	B01,B02,B03,B04,S01,S02,S03,S05,S06
			2E Media player position 3	B01,B02,B03,B04,S01,S02,S03,S05,S06
			34 Self leveling suspension	B01,B02,B03,B04,S01,S02,S03,S05,S06
			36 Driver`s side seat adj.	B01,B02,B03,B04,S01,S02,S03,S05,S06
			37 Navigation	B01,B02,B03,B04,S01,S02,S03,S05,S06
38 ROOF ELECTRONICS	B01,B02,B03,B04,S01,S02,S03,S05,S06			
39 Right light control	B01,B02,B03,B04,S01,S02,S03,S05,S06			
46 Central Control Module	B01,B02,B03,B04,S01,S02,S03,S05,S06			

Bentley V10.01 诊断车型列表 (注:仅供参考)

车型	年份	底盘	系统	功能
			47 Soundsystem	B01,B02,B03,B04,S01,S02,S03,S05,S06
			55 Headlight range control	B01,B02,B03,B04,S01,S02,S03,S05,S06
			56 Radio	B01,B02,B03,B04,S01,S02,S03,S05,S06
			57 TV-TUNER	B01,B02,B03,B04,S01,S02,S03,S05,S06
			65 Tyre pressure monitoring	B01,B02,B03,B04,S01,S02,S03,S05,S06
			66 Seat-/mirror adjust.	B01,B02,B03,B04,S01,S02,S03,S05,S06
			68 WIPER ELECTRONICS	B01,B02,B03,B04,S01,S02,S03,S05,S06
			69 TRAILER FUNCTION	B01,B02,B03,B04,S01,S02,S03,S05,S06
			71 Battery charger	B01,B02,B03,B04,S01,S02,S03,S05,S06
			75 Emergency call module	B01,B02,B03,B04,S01,S02,S03,S05,S06
			76 Parking aid	B01,B02,B03,B04,S01,S02,S03,S05,S06
			77 TELEPHONE	B01,B02,B03,B04,S01,S02,S03,S05,S06
NOTE:				
Basic Functions		Special Functions		
B01: Control Unit Info		S01: Output Tests		
B02: Read Fault Codes		S02: Basic Settings		
B03: Clear Fault Codes		S03: Adaptation		
B04: Measuring Blocks (Live Data)		S04: Login		
B05: Read FreFrame		S05: Access permission		
B06: Readiness		S06: Coding II		
B07: identification services		S07: Code Module		
B08: Single Reading		S08: Long Code		
		S09: Chassis Number adjustment		

NOTE: The final interpretation of the products belongs to LAUNCH TECH CO.,LTD

CONNECTOR	X431/TOOL	DIAGUN
OBD 16C	VW Model of non-CAN BUS protocol	N/A
CANBUS II	All VW Models with 16PIN DLC	N/A
SUPER 16	All VW Models with 16PIN DLC	N/A
diagun connector	N/A	All VW Models with 16PIN DLC