

Bugatti V10.01 诊断车型列表(注:仅供参考)

车型	年份	底盘	系统	功能
Bugatti	All	DC	01 Engine electronics	B01,B02,B03,B04,S01,S02,S03,S05,S06
			02 Transmission Electronics	B01,B02,B03,B04,S01,S02,S03,S05,S06
			03 Brake Electronics	B01,B02,B03,B04,S01,S02,S03,S05,S06
			05 ACCESS & PERMISSI.	B01,B02,B03,B04,S01,S02,S03,S05,S06
			06 PASSENE. SEAT ADJ.	B01,B02,B03,B04,S01,S02,S03,S05,S06
			07 DISPLAY-/CNTL UNIT	B01,B02,B03,B04,S01,S02,S03,S05,S06
			08 AC/Heating electronics	B01,B02,B03,B04,S01,S02,S03,S05,S06
			09 Electronic Ctrl Electronics	B01,B02,B03,B04,S01,S02,S03,S05,S06
			11 Engine electronics 2	B01,B02,B03,B04,S01,S02,S03,S05,S06
			13 Distance control	B01,B02,B03,B04,S01,S02,S03,S05,S06
			15 Airbags	B01,B02,B03,B04
			16 Steering Wheel Electronics	B01,B02,B03,B04,S01,S02,S03,S05,S06
			17 Instrument Cluster	B01,B02,B03,B04,S01,S02,S03,S05,S06
			18 Aux heating	B01,B02,B03,B04,S01,S02,S03,S05,S06
			19 Gateway data bus	B01,B02,B03,B04,S01,S02,S03,S05,S06
			23 BRAKER BOOSTER	B01,B02,B03,B04,S01,S02,S03,S05,S06
			27 DIS./CTL UNIT REAR	B01,B02,B03,B04,S01,S02,S03,S05,S06
			28 Climate Control Unit Rear	B01,B02,B03,B04,S01,S02,S03,S05,S06
			29 Left light control	B01,B02,B03,B04,S01,S02,S03,S05,S06
			2E Media player position 3	B01,B02,B03,B04,S01,S02,S03,S05,S06
			34 Self leveling suspension	B01,B02,B03,B04,S01,S02,S03,S05,S06
			36 Driver`s side seat adj.	B01,B02,B03,B04,S01,S02,S03,S05,S06
			37 Navigation	B01,B02,B03,B04,S01,S02,S03,S05,S06
38 ROOF ELECTRONICS	B01,B02,B03,B04,S01,S02,S03,S05,S06			
39 Right light control	B01,B02,B03,B04,S01,S02,S03,S05,S06			
46 Central Control Module	B01,B02,B03,B04,S01,S02,S03,S05,S06			

Bugatti V10.01 诊断车型列表(注:仅供参考)

车型	年份	底盘	系统	功能
			47 Soundsystem	B01,B02,B03,B04,S01,S02,S03,S05,S06
			55 Headlight range control	B01,B02,B03,B04,S01,S02,S03,S05,S06
			56 Radio	B01,B02,B03,B04,S01,S02,S03,S05,S06
			57 TV-TUNER	B01,B02,B03,B04,S01,S02,S03,S05,S06
			65 Tyre pressure monitoring	B01,B02,B03,B04,S01,S02,S03,S05,S06
			66 Seat-/mirror adjust.	B01,B02,B03,B04,S01,S02,S03,S05,S06
			68 WIPER ELECTRONICS	B01,B02,B03,B04,S01,S02,S03,S05,S06
			69 TRAILER FUNCTION	B01,B02,B03,B04,S01,S02,S03,S05,S06
			71 Battery charger	B01,B02,B03,B04,S01,S02,S03,S05,S06
			75 Emergency call module	B01,B02,B03,B04,S01,S02,S03,S05,S06
			76 Parking aid	B01,B02,B03,B04,S01,S02,S03,S05,S06
			77 TELEPHONE	B01,B02,B03,B04,S01,S02,S03,S05,S06
NOTE:				
Basic Functions		Special Functions		
B01: Control Unit Info		S01: Output Tests		
B02: Read Fault Codes		S02: Basic Settings		
B03: Clear Fault Codes		S03: Adaptation		
B04: Measuring Blocks (Live Data)		S04: Login		
B05: Read FreFrame		S05: Access permission		
B06: Readiness		S06: Coding II		
B07: identification services		S07: Code Module		
B08: Single Reading		S08: Long Code		
		S09: Chassis Number adjustment		

NOTE:The final interpretation of the products belongs to LAUNCH TECH CO.,LTD

CONNECTOR	X431/TOOL	DIAGUN
OBD 16C	VW Model of non-CAN BUS protocol	N/A
CANBUS II	All VW Models with 16PIN DLC	N/A
SUPER 16	All VW Models with 16PIN DLC	N/A
diagun connector	N/A	All VW Models with 16PIN DLC