

JAGUAR V19.22 Diagnostics List (Note:For reference only)

Model	Year	ENG TYPE	PCM	TCM	ABS	RCM	IP	AD CM	BCM	BCM B	HVA C	PBM	TPM	PAM	CCM	AU	G S M	D D M	D S M	P D M	P S M	R S M	R G T M	D C S M	S O D - LR	S P M - AB	H C M	G E M	R D C M	G W M	A H C M	I C S	O C S	V I M	K V M	K T M	I C P	S L M	I C M	I S M	S C L	A A M	A C M	N C M	S R M	T E L	T V M	A P I M	D A B M	V A C M	F C D I M
XK	2006-2009	ALL TYPE	CD S6, S37, S39, S59	CD S5	CD S40, S88, S89	CD S55	CD S31, S81, S96, S97, S98	CD	CD	CD	CD	CD S4	CD S15, S16, S17, S18	CD	CD S44		CD S19	CD S60	CD S20	CD S61							CD S87			CD		CD	CD		C		CD				CD	CD	CD	CD	CD						CD S66
	2010-2013	ALL TYPE	CD S6, S7, S8, S9, S34, S37, S39, S59	CD S5	CD S22	CD	CD S31, S81, S96, S97, S98	CD S70, S71	CD S82	CD S29	CD S23	CD S4	CD S15, S16, S17, S18	CD	CD S44		CD S19	CD S60	CD S20	CD S61			CD				CD S87	CD S45		CD	CD S55	CD	CD		CD					CD	CD	CD	CD	CD		CD	CD		CD		
F-TYPE	2014	ALL TYPE	CD, S13, S6, S7, S21, S37, S94	CD	CD, S95	CD, S42	CD, S81, S93		CD, S15, S18, S68, S69, S52, S31		CD, S23	CD S4, S90, S91, S92		CD			CD S19	CD S60	CD S20	CD S61		CD, S64		CD		CD, S47	CD, S45	CD, S29, S73, S74, S75, S113		CD, S55	CD	CD		CD						CD, S57, S56	CD	CD	CD		CD, S128		CD		CD,		

- C DTC
- D Data Display
- T Action Test
- V MODULE IDENTIFICATION

- S1: Program new transponders
- S2: Clear lost keyfob transmitters
- S3: Program new keyfob transmitters
- S4: Parking brake release to service position
- S5: Transmission control module adaption clear
- S6: Powertrain control module adaption clear
- S7: Oil service counter level
- S8: Reset oil level
- S9: Check the engine oil level
- S10: Diesel particulate filter replacement
- S11: Diesel particulate filter dynamic regeneration
- S12: Diesel particulate filter fuel related component replacement
- S13: Service interval reset
- S14: Injector replacement
- S15: Tire pressure sensor replacement
- S16: Tire pressure monitor confirmation application
- S17: Tire pressure monitor receiver calibration
- S18: Tyre pressure monitor ID value display
- S19: Driver's side - Door glass window calibration
- S20: Passenger's side - Door glass window calibration

JAGUAR V19.22 Diagnostics List (Note:For reference only)

Model	Year	ENG TYPE	PCM	TCM	ABS	RCM	IP	AD CM	BCM	BCM B	HVA C	PBM	TPM	PAM	CCM	AU	G S M	D D M	D S M	P D M	P S M	R S M	R G T M	D C S M	S O D - LR	S P M - AB	H C M	G E M	R D C M	G W M	A H C M	I C S	O C S	V I M	K V M	K T M	I C P	S L M	I C M	I S M	S C L	A A M	A C M	N C M	S R M	T E L	T V M	A P I M	D A B M	V A C M	F C D I M
-------	------	----------	-----	-----	-----	-----	----	-------	-----	-------	-------	-----	-----	-----	-----	----	-------	-------	-------	-------	-------	-------	---------	---------	------------	------------	-------	-------	---------	-------	---------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	---------	---------	---------	-----------

S21: Throttle valve actuator (Diesel)

S22: Brake bleed

S23: Stepper motor initialisation

S24: Exhaust gas recirculation valve

S25: Reset water in fuel detection

S26: Turbine shut-off valve

S27: Oxygen sensor

S28: Oxidation catalyst

S29: Battery replacement

S30: Pedestrian impact crash status reset

S31: Steering column calibration

S32: High pressure injection pump replacement

S33: Sunroof calibration

S34: Fuel lift pump

S35: Diesel particulate filter differential pressure sensor replacement

S36: Diesel fueling adaption re-initialization

S37: Fuel prime routine

S38: Display injector correction factors

S39: Purge valve self test

S40: Yaw rate sensor calibration

S41: Vent actuators test

S42: Restraints build mode

S43: Rest of world - Service interval options

S44: Speed control alignment

S45: Control module calibration

S46: Tire size (rolling circumference)

S47: Headlamp control module system calibration

S48: Navigation reset

S49: Side object detection configuration - Right

S50: Side object detection configuration - Left

S51: Dynamic safety belt retract and release - SPMA

S52: Dynamic safety belt retract and release - SPMB

S53: Clear module learn data - SPMA

S54: Clear module learn data - SPMB

S55: Seat cushion replacement

S56: DVD region counter reset

S57: Calibrate dynamic volume control

S58: Idle speed adjustment

S59: Idle speed test

S60: Driver's seat calibration

S61: Passenger's seat calibration

JAGUAR V19.22 Diagnostics List (Note:For reference only)

Model	Year	ENG TYPE	PCM	TCM	ABS	RCM	IP	AD CM	BCM	BCM B	HVA C	PBM	TPM	PAM	CCM	AU	G S M	D D M	D S M	P D M	P S M	R S M	R G T M	D C S M	S O D - L R	S P M - A B	H C M	G E M	R D C M	G W M	A H C M	I C S	O C S	V I M	K V M	K T M	I C P	S L M	I C M	I S M	S C L	A A M	A C M	N C M	S R M	T E L	T V M	A P I M	D A B M	V A C M	F C D I M
-------	------	----------	-----	-----	-----	-----	----	----------	-----	----------	----------	-----	-----	-----	-----	----	-------------	-------------	-------------	-------------	-------------	-------------	------------------	------------------	----------------------------	----------------------------	-------------	-------------	------------------	-------------	------------------	-------------	-------------	-------------	-------------	-------------	-------------	-------------	-------------	-------------	-------------	-------------	-------------	-------------	-------------	-------------	-------------	------------------	------------------	------------------	-----------------------

- S62: Rear seat calibration - Right
- S63: Rear seat calibration - Left
- S64: Tailgate/trunk calibration
- S65: Passenger restraint disable switch
- S66: Mirror personalisation features
- S67: Paddle shift configuration
- S68: Transportation mode
- S69: Fuel pump supply - Enable/disable
- S70: Calibration learn
- S71: Build mode
- S72: Valet mode reset
- S73: Test dual battery system
- S74: Verify secondary battery charging
- S75: Quiescent current control module internal check
- S76: Evaporator and heater test
- S77: Injector valve test
- S78: Speed control internal state
- S79: Air conditioning system adaption reset
- S80: Diesel particulate filter condition (stored values)
- S81: Vehicle reset
- S82: Alarm trigger history
- S83: Side object detection module history
- S84: Side object detection module history
- S85: OBDII readiness tests
- S86: Service history data
- S87: Headlamp and axle sensor calibration
- S88: Lateral accelerometer calibration
- S89: Pressure sensor calibration
- S90: Longitudinal accelerometer calibration
- S91: Parking brake pad replacement - Exit maintenance mode application
- S92: Parking brake activation
- S93: Odometer calibration
- S94: Engine control module unlock application
- S95: Steering angle sensor calibration

- S96: Key programming
- S97: Erase all existing keys
- S98: Verify Keys
- S99: Check all antennas
- S100: Immobiliser Antenna Unit Functionality Check
- S101: Add additional keys

JAGUAR V19.22 Diagnostics List (Note:For reference only)

Model	Year	ENG TYPE	PCM	TCM	ABS	RCM	IP	AD CM	BCM	BCM B	HVA C	PBM	TPM	PAM	CCM	AU	G S M	D D M	D S M	P D M	P S M	R S M	R G T M	D C S M	S O D - L R	S P M - A B	H C M	G E M	R D C M	G W M	A H C M	I C S	O C S	V I M	K V M	K T M	I C P	S L M	I C M	I S M	S C L	A A M	A C M	N C M	S R M	T E L	T V M	A P I M	D A B M	V A C M	F C D I M
-------	------	----------	-----	-----	-----	-----	----	----------	-----	----------	----------	-----	-----	-----	-----	----	-------------	-------------	-------------	-------------	-------------	-------------	------------------	------------------	----------------------------	----------------------------	-------------	-------------	------------------	-------------	------------------	-------------	-------------	-------------	-------------	-------------	-------------	-------------	-------------	-------------	-------------	-------------	-------------	-------------	-------------	-------------	-------------	------------------	------------------	------------------	-----------------------

S102: Replace faulty/lost keys

S103: Recover programmed keys

S104: Check passive keys enabled

S112: Height calibration

S113: Set/un-set air suspension manufacturing/freeze mode

S114: Set/un-set air suspension geometry set-up

S115: Set/un-set air suspension tight tolerance mode (headlamp setting)

S116: Air suspension inflation

S117: Air suspension deflation

S128: Front control display interface module - Graphics update

S129: Brake sensor set-up

S130: ABS control module configuration clear

(?):Manual on website(www.x431.com)

Note:All description rights reserved by LAUNCH TECH.CO.,LTD

