

LANCIA V16.40 Diagnostics List (Note: For reference only)

Models	Displacement	Systems	Functions
Ypsilon(2011)		BCM(Body Controller)	VCDFA
		CMM(Collision Mitigation Module)	VCDF
		TCM(Transmission Control Module)	VCDFA
		CTM(Convergence Telematic Module)	VCDA
		AHM(Additional Heater Module)	VCDA
		ECM(Engine Control Module)	VCDFA
		ORC(Occupant Restraint)	VCD
		PAM(Parking Aid Module)	VCD
		IPC(Instrument Panel Cluster)	VCDA
		EPS(Electric Power Steering)	VCDF
		ABS(Anti Lock Brakes)	VCDFA
HVAC(Heat, Ventilation and A/C)	VCDFA		
Flavia(2012)		TIPMCGW(Central Gateway)	VCDFA
		PDM(Passenger Door Module)	VCDA
		AMP(Amplifier)	VCDF
		PCM(Powertrain Control Module)	VCDFA
		HVAC(Heat, Ventilation and A/C)	VCDFA
		ABS(Anti Lock Brakes)	VCDFA
		ORC(Occupant Restraint)	VCDF
		CCN(Instrument Cluster/Cabin Compartment Node)	VCDFA
		HFM(Hands Free Module(cell phone))	VCDA
		SAS(Steering Angle Sensor)	VCD
		DDM(Driver Door Module)	VCDA
		RADIO(RADIO)	VCDF
WCM(Wireless Control)	VCDF		

LANCIA V16.40 Diagnostics List (Note: For reference only)

Models	Displacement	Systems	Functions		
Flavia(2013)		PTCM(Power Top Control Module)	VCDF		
		TIPMCGW(Central Gateway)	VCDFFA		
		PDM(Passenger Door Module)	VCDA		
		AMP(Amplifier)	VCDF		
		PCM(Powertrain Control Module)	VCDFFA		
		HVAC(Heat, Ventilation and A/C)	VCDFFA		
		ABS(Anti Lock Brakes)	VCDFFA		
		ORC(Occupant Restraint)	VCDF		
		CCN(Instrument Cluster/Cabin Compartment Node)	VCDFFA		
		HFM(Hands Free Module(cell phone))	VCDA		
		AMP(Amplifier)	VCDA		
		SAS(Steering Angle Sensor)	VCD		
		DDM(Driver Door Module)	VCDA		
		RADIO(RADIO)	VCDF		
		WCM(Wireless Control)	VCDF		
		PTCM(Power Top Control Module)	VCDF		
		ESM(Electronic Shifter)	VCDFFA		
		TCM(Transmission Control Module)	VCDA		
				BCM(Body Controller)	VCDFFA
				ORC(Occupant Restraint)	VCDF
TGW(Telematic Gateway Radio)	VCD				
HVAC(Heat, Ventilation and A/C)	VCDFFA				
ICS(Integrated Center Stack)	VCDFFA				
TCM(Transmission Control Module)	VCDF				
ESM(Electronic Shifter)	VCDA				

LANCIA V16.40 Diagnostics List (Note: For reference only)

Models	Displacement	Systems	Functions
Thema (2012)		AFLS(Adaptive Front Lighting System)	VCD
		PDM(Passenger Door Module)	VCDFA
		PCM(Powertrain Control Module)	VCDFA
		DDM(Driver Door Module)	VCDFA
		AMP(Amplifier)	VCD
		PTS(Parktronics)	VCDFA
		ABS(Anti Lock Brakes)	VCDFA
		IPC(Instrument Panel Cluster)	VCDFA
		SCCM(Steering Column Control Module)	VCD
		ITM(Intrusion)	VCDFA
		HSM(Heated Seat Module)	VCDFA
		EPS(Electric Power Steering)	VCDF
		RFH(Radio Frequency Hub)	VCDFA
		MSM(Memory Seat Module)	VCDFA
		DTCM(Drive Train Control Module)	VCDFA
		ACC(Adaptive Cruise Control)	VCDF
		HFM(Hands Free Module(cell phone))	VCD
		BSM(Blind Spot Module)	VCD
		ADCM(Active Damping Control Module)	VCD
		TPM(Tire Pressure Monitor)	VCDF
		BCM(Body Controller)	VCDFA
		ORC(Occupant Restraint)	VCDF
		TGW(Telematic Gateway Radio)	VCD
		HVAC(Heat, Ventilation and A/C)	VCDFA
		ICS(Integrated Center Stack)	VCDFA

LANCIA V16.40 Diagnostics List (Note: For reference only)

Models	Displacement	Systems	Functions
Thema (2013)		TCM(Transmission Control Module)	VCDF
		ESM(Electronic Shifter)	VCDA
		AFLS(Adaptive Front Lighting System)	VCDA
		PDM(Passenger Door Module)	VCDFA
		PCM(Powertrain Control Module)	VCDFA
		DDM(Driver Door Module)	VCDFA
		AMP(Amplifier)	VCD
		PTS(Parktronics)	VCDFA
		ABS(Anti Lock Brakes)	VCDFA
		IPC(Instrument Panel Cluster)	VCDFA
		SCCM(Steering Column Control Module)	VCD
		ITM(Intrusion)	VCDFA
		HSM(Heated Seat Module)	VCDFA
		EPS(Electric Power Steering)	VCDF
		RFH(Radio Frequency Hub)	VCDFA
		MSM(Memory Seat Module)	VCDFA
		DTCM(Drive Train Control Module)	VCDFA
		ACC(Adaptive Cruise Control)	VCDF
		HFM(Hands Free Module(cell phone))	VCD
		BSM(Blind Spot Module)	VCD
		ADCM(Active Damping Control Module)	VCD
		RBSS(Right blind spot sensor)	VCD
LBSS(Left blind spot sensor)	VCD		
		BCM(Body Controller)	VCDFA
		ORC(Occupant Restraint)	VCDF

LANCIA V16.40 Diagnostics List (Note:For reference only)

Models	Displacement	Systems	Functions
Thema (2014)		TGW(Telematic Gateway Radio)	VCD
		HVAC(Heat, Ventilation and A/C)	VCDFA
		ICS(Integrated Center Stack)	VCDFA
		TCM(Transmission Control Module)	VCDF
		ESM(Electronic Shifter)	VCDA
		AFLS(Adaptive Front Lighting System)	VCDA
		PDM(Passenger Door Module)	VCDFA
		PCM(Powertrain Control Module)	VCDFA
		DDM(Driver Door Module)	VCDFA
		AMP(Amplifier)	VCD
		PTS(Parktronics)	VCDFA
		ABS(Anti Lock Brakes)	VCDFA
		FFCM(Forward Facing Camera Module)	VCDA
		IPC(Instrument Panel Cluster)	VCDFA
		SCCM(Steering Column Control Module)	VCD
		ITM(Intrusion)	VCDFA
		HSM(Heated Seat Module)	VCDFA
		EPS(Electric Power Steering)	VCDF
		RFH(Radio Frequency Hub)	VCDFA
		MSM(Memory Seat Module)	VCDFA
		DTCM(Drive Train Control Module)	VCDFA
	ACC(Adaptive Cruise Control)	VCDF	
	HFM(Hands Free Module(cell phone))	VCD	
	BSM(Blind Spot Module)	VCD	
	ADCM(Active Damping Control Module)	VCD	

LANCIA V16.40 Diagnostics List (Note: For reference only)

Models	Displacement	Systems	Functions
		RBSS(Right blind spot sensor)	VCD
		LBSS(Left blind spot sensor)	VCD
Thema (2015)		BCM(Body Controller)	VCDFA
		ORC(Occupant Restraint)	VCDF
		TGW(Telematic Gateway Radio)	VCD
		HVAC(Heat, Ventilation and A/C)	VCDFA
		ICS(Integrated Center Stack)	VCDFA
		TCM(Transmission Control Module)	VCDF
		ESM(Electronic Shifter)	VCDA
		AFLS(Adaptive Front Lighting System)	VCDA
		PDM(Passenger Door Module)	VCDFA
		PCM(Powertrain Control Module)	VCDFA
		DDM(Driver Door Module)	VCDFA
		AMP(Amplifier)	VCD
		PTS(Parktronics)	VCDFA
		ABS(Anti Lock Brakes)	VCDFA
		FFCM(Forward Facing Camera Module)	VCDA
		IPC(Instrument Panel Cluster)	VCDFA
		SCCM(Steering Column Control Module)	VCD
		ITM(Intrusion)	VCDFA
		HSM(Heated Seat Module)	VCDFA
		EPS(Electric Power Steering)	VCDF
RFH(Radio Frequency Hub)	VCDFA		
MSM(Memory Seat Module)	VCDFA		
DTCM(Drive Train Control Module)	VCDFA		

LANCIA V16.40 Diagnostics List (Note: For reference only)

Models	Displacement	Systems	Functions
		ACC(Adaptive Cruise Control)	VCDF
		HFM(Hands Free Module(cell phone))	VCD
		BSM(Blind Spot Module)	VCD
		ADCM(Active Damping Control Module)	VCD
		RBSS(Right blind spot sensor)	VCD
		LBSS(Left blind spot sensor)	VCD
Voyager (2012)		TIPMCGW(Central Gateway)	VCDFA
		DVD(DVD Changer)	VCD
		HVAC(Heat, Ventilation and A/C)	VCDFA
		PLGM(Power Liftgate)	VCDFA
		SAS(Steering Angle Sensor)	VCD
		DMFL(Door Module Front Left)	VCDFA
		CCN(Instrument Cluster/Cabin Compartment Node)	VCDFA
		SUNR(Sunroof)	VCDA
		PCM(Powertrain Control Module)	VCDFA
		RADIO(RADIO)	VCDF
		DMRL(Door Module Rear Left)	VCDFA
		TPM(Tire Pressure Monitor)	VCDF
		TCM(Transmission Control Module)	VCDFA
		PEM(Passive Entry Module)	VCDF
		VES3(Last Row Screen)	VCDFA
		ORC(Occupant Restraint)	VCDF
		EPPM(Electronic Pedestrian Protection Module)	VCDF
		PSDML(Power Sliding Doors (Left))	VCD
		FSM(Fold Stow Module)	VCDA

LANCIA V16.40 Diagnostics List (Note: For reference only)

Models	Displacement	Systems	Functions
		HFM(Hands Free Module(cell phone))	VCDA
		ABS(Anti Lock Brakes)	VCDF
		PTS(Parktronics)	VCDF
		PSDMR(Power Sliding Doors (Right))	VCD
		WCM(Wireless Control)	VCDF
		ITM(Intrusion)	VCDF
		HSM(Heated Seat Module)	VCDF
		DMRR(Door Module Rear Right)	VCDF
		DMFR(Door Module Front Right)	VCDF
		HIDT(High Intensity Discharge Translator)	VCDA
		VES2(Second Row Screen)	VCDF
		AHBM(Automatic High Beam)	VCD
		MSMD(Memory Seat)	VCDF
		AMP(Amplifier)	VCDF
		BSM(Blind Spot Module)	VCD
		TIPMCGW(Central Gateway)	VCDF
		DVD(DVD Changer)	VCD
		HVAC(Heat, Ventilation and A/C)	VCDF
		PLGM(Power Liftgate)	VCDF
		SAS(Steering Angle Sensor)	VCD
		DMFL(Door Module Front Left)	VCDF
		CCN(Instrument Cluster/Cabin Compartment Node)	VCDF
		SUNR(Sunroof)	VCDA
		PCM(Powertrain Control Module)	VCDF
		RADIO(RADIO)	VCDF

LANCIA V16.40 Diagnostics List (Note:For reference only)

Models	Displacement	Systems	Functions
Voyager (2013)		DMRL(Door Module Rear Left)	VCDFA
		TPM(Tire Pressure Monitor)	VCDF
		TCM(Transmission Control Module)	VCDFA
		PEM(Passive Entry Module)	VCDF
		VES3(Last Row Screen)	VCDFA
		ORC(Occupant Restraint)	VCDF
		EPPM(Electronic Pedestrian Protection Module)	VCDF
		PSDML(Power Sliding Doors (Left))	VCD
		FSM(Fold Stow Module)	VCDA
		HFM(Hands Free Module(cell phone))	VCDA
		ABS(Anti Lock Brakes)	VCDFA
		PTS(Parktronics)	VCDFA
		PSDMR(Power Sliding Doors (Right))	VCD
		WCM(Wireless Control)	VCDFA
		ITM(Intrusion)	VCDFA
		HSM(Heated Seat Module)	VCDFA
		DMRR(Door Module Rear Right)	VCDFA
		DMFR(Door Module Front Right)	VCDFA
		HIDT(High Intensity Discharge Translator)	VCDA
		VES2(Second Row Screen)	VCDFA
		AHBM(Automatic High Beam)	VCD
		MSMD(Memory Seat)	VCDFA
		AMP(Amplifier)	VCDF
	LBSS(Left blind spot sensor)	VCD	
	RBSS(Right blind spot sensor)	VCD	

LANCIA V16.40 Diagnostics List (Note: For reference only)

Models	Displacement	Systems	Functions
Voyager (2014)		TIPMCGW(Central Gateway)	VCDFA
		DVD(DVD Changer)	VCD
		HVAC(Heat, Ventilation and A/C)	VCDFA
		PLGM(Power Liftgate)	VCDFA
		SAS(Steering Angle Sensor)	VCD
		DMFL(Door Module Front Left)	VCDFA
		CCN(Instrument Cluster/Cabin Compartment Node)	VCDFA
		SUNR(Sunroof)	VCDA
		PCM(Powertrain Control Module)	VCDFA
		RADIO(RADIO)	VCDF
		DMRL(Door Module Rear Left)	VCDFA
		TPM(Tire Pressure Monitor)	VCDF
		TCM(Transmission Control Module)	VCDFA
		PEM(Passive Entry Module)	VCDF
		VES3(Last Row Screen)	VCDFA
		ORC(Occupant Restraint)	VCDF
		EPPM(Electronic Pedestrian Protection Module)	VCDF
		PSDML(Power Sliding Doors (Left))	VCD
		FSM(Fold Stow Module)	VCDA
		HFM(Hands Free Module(cell phone))	VCDA
		ABS(Anti Lock Brakes)	VCDFA
		PTS(Parktronics)	VCDFA
		PSDMR(Power Sliding Doors (Right))	VCD
	WCM(Wireless Control)	VCDFA	
	ITM(Intrusion)	VCDFA	

LANCIA V16.40 Diagnostics List (Note: For reference only)

Models	Displacement	Systems	Functions
		HSM(Heated Seat Module)	VCDFA
		DMRR(Door Module Rear Right)	VCDFA
		DMFR(Door Module Front Right)	VCDFA
		HIDT(High Intensity Discharge Translator)	VCDA
		VES2(Second Row Screen)	VCDFA
		AHBM(Automatic High Beam)	VCD
		MSMD(Memory Seat)	VCDFA
		AMP(Amplifier)	VCDF
		LBSS(Left blind spot sensor)	VCD
		RBSS(Right blind spot sensor)	VCD
DEDRA	'96 1.8 16V 115 CV	Bosch 5.3 ABS	VCD
		Hitachi MPI Injection	VCDA
	'96 1.8 16V 115 CV	Bosch 5.3 ABS	VCD
		Hitachi MPI Injection	VCDA
	'96 1.8 16V 130 CV	Bosch 5.3 ABS	VCD
		Hitachi MPI Injection	VCDA
'98 1.6 16V	Bosch 5.3 ABS	VCD	
	Magneti Marelli IAW 49F injection (1.6 eng.)	VCDAS049	
DELTA (111)	'96 1.6 16V	Bosch 5.3 ABS	VCD
	'96 1.6 16V	Bosch 5.3 ABS	VCD
	'96 1.8 16V 115 CV	Bosch 5.3 ABS	VCD
		Hitachi MPI Injection	VCDA
	'96 1.8 16V 130 CV	Bosch 5.3 ABS	VCD
		Hitachi MPI Injection	VCDA
'96 2.0 TURBO 16V	Bosch 5.3 ABS	VCD	

LANCIA V16.40 Diagnostics List (Note: For reference only)

Models	Displacement	Systems	Functions
	'96 TD	Bosch 5.3 ABS	VCD
	'98 1.6 16V	Bosch 5.3 ABS	VCD
		Magneti Marelli IAW 49F injection (1.6 eng.)	VCDAS049
	'98 1.8 16V	Bosch 5.3 ABS	VCD
		Hitachi MPI injection (eng. 1.8 16v '98)	VCDAS001
1.4 TURBO 16V	Engine-Gearbox	Bosch Motronic Injection Me7.9.10 CF5/EOBD (eng. 1.4)	VCDAS002
		Injection Landi Renzo LC02 Gas	VCDA
	Instrumentation	Marelli instrument panel 3	VCDAS003
		Marelli Radio Navigator	VCDA
		Marelli/Microsoft C3 Convergence	VCDAS004
		Marelli/Microsoft Convergence	VCDAS004
	Safety	Marelli Body Computer 8	VCDAS005
		SIEMENS Airbag 1 (Proxi)	VCDA
		TRW ABS ESP	VCDAS006
		TRW Lane Control Control Unit (HALF)	VCDA
	Comfort	Denso 3 climate control (Two-zone)	VCDAS007
		Driver's seat Lear 3	VCDA
		Passenger's seat Lear 3	VCDA
		TRW 3 Electric Steering	VCDS008
	Other systems	Tyre Pressure Control TRW 2	VCDAS057
		Valeo 2 Parking control unit	VCDAS059
		Valeo Semi-automatic Parking Control Unit	VCDAS056
	Engine-Gearbox	Bosch Diesel Injection EDC16C39 CF5/EOBD (1.6/1.9/2.0 eng.)	VCDAS009
		Marelli SELESPEED CFC300 Automatic Gearbox	VCDAS010
		Marelli instrument panel 3	VCDAS003

LANCIA V16.40 Diagnostics List (Note: For reference only)

Models	Displacement	Systems	Functions	
DELTA (181)	1.6 MJET 16V	Instrumentation	Marelli Radio Navigator	VCDA
			Marelli/Microsoft C3 Convergence	VCDAS004
			Marelli/Microsoft Convergence	VCDAS004
		Safety	Marelli Body Computer 8	VCDAS005
			SIEMENS Airbag 1 (Proxi)	VCDA
			TRW ABS ESP	VCDAS006
			TRW Lane Control Control Unit (HALF)	VCDA
		Comfort	Denso 3 climate control (Two-zone)	VCDAS007
			Driver's seat Lear 3	VCDA
			Passenger's seat Lear 3	VCDA
			TRW 3 Electric Steering	VCDS008
		Other systems	Tyre Pressure Control TRW 2	VCDAS057
			Valeo 2 Parking control unit	VCDAS059
			Valeo Semi-automatic Parking Control Unit	VCDAS056
	1.8 JTS TB 16V	Engine-Gearbox	Automatic Gearbox AISIN AF40-6	VCDAS011
			Bosch Injection Motronic MeD17.3.1 CF5/EOBD (eng. 1.8)	VCDAS012
		Instrumentation	Marelli instrument panel 3	VCDAS003
			Marelli Radio Navigator	VCDA
			Marelli/Microsoft C3 Convergence	VCDAS004
			Marelli/Microsoft Convergence	VCDAS004
		Safety	Marelli Body Computer 8	VCDAS005
			SIEMENS Airbag 1 (Proxi)	VCDA
			TRW ABS ESP	VCDAS006
TRW Lane Control Control Unit (HALF)			VCDA	
		Denso 3 climate control (Two-zone)	VCDAS007	

LANCIA V16.40 Diagnostics List (Note: For reference only)

Models	Displacement	Systems	Functions		
		Comfort	Driver's seat Lear 3	VCDA	
			Passenger's seat Lear 3	VCDA	
			TRW 3 Electric Steering	VCDS008	
		Other systems	Tyre Pressure Control TRW 2	VCDAS057	
			Valeo 2 Parking control unit	VCDAS059	
			Valeo Semi-automatic Parking Control Unit	VCDAS056	
	1.9 MJET 16V TWINTB	Engine-Gearbox	Bosch Diesel Injection EDC16C39 CF5/EOBD (1.6/1.9/2.0 eng.)	VCDAS009	
		Instrumentation	Marelli instrument panel 3	VCDAS003	
			Marelli Radio Navigator	VCDA	
			Marelli/Microsoft C3 Convergence	VCDAS004	
			Marelli/Microsoft Convergence	VCDAS004	
		Safety	Marelli Body Computer 8	VCDAS005	
			SIEMENS Airbag 1 (Proxi)	VCDA	
			TRW ABS ESP	VCDAS006	
			TRW Lane Control Control Unit (HALF)	VCDA	
		Comfort	Denso 3 climate control (Two-zone)	VCDAS007	
			Driver's seat Lear 3	VCDA	
			Passenger's seat Lear 3	VCDA	
			TRW 3 Electric Steering	VCDS008	
		Other systems	Tyre Pressure Control TRW 2	VCDAS057	
			Valeo 2 Parking control unit	VCDAS059	
			Valeo Semi-automatic Parking Control Unit	VCDAS056	
			Engine-Gearbox	Bosch Diesel Injection EDC16C39 CF5/EOBD (1.6/1.9/2.0 eng.)	VCDAS009
			Instrumentation	Marelli instrument panel 3	VCDAS003
	Marelli Radio Navigator			VCDA	

LANCIA V16.40 Diagnostics List (Note: For reference only)

Models	Displacement	Systems	Functions	
	2.0 MJET 16V	Instrumentation	Marelli/Microsoft C3 Convergence	VCDAS004
			Marelli/Microsoft Convergence	VCDAS004
		Safety	Marelli Body Computer 8	VCDAS005
			SIEMENS Airbag 1 (Proxi)	VCDA
			TRW ABS ESP	VCDAS006
			TRW Lane Control Control Unit (HALF)	VCDA
		Comfort	Denso 3 climate control (Two-zone)	VCDAS007
			Driver's seat Lear 3	VCDA
			Passenger's seat Lear 3	VCDA
			TRW 3 Electric Steering	VCDS008
		Other systems	Tyre Pressure Control TRW 2	VCDAS057
			Valeo 2 Parking control unit	VCDAS059
			Valeo Semi-automatic Parking Control Unit	VCDAS056
'98 2.4 JTD	Engine-Gearbox	Bosch EDC15 Diesel Injection (2.4 TD d.i. eng.)	VCDAS050	
		Bosch 5.3 ABS	VCD	
	Safety	TRW MY 97 Air Bag (2F-2P)	VCD	
		TRW MY 97 Air Bag (2F-2P-2L-S)	VCD	
		TRW MY 97 Air Bag (2F-2P-S)	VCD	
		TRW MY 97 Air Bag (2F-2P-S)	VCD	
	'99 2.0	Engine-Gearbox	Bosch Motronic ME3.1 injection (eng. 2.0 20V)	VCDAS001
		Safety	Bosch 5.3 ABS	VCD
TRW MY 97 Air Bag (2F-2P)			VCD	
TRW MY 97 Air Bag (2F-2P-2L-S)			VCD	
TRW MY 97 Air Bag (2F-2P-S)			VCD	
TRW MY 97 Air Bag (2F-2P-2L)			VCD	
Engine-Gearbox	Bosch Motronic ME3.1 injection (eng. 2.0 20v)	VCDAS001		

LANCIA V16.40 Diagnostics List (Note: For reference only)

Models	Displacement	Systems		Functions
K	'99 2.4	Safety	Bosch 5.3 ABS	VCD
			TRW MY 97 Air Bag (2F-2P)	VCD
			TRW MY 97 Air Bag (2F-2P-2L-S)	VCD
			TRW MY 97 Air Bag (2F-2P-S)	VCD
			TRW MY 97 Air Bag (2F-2P-2L)	VCD
	99 3.0	Safety	Bosch 5.3 ABS	VCD
			TRW MY 97 Air Bag (2F-2P)	VCD
			TRW MY 97 Air Bag (2F-2P-2L-S)	VCD
			TRW MY 97 Air Bag (2F-2P-S)	VCD
			TRW MY 97 Air Bag (2F-2P-2L)	VCD
	2.0	Safety	Bosch 5.3 ABS	VCD
			TRW MY 97 Air Bag (2F-2P)	VCD
			TRW MY 97 Air Bag (2F-2P-2L-S)	VCD
			TRW MY 97 Air Bag (2F-2P-S)	VCD
	2.0 TURBO	Safety	Bosch 5.3 ABS	VCD
			TRW MY 97 Air Bag (2F-2P)	VCD
			TRW MY 97 Air Bag (2F-2P-2L-S)	VCD
			TRW MY 97 Air Bag (2F-2P-S)	VCD
	2.4	Safety	Bosch 5.3 ABS	VCD
			TRW MY 97 Air Bag (2F-2P)	VCD
TRW MY 97 Air Bag (2F-2P-2L-S)			VCD	
TRW MY 97 Air Bag (2F-2P-S)			VCD	
2.4 TD	Safety	Bosch 5.3 ABS	VCD	
		TRW MY 97 Air Bag (2F-2P)	VCD	
		TRW MY 97 Air Bag (2F-2P-2L-S)	VCD	

LANCIA V16.40 Diagnostics List (Note: For reference only)

Models	Displacement	Systems	Functions	
	3.0	Safety	TRW MY 97 Air Bag (2F-2P-S)	VCD
			Bosch 5.3 ABS	VCD
			TRW MY 97 Air Bag (2F-2P)	VCD
			TRW MY 97 Air Bag (2F-2P-2L-S)	VCD
			TRW MY 97 Air Bag (2F-2P-S)	VCD
	1.6	Allied Airbag MY 97 (2F-2P-2L-2T-I)	VCD	
		Allied MY 97 Air Bag (2F-2P-2L-I-S)	VCD	
		Allied MY 97 AirBag (2F-2P-2L-I)	VCD	
		Allied MY 97 AirBag (2F-2P-I)	VCD	
		Allied MY 97 AirBag (2F-2P-I-S)	VCD	
		Bosch 5.3 ABS	VCD	
		Bosch discharge headlamp (left)	VCDA	
		Bosch discharge headlamp (right)	VCDA	
		ESP TRW Lucas ABS	VCDAS013	
		Injection - Magneti Marelli IAW 4AF/4EF/59F/5AF Outside EEC	VCDAS014	
		Magneti Marelli IAW 49F injection (1.6 eng.)	VCDAS049	
		Magneti Marelli IAW 4AF/4EF/59F/5AF EOBD injection	VCDAS014	
		Marelli Code 2 Electronic Key	VCD	
		SIEMENS MY 99 Airbag (2F-2P-2L-2T-I)	VCDA	
		TRW Lucas ABS	VCDAS015	
		VAS 97/3 Door Lock RF alarm/receiver	VCD	
		Allied Airbag MY 97 (2F-2P-2L-2T-I)	VCD	
		Allied MY 97 Air Bag (2F-2P-2L-I-S)	VCD	
		Allied MY 97 AirBag (2F-2P-2L-I)	VCD	
		Allied MY 97 AirBag (2F-2P-I)	VCD	

LANCIA V16.40 Diagnostics List (Note: For reference only)

Models	Displacement	Systems	Functions
LYBRA		Allied MY 97 AirBag (2F-2P-I-S)	VCD
		Bosch 5.3 ABS	VCD
		Bosch discharge headlamp (left)	VCDA
		Bosch discharge headlamp (right)	VCDA
		ESP TRW Lucas ABS	VCDAS013
		Hitachi EOBD injection	VCDAS001
		Hitachi MPI injection (eng. 1.8 16v '98)	VCDAS001
		Marelli Code 2 Electronic Key	VCD
		SIEMENS MY 99 Airbag (2F-2P-2L-2T-I)	VCDA
		TRW Lucas ABS	VCDAS015
		VAS 97/3 Door Lock RF alarm/receiver	VCD
	1.9 JTD	Allied Airbag MY 97 (2F-2P-2L-2T-I)	VCD
		Allied MY 97 Air Bag (2F-2P-2L-I-S)	VCD
		Allied MY 97 AirBag (2F-2P-2L-I)	VCD
		Allied MY 97 AirBag (2F-2P-I)	VCD
		Allied MY 97 AirBag (2F-2P-I-S)	VCD
		Bosch 5.3 ABS	VCD
		Bosch Diesel EDC15 injection (1.9 TD d.i. engine)	VCDAS050
		Bosch discharge headlamp (left)	VCDA
		Bosch discharge headlamp (right)	VCDA
		Bosch EDC15 CF3/EOBD Diesel Injection (eng. 1.9/2.4)	VCDAS016
		ESP TRW Lucas ABS	VCDAS013
		Marelli Code 2 Electronic Key	VCD
		SIEMENS MY 99 Airbag (2F-2P-2L-2T-I)	VCDA
		TRW Lucas ABS	VCDAS015

LANCIA V16.40 Diagnostics List (Note: For reference only)

Models	Displacement	Systems	Functions
	2.0	VAS 97/3 Door Lock RF alarm/receiver	VCD
		Allied Airbag MY 97 (2F-2P-2L-2T-I)	VCD
		Allied MY 97 Air Bag (2F-2P-2L-I-S)	VCD
		Allied MY 97 Air Bag (2F-2P-2L-I)	VCD
		Allied MY 97 Air Bag (2F-2P-I)	VCD
		Allied MY 97 Air Bag (2F-2P-I-S)	VCD
		Bosch 5.3 ABS	VCD
		Bosch discharge headlamp (left)	VCDA
		Bosch discharge headlamp (right)	VCDA
		Bosch Motronic Me3.1 EOBD injection (eng. 2.0/2.4 20v)	VCDAS001
		ESP TRW Lucas ABS	VCDAS013
		Injection-Bosch Motronic Me3.1 (eng. 2.0/2.4 20v Outside EEC)	VCDAS001
		Marelli Code 2 Electronic Key	VCD
		SIEMENS MY 99 Airbag (2F-2P-2L-2T-I)	VCDA
		TRW Lucas ABS	VCDAS015
		VAS 97/3 Door Lock RF alarm/receiver	VCD
		2.4 JTD	Allied Airbag MY 97 (2F-2P-2L-2T-I)
	Allied MY 97 Air Bag (2F-2P-2L-I-S)		VCD
	Allied MY 97 AirBag (2F-2P-2L-I)		VCD
	Allied MY 97 AirBag (2F-2P-I)		VCD
	Allied MY 97 AirBag (2F-2P-I-S)		VCD
	Bosch 5.3 ABS		VCD
	Bosch discharge headlamp (left)		VCDA
	Bosch discharge headlamp (right)		VCDA
	Bosch EDC15 CF3/EOBD Diesel Injection (eng. 1.9/2.4)		VCDAS016

LANCIA V16.40 Diagnostics List (Note: For reference only)

Models	Displacement	Systems	Functions
		Bosch EDC15 Diesel Injection (2.4 TD d.i. eng.)	VCDAS050
		ESP TRW Lucas ABS	VCDAS013
		Marelli Code 2 Electronic Key	VCD
		SIEMENS MY 99 Airbag (2F-2P-2L-2T-I)	VCDA
		TRW Lucas ABS	VCDAS015
		VAS 97/3 Door Lock RF alarm/receiver	VCD
		1.3 JTD	Engine-Gearbox
Marelli 6JF EOBD Diesel injection (eng. 1.3 JTD)	VCDAS018		
Marelli Automatic Gearbox SELESPEED CFC208F (1)	VCDAS055		
Marelli Diesel Injection 6F3 EOBD (eng. 1.3 JTD)	VCDAS051		
Marelli Diesel Injection 8DF CF5/EOBD (eng. 1.3 JTD)	VCDAS019		
Instrumentation	Marelli 3 Connect (multi-model)		VCDA
	Marelli instrument panel (Comfort)		VCDAS020
	Marelli instrument panel (Modal)		VCDAS021
Safety	Bosch 8 ABS		VCD
	Bosch 8 VDC ABS		VCDAS045
	Marelli 7 Body Computer		VCDAS047
	Marelli Body Computer 1		VCDAS046
	TRW MY 03 Airbag (2F-2P-2L-2T-I)		VCDA
	TRW MY 03 Airbag (2F-2P-2T-I)		VCDA
	TRW MY 03 Airbag (2F-2P-I)		VCDA
Comfort	Denso Climate Control 1 (Two-zone)		VCDAS022
	Marelli/Microsoft Convergence		VCDAS004
	TRW 1 Power Steering		VCDAS061
	TRW 3 Electric Steering		VCDS008

LANCIA V16.40 Diagnostics List (Note: For reference only)

Models	Displacement	Systems	Functions	
		Other systems	G.E.PROCOND boot	VCDA
			G.E.PROCOND Driver's Door	VCDA
			G.E.PROCOND Passenger Door	VCDA
			Single BITRON Driver's Door	VCDA
			Single Driver's Door G.E. PROCOND	VCDA
			Valeo Parking control unit	VCDS023
	1.4 16V	Engine-Gearbox	Bosch Motronic Injection Me7.9.10 CF5/EOBD (eng. 1.4)	VCDAS002
			Bosch Motronic ME7.3 H4M EOBD Injection	VCDAS001
			Marelli SELESPEED CFC228F Automatic Gearbox	VCDAS043
			Marelli SELESPEED CFC328 Automatic Gearbox	VCDAS024
		Instrumentation	Marelli 3 Connect (multi-model)	VCDA
			Marelli instrument panel (Comfort)	VCDAS020
			Marelli instrument panel (Modal)	VCDAS021
		Safety	Bosch 8 ABS	VCD
			Bosch 8 VDC ABS	VCDAS045
			Marelli 7 Body Computer	VCDAS047
			Marelli Body Computer 1	VCDAS046
			TRW MY 03 AirBag (2F-2P-2L-2T-I)	VCDA
			TRW MY 03 AirBag (2F-2P-2T-I)	VCDA
		Comfort	TRW MY 03 AirBag (2F-2P-I)	VCDA
			Denso Climate Control 1 (Two-zone)	VCDAS022
			Marelli/Microsoft Convergence	VCDAS004
			TRW 1 Power Steering	VCDAS061
				TRW 3 Electric Steering
			G.E.PROCOND boot	VCDA

LANCIA V16.40 Diagnostics List (Note: For reference only)

Models	Displacement	Systems	Functions	
MUSA		Other systems	G.E.PROCOND Driver's Door	VCDA
			G.E.PROCOND Passenger Door	VCDA
			Single BITRON Driver's Door	VCDA
			Single Driver's Door G.E. PROCOND	VCDA
			Valeo Parking control unit	VCDS023
	1.4 8V	Engine-Gearbox	Magneti Marelli Injection IAW 5SF CF4/EOBD (eng. 1.4 8v)	VCDAS025
			Instrumentation	Marelli 3 Connect (multi-model)
		Instrumentation	Marelli instrument panel (Comfort)	VCDAS020
			Marelli instrument panel (Modal)	VCDAS021
		Safety	Bosch 8 ABS	VCD
			Bosch 8 VDC ABS	VCDAS045
			Marelli 7 Body Computer	VCDAS047
			Marelli Body Computer 1	VCDAS046
			TRW MY 03 AirBag (2F-2P-2L-2T-I)	VCDA
			TRW MY 03 AirBag (2F-2P-2T-I)	VCDA
			TRW MY 03 AirBag (2F-2P-I)	VCDA
		Comfort	Denso Climate Control 1 (Two-zone)	VCDAS022
			Marelli/Microsoft Convergence	VCDAS004
			TRW 1 Power Steering	VCDAS061
			TRW 3 Electric Steering	VCDS008
		Other systems	G.E.PROCOND boot	VCDA
			G.E.PROCOND Driver's Door	VCDA
			G.E.PROCOND Passenger Door	VCDA
Single Driver's Door G.E. PROCOND	VCDA			
Valeo Parking control unit	VCDS023			

LANCIA V16.40 Diagnostics List (Note: For reference only)

Models	Displacement	Systems	Functions
	1.6 MJET 16V	Engine-Gearbox	Bosch Diesel Injection EDC16C39 CF5/EOBD (1.6/1.9/2.0 eng.) VCDAS009
		Instrumentation	Marelli 3 Connect (multi-model) VCDA
			Marelli instrument panel (Comfort) VCDAS020
			Marelli instrument panel (Modal) VCDAS021
		Safety	Bosch 8 ABS VCD
			Bosch 8 VDC ABS VCDAS045
			Marelli Body Computer VCD
			TRW MY 03 AirBag (2F-2P-2L-2T-I) VCDA
			TRW MY 03 AirBag (2F-2P-2T-I) VCDA
			TRW MY 03 AirBag (2F-2P-I) VCDA
		Comfort	Denso Climate Control 1 (Two-zone) VCDAS022
			Marelli/Microsoft Convergence VCDAS004
			TRW 1 Power Steering VCDAS061
			TRW 3 Electric Steering VCDS008
		Other systems	G.E.PROCOND boot VCDA
			G.E.PROCOND Driver's Door VCDA
			G.E.PROCOND Passenger Door VCDA
			Single Driver's Door G.E. PROCOND VCDA
			Valeo Parking control unit VCDS023
	Engine-Gearbox	Bosch EDC16C9 CF3/EOBD Diesel Injection (1.9 eng.) VCDAS026	
		Bosch EDC16C9 CF4/EOBD Diesel Injection (1.9 eng.) VCDAS027	
	Instrumentation	Marelli 3 Connect (multi-model) VCDA	
		Marelli instrument panel (Comfort) VCDAS020	
Marelli instrument panel (Modal) VCDAS021			
		Bosch 8 ABS VCD	

LANCIA V16.40 Diagnostics List (Note: For reference only)

Models	Displacement	Systems	Functions	
	1.9 JTD	Safety	Bosch 8 VDC ABS	VCDAS045
			Marelli 7 Body Computer	VCDAS047
			Marelli Body Computer 1	VCDAS046
			TRW MY 03 AirBag (2F-2P-2L-2T-I)	VCDA
			TRW MY 03 AirBag (2F-2P-2T-I)	VCDA
			TRW MY 03 AirBag (2F-2P-I)	VCDA
		Comfort	Denso Climate Control 1 (Two-zone)	VCDAS022
			Marelli/Microsoft Convergence	VCDAS004
			TRW 3 Electric Steering	VCDS008
		Other systems	G.E.PROCOND boot	VCDA
			G.E.PROCOND Driver's Door	VCDA
			G.E.PROCOND Passenger Door	VCDA
			Single BITRON Driver's Door	VCDA
			Single Driver's Door G.E. PROCOND	VCDA
			Valeo Parking control unit	VCDS023
		Engine-Gearbox	Magneti Marelli MM4MP2 PSA Injection	VCDA
			Magneti Marelli MM6LP PSA Injection	VCDAS053
			Siemens AL4 TA2000 V PSA Automatic Gearbox	VCDAS054
Instrumentation	Marelli DAV PSA Connect control	VCD		
	Marelli odometer w. lamps (BTO)	VCDA		
	Marelli PSA Connect	VCDAS028		
	Marelli PSA instrument panel	VCDA		
	Sagem multi-function screen	VCDA		
		Bosch 5.7 ESP PSA ABS	VCDAS052	

LANCIA V16.40 Diagnostics List (Note: For reference only)

Models	Displacement	Systems	Functions	
	2.0 16V	Safety	Sagem Body Computer	VCDAS029
			Temic airbag	VCDS030
			Texton alarm 2	VCDA
		Comfort	Bitron PSA driver's seat	VCDA
			Clarion CD Changer	VCDA
			Clarion/Philips sound system	VCDAS031
			Marelli PSA climate control	VCDA
		Other systems	Eaton multi-switch stalk unit (COM2000)	VCD
			Inalfa central sunroof	VCDAS084
			Inalfa front sunroof	VCDAS084
			Inalfa rear sunroof	VCDAS084
			Marelli PSA Driver's Door	VCDA
			Marelli PSA Passenger's Door	VCDS032
			Texton sliding doors	VCDA
			Valeo PSA discharge headlamp (LH)	VCDAS062
	Valeo PSA discharge headlamp (RH)		VCDAS063	
	Valeo PSA Parking Control unit	VCDA		
	Engine-Gearbox	Bosch EDC 15 PSA diesel injection (eng. 16v)	VCDAS033	
		Siemens AL4 TA2000 V PSA Automatic Gearbox	VCDAS054	
	Instrumentation	Marelli DAV PSA Connect control	VCD	
		Marelli odometer w. lamps (BTO)	VCDA	
		Marelli PSA Connect	VCDAS028	
		Marelli PSA instrument panel	VCDA	
Sagem multi-function screen		VCDA		
		Bosch 5.7 ESP PSA ABS	VCDAS052	

LANCIA V16.40 Diagnostics List (Note: For reference only)

Models	Displacement	Systems	Functions	
PHEDRA	2.0 JTD 16V	Safety	Sagem Body Computer	VCDAS029
			Temic airbag	VCDS030
			Texton alarm 2	VCDA
		Comfort	Bitron PSA driver's seat	VCDA
			Clarion CD Changer	VCDA
			Clarion/Philips sound system	VCDAS031
			Marelli PSA climate control	VCDA
			WEBASTO Heater (PSA)	VCDA
			Other systems	Eaton multi-switch stalk unit (COM2000)
		Inalfa central sunroof		VCDAS084
		Inalfa front sunroof		VCDAS084
		Inalfa rear sunroof		VCDAS084
		Marelli diesel additive check		VCDAS034
		Marelli PSA Driver's Door		VCDA
		Marelli PSA Passenger's Door		VCDS032
		Texton sliding doors		VCDA
		Valeo PSA discharge headlamp (LH)		VCDAS062
		Valeo PSA discharge headlamp (RH)		VCDAS063
		Valeo PSA Parking Control unit		VCDA
		Engine-Gearbox	Bosch EDC 15 PSA diesel injection (eng. 16v)	VCDAS033
			Instrumentation	Marelli DAV PSA Connect control
		Marelli odometer w. lamps (BTO)		VCDA
		Marelli PSA Connect		VCDAS028
Marelli PSA instrument panel	VCDA			
Sagem multi-function screen	VCDA			

LANCIA V16.40 Diagnostics List (Note: For reference only)

Models	Displacement	Systems	Functions	
	2.2 JTD 16V	Safety	Bosch 5.7 ESP PSA ABS	VCDAS052
			Sagem Body Computer	VCDAS029
			Temic airbag	VCDS030
			Texton alarm 2	VCDA
		Comfort	Bitron PSA driver's seat	VCDA
			Clarion CD Changer	VCDA
			Clarion/Philips sound system	VCDAS031
			Marelli PSA climate control	VCDA
			WEBASTO Heater (PSA)	VCDA
		Other systems	Eaton multi-switch stalk unit (COM2000)	VCD
			Inalfa central sunroof	VCDAS084
			Inalfa front sunroof	VCDAS084
			Inalfa rear sunroof	VCDAS084
			Marelli diesel additive check	VCDAS034
			Marelli PSA Driver's Door	VCDA
			Marelli PSA Passenger's Door	VCDS032
			Texton sliding doors	VCDA
			Valeo PSA discharge headlamp (LH)	VCDAS062
			Valeo PSA discharge headlamp (RH)	VCDAS063
			Valeo PSA Parking Control unit	VCDA
		Engine-Gearbox	Bosch Motronic Me7.4.6 PSA Injection	VCDAS035
			ZF 4HP20 PSA Automatic Gearbox	VCD
		Instrumentation	Marelli DAV PSA Connect control	VCD
			Marelli odometer w. lamps (BTO)	VCDA
			Marelli PSA Connect	VCDAS028

LANCIA V16.40 Diagnostics List (Note: For reference only)

Models	Displacement	Systems	Functions	
	3.0 V6 24V		Marelli PSA instrument panel	VCDA
			Sagem multi-function screen	VCDA
		Safety	Bosch 5.7 ESP PSA ABS	VCDAS052
			Sagem Body Computer	VCDAS029
			Temic airbag	VCDS030
			Texton alarm 2	VCDA
		Comfort	Bitron PSA driver's seat	VCDA
			Clarion CD Changer	VCDA
			Clarion/Philips sound system	VCDAS031
			Marelli PSA climate control	VCDA
		Other systems	Eaton multi-switch stalk unit (COM2000)	VCD
			Inalfa central sunroof	VCDAS084
			Inalfa front sunroof	VCDAS084
			Inalfa rear sunroof	VCDAS084
			Marelli PSA Driver's Door	VCDA
			Marelli PSA Passenger's Door	VCDS032
			Texton sliding doors	VCDA
			Valeo PSA discharge headlamp (LH)	VCDAS062
			Valeo PSA discharge headlamp (RH)	VCDAS063
		Valeo PSA Parking Control unit	VCDA	
Engine-Gearbox	Bosch EDC 15 PSA diesel injection (eng. 16v)	VCDAS033		
	Siemens AL4 TA2000 V PSA Automatic Gearbox	VCDAS054		
	Siemens Diesel Injection SID803 CF4/EOBD (eng. 16v)	VCDAS036		
	Johnson/Borg multi-function screen	VCDAS073		
	Marelli odometer warning lamps (BTO CAN)	VCDA		

LANCIA V16.40 Diagnostics List (Note: For reference only)

Models	Displacement	Systems	Functions	
PHEDRA (180)	2.0 JTD 16V	Instrumentation	PSA DAV Connect Command (CAN)	VCD
			PSA Marelli Connect (CAN)	VCDAS085
			Marelli Connect PSA RT5 (CAN)	VCDAS082
			PSA Marelli cluster (CAN)	VCDA
		Safety	Bosch ABS 8.1 ESP PSA (CAN)	VCDAS070
			Johnson EV Body Computer (BSI CAN) 2	VCDAS088
			BOSCH/TEMIC Airbag (CAN)	VCDAS071
			PSA Bosch ABS 8 ESP (CAN)	VCDAS083
			Delphi Alarm	VCDAS072
		Comfort	Blaupunkt radio	VCDA
			PSA Denso Climate Control (CAN)	VCDA
			WEBASTO Heater (PSA)	CDA
		Other systems	Valeo PSA discharge headlamp (LH)	VCDAS062
			Valeo PSA discharge headlamp (RH)	VCDAS063
			Delphi multi-function switch (COM2005)	VCDA
			Brose Driver's Door	VCDA
			Brose passenger door	VCDA
			Delphi multi-SWITCH (COM2003)	VCDA
			Inalfa centre sunroof (CAN)	VCDA
			Inalfa front sunroof (CAN)	VCDA
Inalfa rear sunroof (CAN)	VCDA			
Marelli Diesel additive control (CAN)	VCDAS087			
Siemens Tyre Pressure Control	VCDAS086			
Texton sliding doors (CAN)	VCDA			
PSA Valeo Parking Control Unit (CAN)	VCDA			

LANCIA V16.40 Diagnostics List (Note: For reference only)

Models	Displacement	Systems	Functions	
		Engine-Gearbox	AISIN AM6 Automatic Gearbox	VCDAS037
			Bosch Diesel Injection EDC16CP39 CF4/EOBD (2.2 eng.)	VCDAS038
			Bosch EDC 15 PSA diesel injection (eng. 16v)	VCDAS033
		Instrumentation	Johnson/Borg multi-function screen	VCDAS073
			Marelli odometer warning lamps (BTO CAN)	VCDA
			Marelli Connect PSA RT5 (CAN)	VCDAS082
			PSA DAV Connect Command (CAN)	VCD
			PSA Marelli Connect (CAN)	VCDAS085
			PSA Marelli cluster (CAN)	VCDA
		Safety	Bosch ABS 8.1 ESP PSA (CAN)	VCDAS070
			Johnson EV Body Computer (BSI CAN) 2	VCDAS088
			BOSCH/TEMIC Airbag (CAN)	VCDAS071
			PSA Bosch ABS 8 ESP (CAN)	VCDAS083
			Delphi Alarm	VCDAS072
		Comfort	Blaupunkt radio	VCDA
			PSA Denso Climate Control (CAN)	VCDA
			WEBASTO Heater (PSA)	CDA
		Other systems	Valeo PSA discharge headlamp (LH)	VCDAS062
			Valeo PSA discharge headlamp (RH)	VCDAS063
			Brose Driver's Door	VCDA
			Brose passenger door	VCDA
			Delphi multi-SWITCH (COM2003)	VCDA
			Inalfa centre sunroof (CAN)	VCDA
Inalfa front sunroof (CAN)	VCDA			
Inalfa rear sunroof (CAN)	VCDA			

LANCIA V16.40 Diagnostics List (Note: For reference only)

Models	Displacement	Systems	Functions			
	2.2 JTD 16V		Marelli Diesel additive control (CAN)	VCDAS087		
			Siemens Tyre Pressure Control	VCDAS086		
			Texton sliding doors (CAN)	VCDA		
			PSA Valeo Parking Control Unit (CAN)	VCDA		
	2.0 20V TB	Engine-Gearbox	Bosch Motronic Me7.3.1 EOBD injection (2 lambda sensors)	VCDAS001		
		Safety	ESP TRW Lucas ABS	VCDAS013		
			Marelli Easy-go Body computer	VCDAS046		
			Marelli Full Body computer	VCDAS046		
			TRW MY99 Airbag (2F-4P-2L-2T-I-S-C)	VCD		
			TRW MY99 Airbag (2F-4P-4L-2T-I-S-C)	VCD		
		Comfort	Bitron driving seat	VCDA		
			Bitron passenger seat	VCDA		
			Borletti/Hella climate control	VCDS089		
			SAGEM SpeedPro power steering	VCD		
		Other systems	Marelli Boot	VCDA		
			Marelli Driver's Door	VCDA		
			Marelli Passenger Door	VCDA		
			Valeo Parking control unit	VCDS023		
				Engine-Gearbox	AISIN YLII 5 Automatic Gearbox	VCDA
					Bosch Motronic Me3.1 EOBD injection (eng. 2.0/2.4 20v)	VCDAS001
Safety	ESP TRW Lucas ABS			VCDAS013		
	Marelli Easy-go Body computer			VCDAS046		
	Marelli Full Body computer			VCDAS046		
	TRW MY99 Airbag (2F-4P-2L-2T-I-S-C)			VCD		
	TRW MY99 Airbag (2F-4P-4L-2T-I-S-C)			VCD		

LANCIA V16.40 Diagnostics List (Note: For reference only)

Models	Displacement	Systems	Functions	
	2.4 20V	Comfort	Bitron driving seat	VCDA
			Bitron passenger seat	VCDA
			Borletti/Hella climate control	VCDS089
			SAGEM SpeedPro power steering	VCD
		Other systems	Marelli Boot	VCDA
			Marelli Driver's Door	VCDA
			Marelli Passenger Door	VCDA
			Valeo Parking control unit	VCDS023
	2.4 JTD 10V	Engine-Gearbox	Bosch EDC15 CF3/EOBD Diesel injection (eng. 1.9/2.4)	VCDA S016
		Safety	ESP TRW Lucas ABS	VCDA S013
			Marelli Easy-go Body computer	VCDA S046
			Marelli Full Body computer	VCDA S046
			TRW MY99 Airbag (2F-4P-2L-2T-I-S-C)	VCD
			TRW MY99 Airbag (2F-4P-4L-2T-I-S-C)	VCD
		Comfort	Bitron driving seat	VCDA
			Bitron passenger seat	VCDA
			Borletti/Hella climate control	VCDS089
			SAGEM SpeedPro power steering	VCD
		Other systems	Marelli Boot	VCDA
			Marelli Driver's Door	VCDA
			Marelli Passenger Door	VCDA
			Valeo Parking control unit	VCDS023
		Engine-Gearbox	AISIN YLII 5 Automatic Gearbox	VCDA
Bosch Diesel Injection EDC16C39 CF4/EOBD (eng. 1.9/2.4)	VCDA S039			
Bosch EDC16 CF3/EOBD Diesel Injection (1.9/2.4 eng.)	VCDA S040			

LANCIA V16.40 Diagnostics List (Note: For reference only)

Models	Displacement	Systems		Functions
THEISIS	2.4 JTD 20V	Instrumentation	Nippon Seiki instrument panel (Thesis)	VCDAS060
		Safety	ESP TRW Lucas ABS	VCDAS013
			Marelli Easy-go Body computer	VCDAS046
			Marelli Full Body computer	VCDAS046
			TRW MY99 Airbag (2F-4P-2L-2T-I-S-C)	VCD
			TRW MY99 Airbag (2F-4P-4L-2T-I-S-C)	VCD
			Comfort	Bitron driving seat
		Bitron passenger seat		VCDA
		Borletti/Hella climate control		VCDS089
		SAGEM SpeedPro power steering		VCD
		Other systems	Marelli Boot	VCDA
			Marelli Driver's Door	VCDA
			Marelli Passenger Door	VCDA
			Valeo Parking control unit	VCDS023
	3.0 V6 24V	Engine-Gearbox	AISIN YLII 5 Automatic Gearbox	VCDA
			Bosch Motronic EOBD ME3.1 Injection (eng. V6)	VCDAS001
		Instrumentation	Nippon Seiki instrument panel (Thesis)	VCDAS060
		Safety	ESP TRW Lucas ABS	VCDAS013
			Marelli Easy-go Body computer	VCDAS046
			Marelli Full Body computer	VCDAS046
			TRW MY 99 Airbag (2F-4P-2L-2T-I-S-C)	VCD
			TRW MY 99 Airbag (2F-4P-4L-2T-I-S-C)	VCD
TRW MY 99 Airbag (2F-4P-I-S-C)			VCD	
Comfort		Bitron driving seat	VCDA	
	Bitron passenger seat	VCDA		

LANCIA V16.40 Diagnostics List (Note: For reference only)

Models	Displacement	Systems	Functions		
		Comfort	Borletti/Hella climate control	VCDS089	
			SAGEM SpeedPro power steering	VCD	
		Other systems	Marelli Boot	VCDA	
			Marelli Driver's Door	VCDA	
			Marelli Passenger Door	VCDA	
			Valeo Parking control unit	VCDS023	
		3.2 V6 24V	Engine-Gearbox	AISIN YLII 5 Automatic Gearbox	VCDA
				Bosch Motronic ME7.3.1 EOBD Injection	VCDAS001
				Injection-Bosch Motronic Me7.3.1 Outside EEC	VCDAS001
			Instrumentation	Nippon Seiki instrument panel (Thesis)	VCDAS060
	Safety		ESP TRW Lucas ABS	VCDAS013	
			Marelli Easy-go Body computer	VCDAS046	
			Marelli Full Body computer	VCDAS046	
			TRW MY 99 Airbag (2F-4P-2L-2T-I-S-C)	VCD	
			TRW MY 99 Airbag (2F-4P-4L-2T-I-S-C)	VCD	
	Comfort		Bitron driving seat	VCDA	
			Bitron passenger seat	VCDA	
			Borletti/Hella climate control	VCDS089	
			SAGEM SpeedPro power steering	VCD	
	Other systems	Marelli Boot	VCDA		
		Marelli Driver's Door	VCDA		
		Marelli Passenger Door	VCDA		
		Valeo Parking control unit	VCDS023		
		Allied MY 97 Air Bag (2F-2P-2L-S)	VCD		
		Allied MY 97 Airbag (2F-2P-2L-I)	VCD		

LANCIA V16.40 Diagnostics List (Note: For reference only)

Models	Displacement	Systems	Functions
Y	1.1	Allied MY 97 Airbag (2F-2P-I)	VCD
		Bosch 5.3 ABS	VCD
		Magneti Marelli IAW 16F Injection	VCD
	1.2	Allied MY 97 Air Bag (2F-2P-2L-S)	VCD
		Allied MY 97 Airbag (2F-2P-2L-I)	VCD
		Allied MY 97 Airbag (2F-2P-I)	VCD
		Bosch 5.3 ABS	VCD
		Fuji MX665 Automatic Transmission (EEC2 engine)	VCD
		Magneti Marelli IAW 16F Injection	VCD
		1.2 16V	Allied MY 97 Air Bag (2F-2P-2L-S)
	Allied MY 97 Airbag (2F-2P-2L-I)		VCD
	Allied MY 97 Airbag (2F-2P-I)		VCD
	Bosch 5.3 ABS		VCD
	1.2 16V CF3	Allied MY 97 Air Bag (2F-2P-2L-S)	VCD
		Allied MY 97 Airbag (2F-2P-2L-I)	VCD
		Allied MY 97 Airbag (2F-2P-I)	VCD
		Bosch 5.3 ABS	VCD
		Bosch Motronic ME7.3H4 EOBD injection	VCDAS001
	1.2 CF3	Allied MY 97 Air Bag (2F-2P-2L-S)	VCD
		Allied MY 97 Air Bag (2F-2P-S)	VCD
		Allied MY 97 Airbag (2F-2P)	VCD
Allied MY 97 Airbag (2F-2P-2L-I)		VCD	
Allied MY 97 Airbag (2F-2P-I)		VCD	
Bosch 5.3 ABS		VCD	
Fuji MX665 Automatic Transmission (EEC2 engine)		VCD	

LANCIA V16.40 Diagnostics List (Note: For reference only)

Models	Displacement	Systems	Functions	
	1.4	Magneti Marelli IAW 4AF/4EF/59F/5AF EOBD injection	VCDAS014	
		Allied MY 97 Airbag (2F-2P)	VCD	
		Allied MY 97 Airbag (2F-2P-2L-I)	VCD	
		Allied MY 97 Airbag (2F-2P-I)	VCD	
		Bosch 5.3 ABS	VCD	
	1.2 16V	Engine-Gearbox	Bosch Motronic ME7.3H4M EOBD Injection	VCDAS001
		Instrumentation	Marelli 3 Connect (multi-model)	VCDA
			Siemens instrument panel	VCDAS058
		Safety	Autoliv AirBag 99 (A) (2F-2P-2L-I)	VCDA
			Autoliv Airbag MY 99 (2F-2P-2L-2T-1G-I)	VCDA
			Autoliv Airbag MY 99 (2F-2P-2L-2T-I)	VCDA
			Autoliv Airbag MY 99 (2F-2P-2T-I)	VCDA
			Autoliv Airbag MY 99 (2F-2P-4L-2T-1G-I)	VCDA
			Autoliv MY 99 Airbag (2F-2P-I)	VCDA
			ESP TRW Lucas ABS	VCDAS013
			Marelli/Finmek Body Computer	VCDAS041
		TRW Lucas ABS	VCDAS015	
		Comfort	DELPHI Electric Steering	VCDS044
			Denso Climate Control (Two-zone)	VCDAS007
		Other systems	Bitron Driver's door	VCDA
			BITRON passenger door	VCDA
			Bosch Parking Control Unit	VCDAS042
			G.E.PROCKND Driver's Door	VCDA
			G.E.PROCOND Passenger Door	VCDA
		Single BITRON Driver's Door	VCDA	

LANCIA V16.40 Diagnostics List (Note: For reference only)

Models	Displacement	Systems	Functions
	1.2 8V		Singele Driver's Door G.E.PROCOND VCDA
		Engine-Gearbox	Magneti Marelli IAW 4AF/4EF/59F/5AF EOBD injection VCDAS014
		Instrumentation	Marelli 3 Connect (multi-model) VCDA
			Siemens instrument panel VCDAS058
		Safety	Autoliv AirBag 99 (A) (2F-2P-2L-I) VCDA
			Autoliv Airbag MY 99 (2F-2P-2L-2T-1G-I) VCDA
			Autoliv Airbag MY 99 (2F-2P-2L-2T-I) VCDA
			Autoliv Airbag MY 99 (2F-2P-2T-I) VCDA
			Autoliv Airbag MY 99 (2F-2P-4L-2T-1G-I) VCDA
			Autoliv MY 99 Airbag (2F-2P-I) VCDA
			ESP TRW Lucas ABS VCDAS013
			Marelli/Finmek Body Computer VCDAS041
		Comfort	TRW Lucas ABS VCDAS015
			DELPHI Electric Steering VCDS044
		Other systems	Denso Climate Control (Two-zone) VCDAS007
			BITRON Driver's door VCDA
			BITRON passenger door VCDA
			Bosch Parking Control Unit VCDAS042
			G.E.PROCKND Driver's Door VCDA
			G.E.PROCOND Passenger Door VCDA
			Single BITRON Driver's Door VCDA
		Single Driver's Door G.E.PROCOND VCDA	
		Engine-Gearbox	Marelli 6JF EOBD Diesel injection (eng. 1.3 JTD) VCDAS018
			Marelli Automatic Gearbox SELESPEED CFC208F (1) VCDAS055
			Marelli Diesel Injection 6F3 EOBD (eng. 1.3 JTD) VCDAS051

LANCIA V16.40 Diagnostics List (Note: For reference only)

Models	Displacement	Systems	Functions	
YPSILON	1.3 JTD	Instrumentation	Marelli 3 Connect (multi-model)	VCDA
			Siemens instrument panel	VCDAS058
		Safety	Autoliv AirBag 99 (A) (2F-2P-2L-I)	VCDA
			Autoliv Airbag MY 99 (2F-2P-2L-2T-1G-I)	VCDA
			Autoliv Airbag MY 99 (2F-2P-2L-2T-I)	VCDA
			Autoliv Airbag MY 99 (2F-2P-2T-I)	VCDA
			Autoliv Airbag MY 99 (2F-2P-4L-2T-1G-I)	VCDA
			Autoliv MY 99 Airbag (2F-2P-I)	VCDA
			ESP TRW Lucas ABS	VCDAS013
			Marelli/Finmek Body Computer	VCDAS041
		TRW Lucas ABS	VCDAS015	
		Comfort	DELPHI Electric Steering	VCDS044
			Denso Climate Control (Two-zone)	VCDAS007
		Other systems	BITRON Driver's door	VCDA
			BITRON passenger door	VCDA
			Bosch Parking Control Unit	VCDAS042
			G.E.PROCKND Driver's Door	VCDA
	G.E.PROCOND Passenger Door		VCDA	
	Single BITRON Driver's Door		VCDA	
	Single Driver's Door G.E.PROCOND		VCDA	
	Engine-Gearbox	Bosch Motronic ME7.3H4M EOBD Injection	VCDAS001	
		Marelli SELESPEED CFC228F Automatic Gearbox	VCDAS043	
	Instrumentation	Marelli 3 Connect (multi-model)	VCDA	
Siemens instrument panel		VCDAS058		
		Autoliv AirBag 99 (A) (2F-2P-2L-I)	VCDA	

LANCIA V16.40 Diagnostics List (Note: For reference only)

Models	Displacement	Systems	Functions	
	1.4 16V	Safety	Autoliv Airbag MY 99 (2F-2P-2L-2T-1G-I)	VCDA
			Autoliv Airbag MY 99 (2F-2P-2L-2T-I)	VCDA
			Autoliv Airbag MY 99 (2F-2P-2T-I)	VCDA
			Autoliv Airbag MY 99 (2F-2P-4L-2T-1G-I)	VCDA
			Autoliv MY 99 Airbag (2F-2P-I)	VCDA
			ESP TRW Lucas ABS	VCDAS013
			Marelli/Finmek Body Computer	VCDAS041
			TRW Lucas ABS	VCDAS015
		Comfort	DELPHI Electric Steering	VCDS044
			Denso Climate Control (Two-zone)	VCDAS007
		Other systems	BITRON Driver's door	VCDA
			BITRON passenger door	VCDA
			Bosch Parking Control Unit	VCDAS042
			G.E.PROCOND Driver's Door	VCDA
	G.E.PROCOND Passenger Door		VCDA	
	Single BITRON Driver's Door		VCDA	
	Single Driver's Door G.E.PROCOND	VCDA		
	'06 1.2 8V	Engine-Gearbox	Injection - Magneti Marelli IAW 4AF/4EF/59F/5AF Outside EEC	VCDAS014
			Magneti Marelli IAW 4AF/4EF/59F/5AF EOBD injection	VCDAS014
		Instrumentation	Marelli 3 Connect (multi-model)	VCDA
			Siemens instrument panel	VCDAS058
		Safety	ESP TRW Lucas ABS	VCDAS013
			Marelli 7 Body Computer	VCDAS047
TRW Lucas ABS			VCDAS015	
			DELPHI Electric Steering	VCDS044

LANCIA V16.40 Diagnostics List (Note: For reference only)

Models	Displacement	Systems	Functions	
		Comfort	Denso Climate Control (Two-zone)	VCDAS007
			Marelli/Microsoft Convergence	VCDAS004
		Other systems	Bosch Parking Control Unit	VCDAS042
	'06 1.3 JTD	Engine-Gearbox	Marelli Automatic Gearbox SELESPEED CFC208F (1)	VCDAS055
			Marelli Diesel injection 6F3 EOBD (eng. 1.3 JTD)	VCDAS051
		Instrumentation	Marelli 3 Connect (multi-model)	VCDA
			Siemens instrument panel	VCDAS058
		Safety	ESP TRW Lucas ABS	VCDAS013
			Marelli 7 Body Computer	VCDAS047
			TRW Lucas ABS	VCDAS015
		Comfort	DELPHI Electric Steering	VCDS044
			Denso Climate Control (Two-zone)	VCDAS007
			Marelli/Microsoft Convergence	VCDAS004
	Other systems	Bosch Parking Control Unit	VCDAS042	
	'06 1.4 16V	Engine-Gearbox	Bosch Motronic ME7.3H4M EOBD Injection	VCDAS001
			Marelli SELESPEED CFC228F Automatic Gearbox	VCDAS043
		Instrumentation	Marelli 3 Connect (multi-model)	VCDA
			Siemens instrument panel	VCDAS058
		Safety	ESP TRW Lucas ABS	VCDAS013
			Marelli 7 Body Computer	VCDAS047
			TRW Lucas ABS	VCDAS015
Comfort		DELPHI Electric Steering	VCDS044	
		Denso Climate Control (Two-zone)	VCDAS007	
		Marelli/Microsoft Convergence	VCDAS004	
Other systems	Bosch Parking Control Unit	VCDAS042		

LANCIA V16.40 Diagnostics List (Note: For reference only)

Models	Displacement	Systems	Functions
	'06 1.4 8V	Engine-Gearbox	Magneti Marelli Injection IAW 5SF CF4/EOBD (eng. 1.4 8v) VCDAS025
		Instrumentation	Marelli 3 Connect (multi-model) VCDA
			Siemens instrument panel VCDAS058
		Safety	ESP TRW Lucas ABS VCDAS013
			Marelli 7 Body Computer VCDAS047
			TRW Lucas ABS VCDAS015
		Comfort	DELPHI Electric Steering VCDS044
			Denso Climate Control (Two-zone) VCDAS007
			Marelli/Microsoft Convergence VCDAS004
		Other systems	Bosch Parking Control Unit VCDAS042
	0.9 TURBO TWIN AIR	Engine-Gearbox	Automatic Gearbox Marelli SELESPEED CFC328 2 VCDAS066
			Magneti Marelli IAW 8GSF CF5/EOBD Injection (EP 0.9 engine) VCDAS064
		Instrumentation	Continental instrument panel (EP) VCDAS077
			Lauberhorn Convergence (EP) VCDAS081
		Safety	Bosch ABS 9 (EP) VCDAS067
			Bosch ABS 9 ESP (EP) VCDAS068
			Delphi (EP) 6 Body Computer VCDAS076
			Bosch Air bag (EP) VCDA
		Comfort	Denso Heater (EP) VCDA
			DELPHI Electric Steering (EP) 4 VCDS078
			Marelli Single-Zone Automatic Climate Control (EP) VCDAS079
		Other systems	VALEO Parking Control unit (EP) 2 VCDAS069
			Litronic discharge headlamp (left) VCDA
Litronic discharge headlamp (right) VCD			
Valeo Semi-Automatic Parking Control Unit (EP) VCDAS080			

LANCIA V16.40 Diagnostics List (Note: For reference only)

Models	Displacement	Systems	Functions	
	1.2 8V	Engine-Gearbox	Magneti Marelli Injection IAW 5SF9 CF5/EOBD (EP eng. 8V)	VCDAS065
			Magneti Marelli Injection 5SF8 / SDU CF5/EOBD LPG (EP)	VCDAS074
		Instrumentation	Continental instrument panel (EP)	VCDAS077
			Lauberhorn Convergence (EP)	VCDAS081
		Safety	Bosch ABS 9 (EP)	VCDAS067
			Bosch ABS 9 ESP (EP)	VCDAS068
			Delphi (EP) 6 Body Computer	VCDAS076
			Bosch Air bag (EP)	VCDA
		Comfort	Denso Heater (EP)	VCDA
			DELPHI Electric Steering (EP) 4	VCDS078
			Marelli Single-Zone Automatic Climate Control (EP)	VCDAS079
		Other systems	VALEO Parking Control unit (EP) 2	VCDAS069
			Litronic discharge headlamp (left)	VCDA
			Litronic discharge headlamp (right)	VCD
	Valeo Semi-Automatic Parking Control Unit (EP)		VCDAS080	
	1.3 MJET 16V	Engine-Gearbox	Marelli Diesel Injection 8F3 CF5/EOBD (EP 1.3 JTD engine)	VCDAS075
		Instrumentation	Continental instrument panel (EP)	VCDAS077
			Lauberhorn Convergence (EP)	VCDAS081
		Safety	Bosch ABS 9 (EP)	VCDAS067
Bosch ABS 9 ESP (EP)			VCDAS068	
Delphi (EP) 6 Body Computer			VCDAS076	
Bosch Air bag (EP)			VCDA	
Comfort		Denso Heater (EP)	VCDA	
		DELPHI Electric Steering (EP) 4	VCDS078	
	Marelli Single-Zone Automatic Climate Control (EP)	VCDAS079		

LANCIA V16.40 Diagnostics List (Note: For reference only)

Models	Displacement	Systems	Functions	
YPSILON(402)		Other systems	VALEO Parking Control unit (EP) 2	VCDAS069
			Valeo Semi-Automatic Parking Control Unit (EP)	VCDAS080
Z	'00 2.0 16v	Magneti Marelli MM4.8P PSA injection	VCDA	
	'00 2.0 JTD	Bosch EDC 15 PSA Diesel Injection (2.0 8v v60 eng.)	VCDA	
		Bosch EDC 15 PSA Diesel Injection (eng. 16v)	VCDAS033	
		Bosch EDC 15 PSA Diesel Injection (eng. 2.0 8v)	VCDA	
		WEBASTO Heater (PSA)	VCDA	
(*): Tested; (?): Manual on website (www.x431.com) NOTE: The final interpretation of the products belongs to LAUNCH TECH CO., LTD				

N. B. :

V: Control Unit Info

C: Fault Codes

D: Datastream

A: Active Test

S: Additional Functions

- S001 Startup with Code Card
- S002 Startup with Code Card
- S002 Performance limiting
- S002 Neutral signal learn
- S002 Knock counter reset
- S002 Overboost counter reset
- S002 Self-learnt functions reset
- S002 Zeroing of self-adaption parameters

LANCIA V16.40 Diagnostics List (Note:For reference only)

Models	Displacement	Systems	Functions
S003			Headlamp pos. correct.
S003			Inputs status
S003			Servicing information delete
S003			Reset odometer
S003			Seat belts alarm exclusion
S003			Seat belts alarm enable
S003			Oil change servicing information delete
S003			Instrument panel replacement
S004			Audio System Test
S004			Convergence system Restart
S005			Siren Serial line check
S005			Ultrasound sensor check
S005			Tilt sensor check(if present)
S005			Dusk and rain sensors check
S005			Indicators command enable/disable
S005			Inertia switch rearm(FIS)
S005			Key programming
S006			Yaw sensor calibration
S006			Lateral accel. Sensor calibration
S006			Pressure sensor calibration
S006			Accept configuration
S006			Longit. Acc. Sensor calibration
S006			Accelerat. And yaw sensors calibration
S006			Recognition of speed sensor type
S007			Conditioner compressor

LANCIA V16.40 Diagnostics List (Note:For reference only)

Models	Displacement	Systems	Functions
S007			Flap actuators learning test
S007			Pollution sensor test
S007			Autotest
S008			Steering angle calibration
S008			Mounting check
S009			Startup with Code Card
S009			Injector codes read
S009			Neutral signal learn
S009			Replacement of injector cyl.1
S009			Replacement of injector cyl.2
S009			Replacement of injector cyl.3
S009			Replacement of injector cyl.4
S009			Injector replacement(per bank)
S009			Oil change(only for version with DPF)
S009			EGR valve replacement
S009			Variable geometry turbo replacement
S009			Rail pressure sensor replacement
S009			Replacement Lambda sensor
S009			Air flow meter sensor replacement
S009			Differential pressure sensor replacement(only for version with DPF)
S009			Pre-catalyser replacement(only for version with DPF)
S009			Particulate filter replacement (only for version with DPF)
S009			Replacement of particulate filter with built-in pre-catalyzer(only for versions with DPF)
S009			Particulate filter regeneration(only for version with DPF)
S009			Resetting distance travelled with Water Temp.w.lamp ON

LANCIA V16.40 Diagnostics List (Note: For reference only)

Models	Displacement	Systems	Functions
S009			Resetting distance travelled with Water in diesel w.lamp ON
S010			Accumulator depressurisation
S010			Clutch bleed
S010			End of line / service self-calibration
S010			Clutch self-calibration enable
S010			New actuators
S010			Satistical data deletion
S010			Clutch replacement
S010			KIT/Gearbox replacement
S010			Gearbox replacement
S010			Tunnel lever replacement
S010			Steering wheel levers replacement
S010			Electropump replacement
S010			Pump relay replacement
S010			AUTO switch replacement
S010			ECO/SPORT switch replacement
S010			Gearbox oil accumulator replacement
S010			Longitudinal acceleration signal learn
S011			Gearbox lever position learn
S011			Self-adaptation parameter erasure
S012			Startup with Code Card
S012			Oil change
S012			Knock counter reset
S012			Overboost counter reset
S012			Self-learnt functions reset

LANCIA V16.40 Diagnostics List (Note: For reference only)

Models	Displacement	Systems	Functions
S012			Zeroing of self-adaptation parameters
S013			Steering angle calibration
S013			Yaw sensor calibration
S013			Lateral accel. Sensor calibration
S013			Pressure sensor calibration
S013			Accept configuration
S013			Longit. Acc. Sensor calibration
S014			Startup with Code Card
S014			Lambda sensor check
S015			Accept configuration
S016			Startup with Code Card
S016			Injector classification
S017			Accumulator depressurisation
S017			Clutch bleed
S017			End of line / service self-calibration
S017			Clutch self-calibration enable
S017			Calculation of clutch degradation index
S017			Gearbox replacement
S017			Hydraulic Kit replacement
S017			Gearbox and hydraulic KIT replacement
S017			Clutch replacement
S017			Tunnel lever replacement
S017			Electropump replacement
S017			Pump relay replacement
S017			ECO switch replacement

LANCIA V16.40 Diagnostics List (Note:For reference only)

Models	Displacement	Systems	Functions
S017			Gearbox oil accumulator replacement
S017			Selection and/or engagement clutch electrovalve replacement
S017			Longitudinal acceleration signal learn
S018			Startup with Code Card
S018			Self-learnt functions reset
S018			Injector codes read
S018			Cyl.1 injector classification
S018			Cyl.2 injector classification
S018			Cyl.3 injector classification
S018			Cyl.4 injector classification
S018			Injector classification (4 cyl.blank)
S019			Startup with Code Card
S019			Injector codes read
S019			Neutral signal learn
S019			Replacement of injector cyl.1
S019			Replacement of injector cyl.2
S019			Replacement of injector cyl.3
S019			Replacement of injector cyl.4
S019			Injector replacement(per bank)
S019			Oil change
S019			Rail pressure sensor replacement
S019			Replacement Lambda sensor
S019			Air flow meter sensor replacement
S019			Phonic wheel replacement
S019			Differential pressure sensor replacement

LANCIA V16.40 Diagnostics List (Note: For reference only)

Models	Displacement	Systems	Functions
S019			Particulate filter with integrated pre-cat replacement
S019			Particulate filter regeneration
S019			Mechanical waste-gate valve replacement
S019			Replacement of variable geometry turbo and/or turbo posit. Sensor
S019			Resetting distance travelled with Water Temp. w. lamp ON
S019			Resetting distance travelled with Water in diesel w. lamp ON
S020			Headlamp pos. correct.
S020			Inputs status
S020			Servicing information delete
S020			Reset odometer
S020			Seat belts alarm exclusion
S020			Seat belts alarm Enable
S020			Instrument panel replacement
S021			Headlamp pos. correct
S021			Inputs status
S021			Reset odometer
S021			Seat belts alarm exclusion
S021			Seat belts alarm enable
S021			Instrument panel replacement
S022			Flap actuators learning test
S022			Pollution sensor test
S023			Tow hook presence disable
S023			Tow hook presence enable
S024			Accumulator depressurisation
S024			Clutch bleed

LANCIA V16.40 Diagnostics List (Note:For reference only)

Models	Displacement	Systems	Functions
S024			End of line / service self-calibration
S024			Clutch self-calibration enable
S024			New actuators
S024			Calculation of clutch degradation index
S024			Statistical data deletion
S024			Clutch replacement
S024			KIT/Gearbox replacement
S024			Gearbox replacement
S024			Tunnel lever replacement
S024			Electropump replacement
S024			Pump relay replacement
S024			ECO switch replacement
S024			Gearbox oil accumulator replacement
S024			Longitudinal acceleration signal learn
S025			Startup with Code Card
S025			Phonic wheel learn reset
S025			Zeroing of self-adaption parameters
S025			Throttle learn storage
S025			Vehicle configuration deletion
S025			Cruise Control Learn
S025			Air conditioner Learn
S025			Phase sensor learn zeroing
S026			Startup with Code Card
S026			Injector codes read
S026			Cyl.1 injector classification

LANCIA V16.40 Diagnostics List (Note: For reference only)

Models	Displacement	Systems	Functions
S026	Cyl.2 injector classification		
S026	Cyl.3 injector classification		
S026	Cyl.4 injector classification		
S026	Injector classification (4 cyl.blank)		
S027	Startup with Code Card		
S027	Injector codes read		
S027	Replacement of injector cyl. 1		
S027	Replacement of injector cyl. 2		
S027	Replacement of injector cyl. 3		
S027	Replacement of injector cyl. 4		
S027	Replacement injectors (4 cyl. Bank)		
S027	Control unit replacement		
S027	Replacement of control unit and injector/s		
S027	Air flow sensor replacement		
S027	Replacement Lambda sensor		
S027	Rail pressure sensor replacement		
S027	Rail pressure sensor and injector/s replacement		
S028	Voice synthesis test		
S028	Cooling fans test		
S028	Automatic emergency call activation		
S028	Manual emergency call activation		
S028	Assistance call activation		
S028	Optical fibre test		
S028	Backup battery replacement		
S028	Personal data deletion		

LANCIA V16.40 Diagnostics List (Note: For reference only)

Models	Displacement	Systems	Functions
S028			VIN Code Configuration
S028			Call buttons Configuration
S028			Manual System Configuration
S028			Automatic Configuration Read
S028			Activation/Deactivation 'Auxiliary video input' procedure
S029			Dist. To Next Service Zeroing (Coupon)
S029			Tyre Pressure check Wheel transmitters learning Looks for faulty wheel transmitter Looks for flat battery on wheel transmitter Maintenance Services config.
S029			New vehicle preparation Customer mode Reset distance till next servicing
S029			Control Unit Replacement Customer options Key programming Closure / Safety Engine / Gearbox Lights / Visibility
S029			Manual System Configuration Various Driver warnings Select the type of vehicle
S030			System Configuration Read
S031			Chassis number
S032			Stored status deletion
S033			Part. Filter regeneration
S034			FAP Replacement

LANCIA V16.40 Diagnostics List (Note:For reference only)

Models	Displacement	Systems	Functions
S034			Additive type configuration
S034			FAP Temperature Probe presence configuration
S035			Zeroing of self-adaption parameters
S036			Additional diesel circuit filling
S036			Replacement of the additive,or the pump,or the tubes.
S036			Particulate filter replacement (only for version with DPF)
S036			EGR valve learn
S036			Part. Filter regeneration
S036			Replacement injector/s
S037			Automatic gearbox replacement
S037			Automatic gearbox and Control unit replacement
S037			Automatic gearbox oil replacement
S038			Part. Filter regeneration
S039			Startup with Code Card
S039			Injector codes read
S039			Replacement of injector cyl. 1
S039			Replacement of injector cyl. 2
S039			Replacement of injector cyl. 3
S039			Replacement of injector cyl. 4
S039			Replacement injector cyl. 5
S039			Injector replacement (per bank)
S039			Oil change (only for version with DPF)
S039			Rail pressure sensor rerplacement
S039			Lambda sensor replacement (only for version with lambda sensor)
S039			Air flow meter replacement (only for version with lambda sensor)

LANCIA V16.40 Diagnostics List (Note: For reference only)

Models	Displacement	Systems	Functions
S039			Differential pressure sensor replacement (only for version with DPF)
S039			Pre-catalyser replacement (only for version with DPF)
S039			Particulate filter replacement (only for version with DPF)
S039			Particulate filter regeneration (only for version with DPF)
S040			Startup with Code Card
S040			Injector codes read
S040			Cyl. 1 injector classification
S040			Cyl. 2 injector classification
S040			Cyl. 3 injector classification
S040			Cyl. 4 injector classification
S040			Cyl.5 injector classification
S040			Injector classification (4 cyl. blank)
S040			Injector classification (5 cyl. blank)
S041			Siren serial line check
S041			Ultrasound sensor check
S041			Tilt sensor check (if present)
S041			Dusk and rain sensors check
S041			Window wash system check
S041			Country Standards Change
S042			Sensor vibration time too long
S043			Accumulator depressurisation
S043			Clutch bleed
S043			End of line / service self-calibration
S043			Clutch self-calibration enable
S043			New actuators

LANCIA V16.40 Diagnostics List (Note:For reference only)

Models	Displacement	Systems	Functions
S043			Calculation of clutch degradation index
S043			Satistical data deletion
S043			Data deletion and return to initial values for clutch replacement
S043			Data deletion for KIT/Gearbox replacement
S043			Data deletion for tunnel lever replacement
S043			Data deletion for pump replacement
S043			Data deletion for KIT/Pump replacement
S043			Data deletion for pump relay replacement
S043			Deletion of statistical data relating to errors
S044			Servo Mechanism Group Replacement
S044			Engine - Control Unit Group Replacement
S045			Steering angle calibration
S045			Longit.acc.sensor calibration
S046			Siren serial line check
S046			Ultrasound sensor check
S046			Tilt sensor check(if present)
S046			Dusk and rain sensors check
S046			Window wash system check
S047			Dusk and rain sensors check
S047			Window wash system check
S048			next service km's reset
S048			Light setting corr.
S048			trip counter reset
S049			Startup with Code Card
S049			Zeroing of self-adaption parameters

LANCIA V16.40 Diagnostics List (Note: For reference only)

Models	Displacement	Systems	Functions
S050			Electronic Key release
S050			EGR
S051			Startup with Code Card
S051			Replacement of injector cyl. 1
S051			Replacement of injector cyl. 2
S051			Replacement of injector cyl. 3
S051			Replacement of injector cyl. 4
S051			Oil change (only for version with DPF)
S051			Phonic wheel replacement
S051			Rail pressure sensor replacement
S051			Lambda sensor replacement (only for version with lambda sensor)
S051			Air flow meter replacement (only for version with lambda sensor)
S051			Differential pressure sensor replacement (only for version with DPF)
S051			Pre-catalyser replacement (only for version with DPF)
S051			Particulate filter replacement (only for version with DPF)
S052			Steering angle calibration
S052			Test limit speed disable
S052			Test limit speed restore
S052			Brake bleed
S053			Reset self-adapt. param. and idle act
S054			Oil Counter Write
S054			Self-adaptive parameters
S054			Sequence EV. 1
S054			Sequence EV. 2
S054			Sequence EV. 3

LANCIA V16.40 Diagnostics List (Note:For reference only)

Models	Displacement	Systems	Functions
S054			Sequence EV. 4
S054			Sequence EV. 5
S054			Sequence EV. 6
S054			Heat exchang. Flow EV.
S055			Accumulator depressurisation
S055			Clutch bleed
S055			End of line / service self-calibration
S055			Clutch self-calibration enable
S055			New actuators
S055			Calculation of clutch degradation index
S055			Engagement lever pin securing screw diagnosis
S055			Selection lever return diagnosis
S055			Satistical data deletion
S055			Deletion of statistical data relating to errors
S055			Data deletion and return to initial values for clutch replacement
S055			Data deletion for KIT/Gearbox replacement
S055			Data deletion for tunnel lever replacement
S055			Data deletion for pump replacement
S055			Data deletion for KIT/Pump replacement
S055			Data deletion for pump relay replacement
S055			Deletion of CITY switch replacement data
S055			Deletion of SPORT switch replacement data
S055			Data deletion for steering wheel levers replacement
S056			Tow hook presence disable
S056			Tow hook presence enable

LANCIA V16.40 Diagnostics List (Note: For reference only)

Models	Displacement	Systems	Functions
S056			Parking manoeuvre status
S057			Antenna replacement
S057			Control unit replacement
S057			Alarm deletion
S057			Wheel transmitters learning
S057			Control unit activation
S057			Control unit deactivation
S057			Alarm state check
S058			Headlamp pos.correct.
S058			Servicing information delete
S058			Reset odometer
S058			Seat belts alarm exclusion
S058			Seat belts alarm Enable
S058			Instrument panel replacement
S059			Tow hook presence disable
S059			Tow hook presence enable
S060			Reset odometer
S060			Servicing information delete
S060			Odometer write
S060			Intrument panel replacement
S061			Steering angle calibration
S061			Vehicle type learn reset
S062			Headlight actuators - high
S062			Headlight actuators - intermediate
S062			Headlight actuators - low

LANCIA V16.40 Diagnostics List (Note: For reference only)

Models	Displacement	Systems	Functions
S062			System calibration
S063			Headlight actuators - high
S063			Headlight actuators - intermediate
S063			Headlight actuators - low
S063			System calibration
S064			Startup with Code Card
S064			Self - learnt functions reset
S064			Zeroing of self - adaption parameters
S064			Neutral signal learn
S064			Performance limiting deactivation
S064			Oil change
S064			Motorised throttle replacement
S064			MultiAir Rolling finger replacement
S064			Timing sensor and/or cam replacement
S064			Rpm sensor and/or timing chain replacement
S064			Oil temperature sensor replacement
S064			Phonic wheel replacement
S064			UniAir module replacement
S064			Intelligent alternator (IAM) replacement
S064			Supercharging system components replacement
S064			Downstream lambda sensor and/or catalyzer and/or Injectors replacement
S065			Startup with Code Card
S065			Throttle learn storage
S065			Vehicle configuration deletion
S065			Phonic wheel learn reset

LANCIA V16.40 Diagnostics List (Note: For reference only)

Models	Displacement	Systems	Functions
S065			Zeroing of self-adaption parameters
S065			Cam edges zeroing(VVT)
S065			Neutral signal learn
S066			Self-learnt functions reset
S066			Pump relay replacement
S066			Tunnel lever replacement
S066			Steering wheel levers replacement
S066			AUTO switch replacement
S066			ECO/SPORT switch replacement
S066			Clutch self-calibration enable
S066			Accumulator depressurisation
S066			New actuators
S066			Clutch bleed
S066			End of line/service self-calibration
S066			Longitudinal acceleration signal learn
S067			Static test
S068			Static test
S068			Lateral and longitud.acceleration sensor calibration
S068			Steering angle calibration
S068			Longitudinal/lateral Accel.sens.Calibration reset
S069			Tow hook presence disable
S069			Tow hook presence enable
S070			Brake bleed
S070			Steering angle calibration
S070			Steering angle reset

LANCIA V16.40 Diagnostics List (Note:For reference only)

Models	Displacement	Systems	Functions
S070			Longit. acc. sensor calibration
S071			System Configuration Read
S071			control Unit Unlock
S072			Manual System Configuration
S072			Automatic Configuration Read
S072			Automatic Configuration Write
S072			United Kingdom(Thatcham std)
S072			Volumetric sensors automatic diagnosis
S073			Manual System Configuration
S073			Deletion stored buttons
S073			Automatic Configuration Read
S073			Automatic Configuration Write
S074			Startup with Code Card
S074			Throttle learn storage
S074			Vehicle configuration deletion
S074			Phonic wheel learn reset
S074			Zeroing of self-adaption parameters
S074			Cam edges zeroing(VVT)
S075			Startup with Code Card
S075			Injector codes read
S075			Speed limit setting
S075			Neutral signal learn
S075			Replacement of injector cyl. 1
S075			Replacement of injector cyl. 2
S075			Replacement of injector cyl. 3

LANCIA V16.40 Diagnostics List (Note:For reference only)

Models	Displacement	Systems	Functions
S075			Replacement of injector cyl. 4
S075			Injector replacement(per bank)
S075			Oil change
S075			Phonic wheel replacement
S075			Rail pressure sensor replacement
S075			Replacement lambda sensor
S075			Air flow meter sensor replacement
S075			Differential pressure sensor replacement
S075			Particulate filter with intergrated pre-cat replacement
S075			Particulate filter regeneration
S075			Intelligent alternator (IAM) replacement
S075			Mechanical waste-gate valve replacement
S075			Replacement of variable geometry turbo and/or turbo posit. Sensor
S075			Resetting distance travelled with Water Temp. w. lamp ON
S075			Resetting distance travelled with Water in diesel w. lamp ON
S075			EGR valve test
S075			Throttle test
S075			Glow plug preheating circuit test
S075			Self-learnt functions reset
S076			Windowscreen wiper relay speed 1
S076			Windowscreen wiper relay speed 2
S076			Driver's side wind. Lift. Motion
S076			Pass. Side wind. Lift. Motion
S076			Inertia switch rearm (FIS)
S076			Indicators command enable/disable

LANCIA V16.40 Diagnostics List (Note: For reference only)

Models	Displacement	Systems	Functions
S076			Country Standards Change
S076			Power Mode Gearbox
S077			Headlamp pos. correct
S077			Servicing information delete
S077			Reset odometer
S077			Seat belts alarm exclusion
S077			Seat belts alarm Enable
S077			Instrument panel replacement
S078			Position sensor calibration
S079			Flap actuators learning test
S080			Tow hook presence disable
S080			Tow hook presence enable
S080			Parking manoeuvre status
S081			Audio System Test
S081			Convergence System Restart
S082			Cooling fans test
S082			Automatic emergency call activation
S082			Manual emergency call activation
S082			Assistance call activation
S082			Backup battery replacement
S082			Personal data deletion
S082			JukeBox data deletion
S082			VIN Code Configuration
S082			Call buttons Configuration
S082			Manual System Configuration

LANCIA V16.40 Diagnostics List (Note:For reference only)

Models	Displacement	Systems	Functions
S082			Automatic Configuration Read
S082			Automatic Configuration Write
S083			Brake bleed
S083			Steering angle calibration
S083			Steering angle reset
S084			System configuration
S085			Voice synthesis test
S085			Cooling fans test
S085			Automatic emergency call activation
S085			Manual emergency call activation
S085			Assistance call activation
S085			Optical fibre test
S085			Backup battery replacement
S085			Personal data deletion
S085			VIN Code Configuration
S085			Call buttons configuration
S086			Looks for faunty wheel transmitter
S086			Wheel transmitters learning
S086			Wheel identification check
S086			Control unit deactivation
S086			Control unit activation
S087			FAP Replacement
S087			Control unit replacement
S087			Engine type configuration
S088			Dist. To Next Service Zeroing(Coupon)

LANCIA V16.40 Diagnostics List (Note: For reference only)

Models	Displacement	Systems	Functions
S089	Flap actuators learning test		
S089	Pollution sensor test		

CONNECTOR	X431/TOOL	DIAGUN
FIAT-3	Old LANCIA Model with 3PIN DLC before 1997	N/A
OBD 16C	LANCIA Model of non-CAN BUS protocol 1997-2005	N/A
SUPER 16	All LANCIA Models with 16PIN DLC	N/A
diagun connector	N/A	All LANCIA Models with 16PIN DLC