

Mitsubishi V32.00Diagnostics List(Note:For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
JAPAN	COLT	ENGINE	√	√	√	√	√		
JAPAN	COLT	AT	√	√	√	√	√		
JAPAN	COLT	ABS	√	√	√	√	√	1.Emission gas mode 2.Sensor calibration 3.Yaw rate sensor type reset	
JAPAN	COLT	AC	√	√	√	√	√		
JAPAN	COLT	SRS	√	√	√	√	√		
JAPAN	COLT	SWS	√	√	√	√	√		
JAPAN	COLT	METER	√	√	√	√	√		
JAPAN	COLT	ETACS	√	√	√	√	√		
JAPAN	COLT	4WS/Electric Power Steering	√	√	√	√	√		
JAPAN	COLT	Power Gate	√	√	√	√			
JAPAN	COLT PLUS	ENGINE	√	√	√	√	√		
JAPAN	COLT PLUS	AT	√	√	√	√	√		
JAPAN	COLT PLUS	ABS	√	√	√	√	√		
JAPAN	COLT PLUS	SRS	√	√	√	√	√		
JAPAN	COLT PLUS	SWS	√	√	√	√	√		
JAPAN	COLT PLUS	AC	√	√	√	√	√		
JAPAN	COLT PLUS	METER	√	√	√	√	√		
JAPAN	COLT PLUS	ETACS	√	√	√	√	√		
JAPAN	COLT PLUS	4WS/Electric Power Steering	√	√	√	√	√		
JAPAN	COLT PLUS	POWER GATE	√	√	√	√			

Mitsubishi V32.00Diagnostics List(Note:For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
JAPAN	DELICA D:5	ENGINE	√	√	√	√	√	1.Learned value reset 2.Learning 3.OBD test results (Mode \$06) 4.In-use performance tracking(ENH) 5.In-use performance tracking(OBD) 6.Ethanol forced learning mode 7.Timing chain maintenance	1.READINESS TEST 2.CODING
JAPAN	DELICA D:5	AT	√	√	√	√		1.CVT oil degradation level(*) 2.Electronic oil pump air bleeding 3.Permit condition for AS&G 4.Emission gas mode	1.Freeze Frame
JAPAN	DELICA D:5	ABS	√	√	√	√	√	1.Emission gas mode(*) 2.SAS calibration(*)	1.Freeze Frame
JAPAN	DELICA D:5	SRS	√	√	√	√	√		
JAPAN	DELICA D:5	AC	√	√	√	√	√		
JAPAN	DELICA D:5	METER	√	√	√	√	√	1.Head lamp Auto leveling Diag mode(*) 2.Service reminder(*) 3.Test	

Mitsubishi **V32.00** Diagnostics List (Note: For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
JAPAN	DELICA D:5	ETACS	√	√	√	√		1.Customization 2.Customization information 3.Customization Reset 4.Alarm record (optional)	1.CODING
JAPAN	DELICA D:5	SAS	√	√	√			1.SAS calibration(*)	
JAPAN	DELICA D:5	IMMO	√	√	√	√	√	1.Change password(*) 2.Key registration (bar code number)(*) 3.Key&KOS (Keyless Operation System) key registration(*) 4.Steering lock unit registration 5.Comm.Test 6.ENG key code registration 7.ENG key code&Chassis No.registration 8.Key Registration 9.Keyless ID registration	1.CODING
JAPAN	DELICA D:5	AUTO CRUISE	√	√	√	√			
JAPAN	DELICA D:5	AFS/ACL	√	√	√	√	√	1.HS initial position Clear 2.HS initial position Learning	
JAPAN	DELICA D:5	CAMERA	√	√	√	√			
JAPAN	DELICA D:5	POWER GATE	√	√	√	√	√		
JAPAN	DELICA D:5	AND	√	√	√				
JAPAN	DELICA D:5	LIN	√	√	√	√		Rain sensor adaptation	

Mitsubishi **V32.00** Diagnostics List (Note: For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
JAPAN	DELICA D:5	ELECTRIC SLIDE DOOR R	√	√	√	√	√		
JAPAN	DELICA D:5	ELECTRIC SLIDE DOOR L	√	√	√	√	√		
JAPAN	DELICA D:5	MULTI SELECT 4WD	√	√	√	√		Test	
JAPAN	DELICA D:5	AS&G	√	√	√	√			
JAPAN	DELICA D:5	CORNER SENSOR/BACK SENSOR	√	√	√	√			
JAPAN	DELICA SPACE GEAR	ENGINE	√	√	√	√	√		
JAPAN	DELICA SPACE GEAR	AT	√	√	√	√	√		
JAPAN	DELICA SPACE GEAR	ABS	√	√	√	√	√		
JAPAN	DELICA SPACE GEAR	SRS	√	√	√	√	√		
JAPAN	DELICA SPACE GEAR	AC	√	√	√	√	√		
JAPAN	DELICA SPACE GEAR	ETACS	√	√	√	√	√		
JAPAN	DELICA SPACE GEAR	ECS	√	√	√	√	√		

Mitsubishi **V32.00** Diagnostics List (Note: For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
JAPAN	DELICA VAN / CARGO /TRUCK	ENGINE	√	√	√	√	√		
JAPAN	DELICA VAN / CARGO /TRUCK	AT	√	√	√	√	√		
JAPAN	DELICA VAN / CARGO /TRUCK	ABS	√	√	√	√	√		
JAPAN	DELICA VAN / CARGO /TRUCK	METER	√	√	√	√	√		
JAPAN	EK-SPACE	ENGINE	√	√	√	√	√	1.Learning value reset 2.Starting counter 3.Starting counter initialization	1.CODING
JAPAN	EK-SPACE	AT	√	√	√	√		1.Emission gas mode 2.CVT oil degradation level 3.Sensor calibration 4.Electronic oil pump air bleeding 5.Reset	
JAPAN	EK-SPACE	ABS	√	√	√	√	√	1.Emission gas mode 2.Sensor calibration	
JAPAN	EK-SPACE	AC	√	√	√	√			
JAPAN	EK-SPACE	SRS	√	√	√	√	√		1.CODING

Mitsubishi **V32.00** Diagnostics List (Note: For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
JAPAN	EK-SPACE	METER	√	√	√	√	√	1.Service reminder 2.Turn-signal sound customization 3.Test	
JAPAN	EK-SPACE	ETACS	√	√	√	√	√		
JAPAN	EK-SPACE	IMMO	√	√	√	√	√	1.Keyless ID Registration 2.Keyless Reception Check 3.KOS key registration 4.Forced power supply output 5.Forced power supply output(stop) 6.Engine switch control	CODING
JAPAN	EK-SPACE	4WS/Electric Power Steering	√	√	√	√	√		
JAPAN	EK-SPACE	SAS	√	√	√	√		1.SAS Calibrition	
JAPAN	EK-SPACE	ELECTRIC SLIDE DOOR R	√	√	√	√			
JAPAN	EK-SPACE	ELECTRIC SLIDE DOOR L	√	√	√	√			
JAPAN	EK-SPACE	AFS/ACL	√	√	√	√			
JAPAN	EK-SPACE	Assist Battery	√	√	√				

Mitsubishi V32.00Diagnostics List(Note:For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
JAPAN	EK-SPACE	Multi Around Monitor	√	√	√	√	√	1.Write Learned value(Changed ECU) 2.Front & Top view forced display 3.Calibration maker range display 4.Calibration	
JAPAN	EK-SPACE	LIN		√	√	√		1.Rain Sensor Adaptation	
JAPAN	EK-WAGON(B11W)	ENGINE	√	√	√	√	√	1.Learning value reset 2.Starting counter 3.Starting counter initialization	1.CODING
JAPAN	EK-WAGON(B11W)	AT	√	√	√	√		1.Emission gas mode 2.CVT oil degradation level 3.Sensor calibration 4.Electronic oil pump air bleeding 5.Reset	
JAPAN	EK-WAGON(B11W)	ABS	√	√	√	√	√	1.Emission gas mode 2.Sensor calibration	
JAPAN	EK-WAGON(B11W)	AC	√	√	√	√	√		
JAPAN	EK-WAGON(B11W)	SRS	√	√	√	√	√		1.CODING

Mitsubishi V32.00Diagnostics List(Note:For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
JAPAN	EK-WAGON(B11W)	METER	√	√	√	√	√	1.Service reminder 2.Turn-signal sound customization 3.Test	
JAPAN	EK-WAGON(B11W)	ETACS	√	√	√	√			
JAPAN	EK-WAGON(B11W)	IMMO	√	√	√	√	√	1.Keyless ID Registration 2.Keyless Reception Check 3.KOS key registration 4.Forced power supply output 5.Forced power supply output(stop) 6.Engine switch control	CODING
JAPAN	EK-WAGON(B11W)	4WS/Electric Power Steering	√	√	√	√	√		
JAPAN	EK-WAGON(B11W)	SAS	√	√	√	√		1.SAS Calibrition	
JAPAN	EK-WAGON(B11W)	AFS/ACL	√	√	√	√			

Mitsubishi **V32.00** Diagnostics List (Note: For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
JAPAN	EK-WAGON(B11W)	Multi Around Mo	√	√	√	√	√	1. Write Learned value (Changed ECU) 2. Front & Top view forced display 3. Calibration maker range display 4. Calibration	
JAPAN	EK-WAGON(B11W)	CMU	√	√	√	√		1. Reset	
JAPAN	EK-WAGON(H81W)	ENGINE	√	√	√	√	√		
JAPAN	EK-WAGON(H81W)	AT	√	√	√	√	√		
JAPAN	EK-WAGON(H81W)	ABS	√	√	√	√	√		
JAPAN	EK-WAGON(H81W)	SRS	√	√	√	√	√		
JAPAN	EK-WAGON(H81W)	SWS	√	√	√	√	√		

Mitsubishi **V32.00** Diagnostics List (Note: For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
JAPAN	EK-WAGON(H82W)	ENGINE	√	√	√	√	√		
JAPAN	EK-WAGON(H82W)	AT	√	√	√	√	√		
JAPAN	EK-WAGON(H82W)	ABS	√	√	√	√	√		
JAPAN	EK-WAGON(H82W)	SRS	√	√	√	√	√		
JAPAN	EK-WAGON(H82W)	SWS	√	√	√	√	√		
JAPAN	GALANT FORTIS	ENGINE	√	√	√	√	√	1.Learned value reset 2.Learning 3.OBD test results (Mode \$06) 4.In-use performance tracking(ENH) 5.In-use performance tracking(OBD) 6.Ethanol forced learning mode 7.Timing chain maintenance	1.READINESS TEST 2.CODING

Mitsubishi **V32.00** Diagnostics List (Note: For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
JAPAN	GALANT FORTIS	AT	√	√	√	√		1.CVT oil degradation level(*) 2.Electronic oil pump air bleeding 3.Permit condition for AS&G 4.Teach-In 5.Emission gas mode	1.Freeze Frame
JAPAN	GALANT FORTIS	ABS	√	√	√	√	√	1.Emission gas mode(*) 2.SAS calibration(*)	
JAPAN	GALANT FORTIS	SRS	√	√	√	√	√		
JAPAN	GALANT FORTIS	AC	√	√	√	√	√		
JAPAN	GALANT FORTIS	METER	√	√	√	√	√	1.Head lamp Auto leveling Diag mode(*) 2.Service reminder(*) 3.Test	
JAPAN	GALANT FORTIS	ETACS	√	√	√	√		1.Customization 2.Customization information 3.Customization Reset 4.Alarm record (optional)(*)	
JAPAN	GALANT FORTIS	SAS	√	√	√			SAS calibration	

Mitsubishi **V32.00** Diagnostics List (Note: For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
JAPAN	GALANT FORTIS	IMMO	√	√	√	√	√	1.Change password(*) 2.Key registration (bar code number)(*) 3.Key&KOS (Keyless Operation System) key registration(*) 4.Steering lock unit registration 5.Comm.Test 6.ENG key code registration 7.ENG key code&Chassis No.registration 8.Key Registration 9.Keyless ID registration	1.CODING
JAPAN	GALANT FORTIS	AUTO CRUISE	√	√	√	√			
JAPAN	GALANT FORTIS	4WS/Electric Power Steering	√	√	√	√	√		
JAPAN	GALANT FORTIS	AFS/ACL	√	√	√	√	√	1.HS initial position Clear 2.HS initial position Learning	
JAPAN	GALANT FORTIS	AYC/ACD	√	√	√	√		1.Sensor calibration(*) 2.Air bleeding 3.Test	
JAPAN	GALANT FORTIS	AND	√	√	√				

Mitsubishi **V32.00** Diagnostics List (Note: For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
JAPAN	GALANT FORTIS	LIN	√	√	√	√		Rain sensor adaptation	
JAPAN	GALANT FORTIS	MULTI SELECT 4WD	√	√	√	√		Test	
JAPAN	GALANT FORTIS	AUDIO	√	√	√	√			
JAPAN	GALANT FORTIS	SHIFT LEVER	√	√	√	√	√		
JAPAN	GALANT FORTIS	AS&G	√	√	√	√			
JAPAN	GALANT FORTIS SPORTBACK	ENGINE	√	√	√	√	√	1.Learned value reset 2.Learning 3.OBD test results (Mode \$06) 4.In-use performance tracking(ENH) 5.In-use performance tracking(OBD) 6.Ethanol forced learning mode 7.Timing chain maintenance	1.READINESS TEST 2.CODING
JAPAN	GALANT FORTIS SPORTBACK	AT	√	√	√	√		1.CVT oil degradation level(*) 2.Electronic oil pump air bleeding 3.Permit condition for AS&G 4.Teach-In 5.Emission gas mode	1.CODING

Mitsubishi **V32.00** Diagnostics List (Note: For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
JAPAN	GALANT FORTIS SPORTBACK	ABS	√	√	√	√	√	1.Emission gas mode(*) 2.SAS calibration(*)	1.Freeze Frame
JAPAN	GALANT FORTIS SPORTBACK	SRS	√	√	√	√	√		
JAPAN	GALANT FORTIS SPORTBACK	AC	√	√	√	√	√		
JAPAN	GALANT FORTIS SPORTBACK	METER	√	√	√	√	√	1.Head lamp Auto leveling Diag mode(*) 2.Service reminder(*) 3.Test	
JAPAN	GALANT FORTIS SPORTBACK	ETACS	√	√	√	√		1.Customization 2.Customization information 3.Customization Reset 4.Alarm record (optional)(*)	
JAPAN	GALANT FORTIS SPORTBACK	STEERING ANGLE SENSOR	√	√	√			1.SAS calibration(*)	

Mitsubishi **V32.00** Diagnostics List (Note: For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
JAPAN	GALANT FORTIS SPORTBACK	IMMO	√	√	√	√	√	1.Change password 2.Key registration (bar code number) 3.Key&KOS (Keyless Operation System) key registration 4.Steering lock unit registration 5.Comm.Test 6.ENG key code registration 7.ENG key code&Chassis No.registration 8.Key Registration 9.Keyless ID registration	1.CODING
JAPAN	GALANT FORTIS SPORTBACK	AUTO CRUISE	√	√	√	√			
JAPAN	GALANT FORTIS SPORTBACK	4WS/ELECTRIC POWER STEERING	√	√	√	√	√		
JAPAN	GALANT FORTIS SPORTBACK	AFS/ACL	√	√	√	√	√	1.HS initial position Clear 2.HS initial position Learning	
JAPAN	GALANT FORTIS SPORTBACK	AYC/ACD	√	√	√	√		1.Sensor calibration(*) 2.Air bleeding 3.Test	

Mitsubishi V32.00Diagnostics List(Note:For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
JAPAN	GALANT FORTIS SPORTBACK	AND	√	√	√				
JAPAN	GALANT FORTIS SPORTBACK	LIN	√	√	√	√		Rain sensor adaptation	
JAPAN	GALANT FORTIS SPORTBACK	MULTI SELECT 4WD	√	√	√	√		Test	
JAPAN	GALANT FORTIS SPORTBACK	AUDIO	√	√	√	√			
JAPAN	GALANT FORTIS SPORTBACK	SHIFT LEVER	√	√	√	√	√		
JAPAN	GALANT FORTIS SPORTBACK	AS&G	√	√	√	√			
JAPAN	GALANT FORTIS SPORTBACK	SAS	√	√	√			1.SAS Calibration	
JAPAN	GALANT FORTIS SPORTBACK	CORNER SENSOR	√	√	√	√			

Mitsubishi V32.00Diagnostics List(Note:For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
JAPAN	GRANDIS	ENGINE	√	√	√	√	√		
JAPAN	GRANDIS	AT	√	√	√	√	√		
JAPAN	GRANDIS	ABS	√	√	√	√	√		
JAPAN	GRANDIS	SRS	√	√	√	√	√		
JAPAN	GRANDIS	SWS	√	√	√	√	√		
JAPAN	GRANDIS	AC	√	√	√	√	√		
JAPAN	GRANDIS	METER	√	√	√	√	√		
JAPAN	GRANDIS	ETACS	√	√	√	√	√		
JAPAN	GRANDIS	SAS	√	√	√			SAS calibration	
JAPAN	GRANDIS	IMMO	√	√	√	√	√	1.Key registration (key used) 2.Key registration (bar code number)(*) 3.ENG key code&Chassis No.registration 4.Change password(*)	1.CODING
JAPAN	GRANDIS	AUTO CRUISE	√	√	√	√	√		
JAPAN	GRANDIS	CAMERA	√	√	√	√	√		
JAPAN	GRANDIS	POWER GATE	√	√	√	√			
JAPAN	GRANDIS	DISPLAY	√	√	√				
JAPAN	GRANDIS	KEYLESS OPERATION	√	√	√				
JAPAN	GRANDIS	MULTI SELECT 4WD	√	√	√	√	√		
JAPAN	I(アイ)	ENGINE	√	√	√	√	√	1.Learned value reset(*)	1.READINESS TEST

Mitsubishi V32.00Diagnostics List(Note:For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
JAPAN	I(アイ)	AT	√	√	√	√	√	1.Learned value reset	
JAPAN	I(アイ)	ABS	√	√	√	√	√		
JAPAN	I(アイ)	SRS		√	√	√	√		
JAPAN	I(アイ)	AC		√	√	√	√		
JAPAN	I(アイ)	METER	√	√	√	√	√	1.Service reminder(*)	
JAPAN	I(アイ)	ETACS	√	√	√	√	√	1.Customization 2.Customization information 3.Customization Reset 4.Keyless ID registration(*) 5.Keyless reception check(*)	CODING
JAPAN	I(アイ)	4WS/Electric Power Steering	√	√	√	√	√		
JAPAN	I(アイ)	LIN	√	√	√	√			
JAPAN	I(アイ)	KEYLESS OPERATION	√	√	√	√	√	1.Keyless Operation System key registration 2.Steering lock unit registration 3.Comm.Test 4.KOS Customization	
JAPAN	I-MIEV	ABS	√	√	√	√	√	Emission gas mode	
JAPAN	I-MIEV	SRS		√	√	√	√		
JAPAN	I-MIEV	AC		√	√	√	√		
JAPAN	I-MIEV	METER	√	√	√	√	√	1.Service reminder 2.Test	

Mitsubishi V32.00Diagnostics List(Note:For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
JAPAN	I-MIEV	ETACS	√	√	√	√		1.Customization 2.Customization information 3.Customization Reset 4.Keyless ID registration(*) 5.Keyless reception check(*)	1.CODING
JAPAN	I-MIEV	4WS/Electric Power Steering	√	√	√	√	√		
JAPAN	I-MIEV	STEERING ANGLE SENSOR	√	√	√			1.SAS calibration	
JAPAN	I-MIEV	LIN	√	√	√	√			
JAPAN	I-MIEV	KEYLESS OPERATION	√	√	√	√	√	1.Keyless Operation System key registration 2.Steering lock unit registration 3.Comm.Test 4.KOS Customization	
JAPAN	I-MIEV	EV-ECU	√	√	√	√	√	1.Initialization	

Mitsubishi V32.00Diagnostics List(Note:For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
JAPAN	I-MIEV	BMU	√	√	√	√	√	1.Test 2.Reset 3.Write learned value(Changed ECU) 4.Cell voltage smoothing 5.CMU ID numbering 6.Battery capacity measure(Ready) 7.Battery capacity measure(Action) 8.Battery auto capacity measured	
JAPAN	I-MIEV	COMP&HTR	√	√	√	√	√	1.Compressor drive history reset	
JAPAN	I-MIEV	MCU	√	√	√	√	√	1.Initial Phase Position Of Motor	
JAPAN	I-MIEV	CMU	√			√		1.Reset	
JAPAN	I-MIEV	MiEV Remote System	√	√	√	√	√	Test	
JAPAN	LANCER	ENGINE	√	√	√	√	√		
JAPAN	LANCER	AT	√	√	√	√	√		
JAPAN	LANCER	ABS	√	√	√	√	√		
JAPAN	LANCER	IMMO	√	√	√	√	√		
JAPAN	LANCER	SRS	√	√	√	√	√		
JAPAN	LANCER	SWS	√	√	√	√	√		
JAPAN	LANCER	AC	√	√	√	√	√		
JAPAN	LANCER	AYC/ACD	√	√	√	√	√		

Mitsubishi **V32.00** Diagnostics List (Note: For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
JAPAN	LANCER CARGO	ENGINE	√	√	√	√	√		
JAPAN	LANCER CARGO	ABS	√	√	√	√	√		
JAPAN	LANCER CARGO	SRS	√	√	√	√	√		
JAPAN	LANCER CARGO	SWS	√	√	√	√	√		
JAPAN	LANCER CARGO	AT	√	√	√	√	√		
JAPAN	LANCER EVOLUTION	ENGINE	√	√	√	√	√	1.Learned value reset 2.Learning 3.OBD test results (Mode \$06) 4.In-use performance tracking(ENH) 5.In-use performance tracking(OBD) 6.Ethanol forced learning mode 7.Timing chain maintenance	1.READINESS TEST 2.CODING
JAPAN	LANCER EVOLUTION	AT	√	√	√	√		1.Provisional DTCs 2.Teach-in	
JAPAN	LANCER EVOLUTION	ABS	√	√	√	√	√	1.Emission gas mode(*) 2.Sensor calibration(*) 3.Valve pressure learning	

Mitsubishi **V32.00** Diagnostics List (Note: For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
JAPAN	LANCER EVOLUTION	SRS	√	√	√	√	√		
JAPAN	LANCER EVOLUTION	AC	√	√	√	√	√		
JAPAN	LANCER EVOLUTION	AUTO CRUISE	√	√	√	√			
JAPAN	LANCER EVOLUTION	METER	√	√	√	√	√	1.Head lamp Auto leveling Diag mode(*) 2.Service reminder(*) 3.Test	
JAPAN	LANCER EVOLUTION	ETACS	√	√	√	√		1.Customization 2.Customization information 3.Customization Reset 4.Alarm record (optional)(*)	
JAPAN	LANCER EVOLUTION	STEERING ANGLE SENSOR	√	√	√			1.SAS calibration(*)	

Mitsubishi **V32.00** Diagnostics List (Note: For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
JAPAN	LANCER EVOLUTION	IMMO	√	√	√	√	√	1.Change password(*) 2.Key registration (bar code number)(*) 3.Key&KOS (Keyless Operation System) key registration(*) 4.Steering lock unit registration 5.Comm.Test 6.ENG key code registration 7.ENG key code&Chassis No.registration 8.Key Registration 9.Keyless ID registration	1.CODING
JAPAN	LANCER EVOLUTION	AFS/ACL	√	√	√	√	√	1.HS initial position Clear 2.HS initial position Learning	
JAPAN	LANCER EVOLUTION	AYC/ACD	√	√	√	√		1.Sensor calibration 2.Air bleeding 3.Test	
JAPAN	LANCER EVOLUTION	AND	√	√	√				
JAPAN	LANCER EVOLUTION	LIN	√	√	√	√		1.Rain Sensor Adaptation	
JAPAN	LANCER EVOLUTION	AUDIO	√	√	√	√			

Mitsubishi **V32.00** Diagnostics List (Note: For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
JAPAN	LANCER EVOLUTION	HFM	√	√	√	√	√		
JAPAN	LANCER EVOLUTION	SHIFT LEVER	√	√	√	√	√		
JAPAN	LANCER WAGON	ENGINE	√	√	√	√	√		
JAPAN	LANCER WAGON	AT	√	√	√	√	√		
JAPAN	LANCER WAGON	ABS	√	√	√	√	√		
JAPAN	LANCER WAGON	SRS	√	√	√	√	√		
JAPAN	LANCER WAGON	SWS	√	√	√	√	√		
JAPAN	LANCER WAGON	AC	√	√	√	√	√		
JAPAN	LANCER WAGON	IMMO	√	√	√	√	√		
JAPAN	LANCER WAGON	AYC/ACD	√	√	√	√	√		
JAPAN	MINICA	ENGINE	√	√	√	√	√		
JAPAN	MINICA	ABS	√	√	√	√	√		
JAPAN	MINICA	SRS	√	√	√	√	√		
JAPAN	MINICA	SWS	√	√	√	√	√		

Mitsubishi **V32.00** Diagnostics List (Note: For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
JAPAN	MINICAB / TOWNBOX	ENGINE	√	√	√	√	√		
JAPAN	MINICAB / TOWNBOX	ABS	√	√	√	√	√		
JAPAN	MINICAB / TOWNBOX	SRS	√	√	√	√	√		
JAPAN	MINICAB / TOWNBOX	SWS	√	√	√	√	√		
JAPAN	MINICAB / TOWNBOX	AT	√	√	√	√	√		
JAPAN	MINICAB-MIEV	ABS	√	√	√	√	√		
JAPAN	MINICAB-MIEV	SRS	√	√	√	√	√		
JAPAN	MINICAB-MIEV	4WS/Electric Power Steering	√	√	√	√	√		
JAPAN	MINICAB-MIEV	ETACS	√	√	√	√		1.Customization 2.Customization information 3.Customization Reset 4.Keyless ID registration 5.Keyless reception check	CODING
JAPAN	MINICAB-MIEV	METER	√	√	√	√	√	1.Service reminder 2.Test	

Mitsubishi **V32.00** Diagnostics List (Note: For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
JAPAN	MINICAB-MIEV	BMU	√	√	√	√	√	1.Test 2.Reset 3.Write learned value(Changed ECU) 4.Cell voltage smoothing 5.CMU ID numbering 6.Battery capacity measure(Ready) 7.Battery capacity measure(Action) 8.Battery auto capacity measured	
JAPAN	MINICAB-MIEV	COMP&HTR	√	√	√	√	√	1.Temp.dial position adjust 2.Compressor drive history reset	
JAPAN	MINICAB-MIEV	EV-ECU	√	√	√	√	√	1.Initialization	
JAPAN	MINICAB-MIEV	MCU	√	√	√	√	√	Initial Phase Position Of Motor	
JAPAN	MINICAB-MIEV	CMU	√			√		Reset	
JAPAN	MIRAGE	ENGINE	√	√	√	√	√	1.Learned value reset 2.OBD test results (Mode \$06) 3.In-use performance tracking(ENH) 4.In-use performance tracking(OBD) 5.Timing chain maintenance	1.READINESS TEST 2.CODING

Mitsubishi **V32.00** Diagnostics List (Note: For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
JAPAN	MIRAGE	AT	√	√	√	√		1.Emission gas mode 2.CVT oil degradation level 3.Sensor calibration 4.Electronic oil pump air bleeding 5.Reset	
JAPAN	MIRAGE	ABS	√	√	√	√			
JAPAN	MIRAGE	AC	√	√	√	√			
JAPAN	MIRAGE	SRS	√	√	√	√			1.CODING
JAPAN	MIRAGE	METER	√	√	√	√			
JAPAN	MIRAGE	ETACS	√	√	√	√			
JAPAN	MIRAGE	IMMO	√	√	√	√	√	1.Change Password 2.Keyless ID registration 3.Keyless Reception Check 4. Key registration 5.Key registration (bar code number) 6.Engine Key Code registration 7.ENGINE KEY CODE registration&VIN WRITING 8.Comm. Test 9.KOS Key registration	
JAPAN	MIRAGE	4WS/Electric Power Steering	√	√	√	√			
JAPAN	MIRAGE	SAS	√	√	√	√		1.SAS calibration	

Mitsubishi **V32.00** Diagnostics List (Note: For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
JAPAN	OUTLANDER (CW#)	METER	√	√	√	√	√	1.Head lamp Auto leveling Diag mode 2.Service reminder 3.Test	
JAPAN	OUTLANDER (CW#)	ETACS	√	√	√	√		1.Customization 2.Customization information 3.Customization Reset 4.Alarm record (optional)	
JAPAN	OUTLANDER (CW#)	SAS	√	√	√			SAS calibration	
JAPAN	OUTLANDER (CW#)	IMMO	√	√	√	√	√	1.Change password 2.Key registration (bar code number) 3.Key&KOS (Keyless Operation System) key registration 4.Steering lock unit registration 5.Comm.Test 6.ENG key code registration 7.ENG key code&Chassis No.registration 8.Key Registration 9.Keyless ID registration	1.CODING
JAPAN	OUTLANDER (CW#)	AUTO CRUISE	√	√	√	√			

Mitsubishi **V32.00** Diagnostics List (Note: For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
JAPAN	OUTLANDER (CW#)	AND	√	√	√				
JAPAN	OUTLANDER (CW#)	LIN	√	√	√	√		Rain Sensor Adaptation	
JAPAN	OUTLANDER (CW#)	MULTI SELECT 4WD	√	√	√	√		Test	
JAPAN	OUTLANDER (CW#)	AUDIO	√	√	√	√			
JAPAN	OUTLANDER (CW#)	AFS/ACL	√	√	√	√	√	1.HS initial position Clear 2.HS initial position Learning	
JAPAN	OUTLANDER (CW#)	CORNER SENSOR/BACK SENSOR	√	√	√	√			
JAPAN	OUTLANDER (GF#)	ENGINE	√	√	√	√	√	1.Learned value reset 2.Learning 3.OBD test results (Mode \$06) 4.In-use performance tracking(ENH) 5.In-use performance tracking(OBD) 6.Ethanol forced learning mode 7.Timing chain maintenance	1.READINESS TEST 2.CODING

Mitsubishi **V32.00** Diagnostics List (Note: For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
JAPAN	OUTLANDER (GF#)	AT	√	√	√	√	√	1.CVT oil degradation level(*) 2.Electronic oil pump air bleeding 3.Permit condition for AS&G 4.Emission gas mode	
JAPAN	OUTLANDER (GF#)	ABS	√	√	√	√	√	1.Emission gas mode 2.All sensors calibration	
JAPAN	OUTLANDER (GF#)	SRS	√	√	√	√	√		
JAPAN	OUTLANDER (GF#)	AC	√	√	√	√	√		
JAPAN	OUTLANDER (GF#)	METER	√	√	√	√	√	1.Service reminder 2.Turn-signal sound customization 3.Test	
JAPAN	OUTLANDER (GF#)	ETACS	√	√	√	√		1.Customization 2.Customization information 3.Customization Reset 4.Alarm record (optional)	
JAPAN	OUTLANDER (GF#)	SAS	√	√	√			SAS calibration	
JAPAN	OUTLANDER (GF#)	IMMO	√	√	√	√	√	1.Comm.Test 2.KOS key registration	1.CODING
JAPAN	OUTLANDER (GF#)	AUTO CRUISE	√	√	√	√			

Mitsubishi **V32.00** Diagnostics List (Note: For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
JAPAN	OUTLANDER (GF#)	AND	√	√	√				
JAPAN	OUTLANDER (GF#)	LIN	√	√	√	√		Rain Sensor Adaptation	
JAPAN	OUTLANDER (GF#)	MULTI SELECT 4WD	√	√	√	√		Test	
JAPAN	OUTLANDER (GF#)	AUDIO	√	√	√	√			
JAPAN	OUTLANDER (GF#)	AFS/ACL	√	√	√	√	√	1.HS initial position Clear 2.HS initial position Learning	
JAPAN	OUTLANDER (GF#)	CORNER SENSOR/BACK SENSOR	√	√	√	√			
JAPAN	OUTLANDER (GF#)	ACC/FCM	√	√	√	√		1.Reset 2.Learning	
JAPAN	OUTLANDER (GF#)	Lane Keep	√	√	√	√	√	1.Reset 2.Learning	

Mitsubishi **V32.00** Diagnostics List (Note: For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
JAPAN	OUTLANDER-PHEV	ENGINE	√	√	√	√	√	1.Learned value reset 2.Learning 3.OBD test results (Mode \$06) 4.In-use performance tracking(ENH) 5.In-use performance tracking(OBD) 6.Ethanol forced learning mode 7.Timing chain maintenance	1.READINESS TEST 2.CODING
JAPAN	OUTLANDER-PHEV	ABS	√	√	√	√			
JAPAN	OUTLANDER-PHEV	AC	√	√	√	√			
JAPAN	OUTLANDER-PHEV	SRS	√	√	√	√			
JAPAN	OUTLANDER-PHEV	METER	√	√	√	√	√	1.Service reminder 2.Turn-signal sound customization 3.Test	
JAPAN	OUTLANDER-PHEV	ETACS	√	√	√	√			
JAPAN	OUTLANDER-PHEV	IMMO	√	√	√	√	√	1.Comm.Test 2.KOS key registration	1.CODING
JAPAN	OUTLANDER-PHEV	4WS/Electric Power Steering	√	√	√	√			

Mitsubishi **V32.00** Diagnostics List (Note: For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
JAPAN	OUTLANDER-PHEV	SAS	√	√	√	√			
JAPAN	OUTLANDER-PHEV	LIN	√	√	√	√			
JAPAN	OUTLANDER-PHEV	BMU	√	√	√	√			
JAPAN	OUTLANDER-PHEV	EV/MiEV Remote System	√	√	√	√			
JAPAN	OUTLANDER-PHEV	OSS	√	√	√	√			
JAPAN	OUTLANDER-PHEV	AND	√	√	√	√			
JAPAN	OUTLANDER-PHEV	ACC/FCM	√	√	√	√		1.Reset 2.Learning	
JAPAN	OUTLANDER-PHEV	AUDIO	√	√	√	√			
JAPAN	OUTLANDER-PHEV	CORNER SENSOR/BACK SENSOR	√	√	√	√			
JAPAN	OUTLANDER-PHEV	Compressor	√	√	√	√			
JAPAN	OUTLANDER-PHEV	F-MCU	√	√	√	√			

Mitsubishi V32.00Diagnostics List(Note:For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
JAPAN	OUTLANDER-PHEV	GCU	√	√	√	√	√		
JAPAN	OUTLANDER-PHEV	Lane Keep	√	√	√	√	√	1.Reset 2.Learning	
JAPAN	OUTLANDER-PHEV	OBC	√	√	√	√			
JAPAN	OUTLANDER-PHEV	P LOCK	√	√	√	√			
JAPAN	OUTLANDER-PHEV	Power Gate	√	√	√	√			
JAPAN	OUTLANDER-PHEV	PHEV	√	√	√	√	√	1.Test 2.Initialization	CODING
JAPAN	OUTLANDER-PHEV	R-MCU	√	√	√	√			CODING
JAPAN	OUTLANDER-PHEV	CMU	√			√			
JAPAN	PAJERO(V6#,V7#)	ENGINE	√	√	√	√	√		
JAPAN	PAJERO(V6#,V7#)	AT	√	√	√	√	√		
JAPAN	PAJERO(V6#,V7#)	ABS	√	√	√	√	√		
JAPAN	PAJERO(V6#,V7#)	SRS	√	√	√	√	√		

Mitsubishi V32.00Diagnostics List(Note:For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
JAPAN	PAJERO(V6#,V7#)	SWS	√	√	√	√	√		
JAPAN	PAJERO(V6#,V7#)	AC	√	√	√	√	√		
JAPAN	PAJERO(V6#,V7#)	IMMO	√	√	√	√	√		
JAPAN	PAJERO(V6#,V7#)	TCL/STABILITY CONTROL	√	√	√	√	√		
JAPAN	PAJERO(V6#,V7#)	SS4II	√	√	√	√	√		
JAPAN	PAJERO(V6#,V7#)	AUTO CRUISE	√	√	√	√			
JAPAN	PAJERO(V6#,V7#)	HBB	√	√	√	√	√		

Mitsubishi **V32.00** Diagnostics List (Note: For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
JAPAN	PAJERO(V8#,V9#)	ENGINE	√	√	√	√	√	1.Test 2.Learning 3.Initialization 4.Injector ID Writing(Exchanging Injector) 5.Injector ID Readout 6.DPF regeneration 7.Write learned value(Changed ECU) 8.Learning value reset 9.OBD test results (Mode \$06) 10.In-use performance tracking(ENH) 11.In-use performance tracking(OBD)	1.READINESS TEST 2.CODING
JAPAN	PAJERO(V8#,V9#)	ABS	√	√	√	√	√	1.Emission gas mode 2.Sensor calibration 3.Yaw rate sensor type reset	
JAPAN	PAJERO(V8#,V9#)	SRS	√	√	√	√	√		
JAPAN	PAJERO(V8#,V9#)	SWS	√	√	√	√	√		
JAPAN	PAJERO(V8#,V9#)	AC		√	√	√	√		

Mitsubishi **V32.00** Diagnostics List (Note: For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
JAPAN	PAJERO(V8#,V9#)	METER	√	√	√	√	√	Service reminder	
JAPAN	PAJERO(V8#,V9#)	ETACS	√	√	√	√	√		
JAPAN	PAJERO(V8#,V9#)	IMMO	√	√	√	√	√	1.Change password 2.Key registration (key used) 3.ENG key code&Chassis No.registration	
JAPAN	PAJERO(V8#,V9#)	SS4II	√	√	√	√	√		
JAPAN	PAJERO(V8#,V9#)	HBB	√	√	√	√	√		
JAPAN	PAJERO(V8#,V9#)	DISPLAY	√	√	√				
JAPAN	PAJERO(V8#,V9#)	AT	√	√	√	√	√	1.Learned value reset 2.Test	
JAPAN	PAJERO(V8#,V9#)	AUTO CRUISE	√	√	√	√			
JAPAN	PAJERO(V8#,V9#)	LIN	√	√	√	√		Rain Sensor Adaptation	
JAPAN	PAJERO(V8#,V9#)	CAN/LIN/SWS converter	√	√	√	√		1.Customization 2.Customization information 3.Reset	
JAPAN	PAJERO MINI	ENGINE	√	√	√	√	√		

Mitsubishi V32.00Diagnostics List(Note:For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
JAPAN	PAJERO MINI	AT	√	√	√	√	√		
JAPAN	PAJERO MINI	ABS	√	√	√	√	√		
JAPAN	PAJERO MINI	SRS	√	√	√	√	√		
JAPAN	PAJERO MINI	SWS	√	√	√	√	√		
JAPAN	PAJERO IO	ENGINE	√	√	√	√	√		
JAPAN	PAJERO IO	AT	√	√	√	√	√		
JAPAN	PAJERO IO	ABS	√	√	√	√	√	1.Emission gas mode 2.Sensor calibration 3.Yaw rate sensor type reset	
JAPAN	PAJERO IO	SRS	√	√	√	√	√		
JAPAN	PAJERO IO	SWS	√	√	√	√	√		
JAPAN	PAJERO IO	AC	√	√	√	√	√		
JAPAN	RVR	ENGINE	√	√	√	√	√	1.Learned value reset 2.Learning 3.OBD test results (Mode \$06) 4.In-use performance tracking(ENH) 5.In-use performance tracking(OBD) 6.Ethanol forced learning mode 7.Timing chain maintenance	1.READINESS TEST 2.CODING

Mitsubishi **V32.00** Diagnostics List (Note: For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
JAPAN	RVR	AT	√	√	√	√		1.CVT oil degradation level 2.Electronic oil pump air bleeding 3.Permit condition for AS&G 4.Emission gas mode	
JAPAN	RVR	ABS	√	√	√	√	√	1.Emission gas mode 2.All sensors calibration	
JAPAN	RVR	AC	√	√	√	√	√		
JAPAN	RVR	SRS	√	√	√	√	√		
JAPAN	RVR	AUTO CRUISE	√	√	√	√			
JAPAN	RVR	4WS/Electric Power Steering	√	√	√	√	√		
JAPAN	RVR	ETACS	√	√	√	√		1.Customization 2.Customization information 3.Customization Reset 4.Alarm record (optional)	
JAPAN	RVR	METER	√	√	√	√	√	1.Head lamp Auto leveling Diag mode 2.Service reminder 3.Test	
JAPAN	RVR	SAS	√	√	√			SAS calibration	
JAPAN	RVR	MULTI SELECT 4WD	√	√	√	√		Test	
JAPAN	RVR	AND	√	√	√				
JAPAN	RVR	LIN	√	√	√	√		Rain Sensor Adaptation	

Mitsubishi **V32.00** Diagnostics List (Note: For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
JAPAN	RVR	IMMO	√	√	√	√	√	1.Change password 2.Key registration (bar code number) 3.Key&KOS (Keyless Operation System) key registration 4.Steering lock unit registration 5.Comm.Test 6.ENG key code registration 7.ENG key code&Chassis No.registration 8.Key Registration 9.Keyless ID registration	1.CODING
JAPAN	RVR	AFS/ACL	√	√	√	√	√	1.HS initial position Clear 2.HS initial position Learning	
JAPAN	RVR	AS&G	√	√	√	√			
JAPAN	RVR	OSS	√	√	√	√	√	1.Forced power supply output 2.Forced power supply output(stop)	1.CODING
JAPAN	TOPPO	ENGINE	√	√	√	√	√		
JAPAN	TOPPO	AT	√	√	√	√	√		
JAPAN	TOPPO	ABS	√	√	√	√	√		
JAPAN	TOPPO	SRS		√	√	√	√		
JAPAN	TOPPO	SWS	√	√	√	√	√		
JAPAN	TRITON	ENGINE	√	√	√	√	√	1.Learned value reset	1.CODING

Mitsubishi **V32.00** Diagnostics List (Note: For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
JAPAN	TRITON	AT	√	√	√	√	√	1.Learned value reset 2.Test(INVECS-2 control stopped)	
JAPAN	TRITON	ABS	√	√	√	√	√		
JAPAN	TRITON	SRS	√	√	√	√	√		
JAPAN	TRITON	AC	√	√	√	√	√		
JAPAN	TRITON	AUTO CRUISE	√	√	√	√			
JAPAN	TRITON	ETACS	√	√	√	√		1.Customization 2.Customization information 3.Customization Reset 4.Keyless ID registration 5.Keyless reception check	1.CODING
JAPAN	TRITON	IMMO	√	√	√	√	√	1.Key registration (key used) 2.Key registration (bar code number) 3.ENG key code&Chassis No.registration 4.Change password	1.CODING
JAPAN	TRITON	LIN	√	√	√	√			
JAPAN	TRITON	DISPLAY	√	√	√				

Mitsubishi **V32.00** Diagnostics List (Note: For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
EUR	ASX	ENGINE	√	√	√	√	√	1.Test 2.Learning 3.Initialization 4.Injector ID Writing(Exchanging Injector) 5.Injector ID Readout 6.DPF regeneration 7.Ethanol forced learning mode 8.OBD test results (Mode \$06) 9.Learned value reset 10.In-use performance tracking(OBD) 11.In-use performance tracking(ENH) 12.Write learned value(changed ECU) 13.Timing chain maintenance	1.READINESS TEST 2.CODING
EUR	ASX	AT	√	√	√	√		1.Permit condition for AS&G 2.CVT oil degradation level 3.Electronic oil pump air bleeding 4.Emission gas mode 5.Control valve learning mode 6.Calibration value reset 7.Reset	

Mitsubishi V32.00Diagnostics List(Note:For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
EUR	ASX	ABS	√	√	√	√	√	1.Emission gas mode 2.Sensor calibration	1.CODING
EUR	ASX	AC	√	√	√	√	√		
EUR	ASX	SRS	√	√	√	√	√		1.CODING
EUR	ASX	AUTO CRUISE	√	√	√	√			
EUR	ASX	MULTI SELECT 4WD	√	√	√	√		Test	
EUR	ASX	AND	√	√	√	√	√		
EUR	ASX	AFS/ACL	√	√	√	√	√	1.HS initial postion Clear 2.HS initial postion learing	
EUR	ASX	LIN	√	√	√			1.Rain sensor adaptation	
EUR	ASX	AUDIO	√	√	√	√			
EUR	ASX	STEERING ANGLE SENSOR	√	√	√			1.SAS calibration	
EUR	ASX	METER	√	√	√	√	√	1.Head lamp Auto leveling Diag mode 2.Service reminder 3.Test	1.CODING

Mitsubishi V32.00Diagnostics List(Note:For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
EUR	ASX	ETACS	√	√	√	√		1.Customization 2.Customization information 3.Customization Reset 4.Anti-theft warning device	1.CODING
EUR	ASX	4WS/Electric Power Steering	√	√	√	√	√		1.CODING
EUR	ASX	IMMO	√	√	√	√			
EUR	ASX	CORNER SENSOR/BACK SENSOR	√	√	√	√			
EUR	ASX	OSS	√	√	√	√	√	1.Forced power supply output 2.Forced power supply output(stop)	1.CODING
EUR	ASX	AS&G	√	√	√	√			
EUR	ATTRAGE	ENGINE	√	√	√	√	√	1.Learned value reset 2.OBD test results (Mode \$06) 3.In-use performance tracking(ENH) 4.In-use performance tracking(OBD) 5.Timing chain maintenance	1.READINESS TEST 2.CODING

Mitsubishi **V32.00** Diagnostics List (Note: For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
EUR	ATTRAGE	AT	√	√	√	√		1.Emission gas mode 2.CVT oil degradation level 3.Sensor calibration 4.Electronic oil pump air bleeding 5.Reset	
EUR	ATTRAGE	ABS	√	√	√	√	√	1.Emission gas mode 2.Sensor calibration	
EUR	ATTRAGE	AC	√	√	√	√			
EUR	ATTRAGE	SRS	√	√	√	√			
EUR	ATTRAGE	METER	√	√	√	√	√	1.Service reminder 2.Turn-signal sound customization 3.test	
EUR	ATTRAGE	ETACS	√	√	√	√		1.Customized 2.Customized information 3.Custom reset	1.CODING
EUR	ATTRAGE	TPMS	√	√	√	√		1.Tire pressure sensor ID registration 2.Tire pressure sensor ID check 3.Tire pressure sensor ID registration(Set2)	

Mitsubishi V32.00Diagnostics List(Note:For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
EUR	ATTRAGE	IMMO	√	√	√	√	√	1.Change Password 2.Keyless ID registration 3.Keyless Reception Check 4.Key registration 5.Key registration (bar code number) 6.Engine Key Code registration 7.ENGINE KEY CODE registration&VIN WRITING 8.Comm. Test 9.KOS Key registration	1.CODING
EUR	ATTRAGE	4WS/Electric Power Steering	√	√	√	√			
EUR	ATTRAGE	SAS	√	√	√	√			
EUR	ATTRAGE	LIN	√	√	√	√		1.Rain Sensor Adaptation	
EUR	ATTRAGE	OSS	√	√	√	√		1. Forced power supply output 2. Forced power supply output(stop)	1.CODING
EUR	COLT CZC	ENGINE	√	√	√	√	√	1.Learning	1.READINESS TEST 2.CODING
EUR	COLT CZC	ABS	√	√	√	√	√	1.Emission gas mode 2.Sensor calibration 3.Yaw rate sensor type reset 4.SAS calibration	1.CODING

Mitsubishi **V32.00** Diagnostics List (Note: For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
EUR	COLT CZC	SRS	√	√	√	√	√	1.SRS ECU initialization	
EUR	COLT CZC	AC	√	√	√	√	√		
EUR	COLT CZC	METER	√	√	√	√	√	1.Service reminder	1.CODING
EUR	COLT CZC	ETACS	√	√	√	√		1.Customization 2.Customization information 3.Customization Reset 4.Anti-theft warning device	1.CODING
EUR	COLT CZC	IMMO	√	√	√	√		1.Key registration 2.Master Key Search 3.Change Password 4.Engine ECU<=>ETACS Matching	
EUR	COLT CZC	4WS/Electric Power Steering	√	√	√	√	√		1.CODING
EUR	COLT CZC	DISPLAY	√	√	√				
EUR	COLT CZC	RHT/TOPSTACK	√	√	√	√		1.Learning 2.Function test	1.CODING

Mitsubishi **V32.00** Diagnostics List (Note: For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
EUR	COLT, COLT CZ3 / CZT	ENGINE	√	√	√	√	√	1. Learned value reset 2. test 3. learning 4. injector ID initialization 5. Injector ID writing (Exchanging Injector) 7. Injector ID Readout	1. READINESS TEST 2. CODING
EUR	COLT, COLT CZ3 / CZT	ABS	√	√	√	√	√	1. Emission gas mode 2. Sensor calibration 3. Yaw rate sensor type reset	1. CODING
EUR	COLT, COLT CZ3 / CZT	SRS	√	√	√	√	√	1. SRS ECU initialization	
EUR	COLT, COLT CZ3 / CZT	AC	√	√	√	√	√		
EUR	COLT, COLT CZ3 / CZT	METER	√	√	√	√	√	1. Service reminder	1. CODING
EUR	COLT, COLT CZ3 / CZT	ETACS	√	√	√	√	√	1. Customization 2. Customization information	
EUR	COLT, COLT CZ3 / CZT	IMMO	√	√	√	√		1. Key registration 2. Master Key Search 3. Change Password 4. Engine ECU <=> ETACS Matching	
EUR	COLT, COLT CZ3 / CZT	4WS/Electric Power Steering	√	√	√	√	√		1. CODING

Mitsubishi **V32.00** Diagnostics List (Note: For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
EUR	COLT, COLT CZ3 / CZT	DISPLAY	√	√	√	√	√		
EUR	COLT, COLT CZ3 / CZT	AT	√	√	√			1.Clutch 2.Gear	
EUR	GALANT	ENGINE	√	√	√	√	√	1.OBD test results (Mode \$06) 2.Learned value reset 3.In-use performance tracking(OBD) 4.In-use performance tracking(ENH)	1.READINESS TEST 2.CODING
EUR	GALANT	AT	√	√	√	√	√	1.Learned value reset 2.Test	
EUR	GALANT	ABS	√	√	√	√	√	1.Sensor calibration	
EUR	GALANT	SRS	√	√	√	√	√	Seat Weight sensor Accuracy Check	
EUR	GALANT	SWS	√	√	√	√	√		
EUR	GALANT	AC	√	√	√	√	√		
EUR	GALANT	METER	√	√	√	√	√		
EUR	GALANT	ETACS	√	√	√	√			

Mitsubishi **V32.00** Diagnostics List (Note: For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
EUR	GRANDIS	AC	√	√	√	√	√		
EUR	GRANDIS	METER	√	√	√	√	√	1.Service reminder	
EUR	GRANDIS	ETACS	√	√	√	√			
EUR	GRANDIS	SAS	√	√	√			1.SAS calibration	
EUR	GRANDIS	AUTO CRUISE	√	√	√	√	√		1.CODING
EUR	GRANDIS	IMMO	√	√	√	√	√	1.Key registration (key used) 2.Key registration (bar code number) 3.ENG key code&Chassis No.registration 4.Change password	1.CODING
EUR	GRANDIS	DISPLAY	√	√	√	√	√		
EUR	GRANDIS	AT	√	√	√	√	√		
EUR	I	ENGINE	√	√	√	√	√	1.Learned value reset	1.READINESS TEST
EUR	I	AT	√	√	√	√	√	1.Learned value reset	

Mitsubishi **V32.00** Diagnostics List (Note: For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
EUR	I	ABS	√	√	√	√	√		
EUR	I	SRS	√	√	√	√	√		
EUR	I	AC	√	√	√	√	√		
EUR	I	METER	√	√	√	√	√	1.Service reminder	
EUR	I	ETACS	√	√	√	√	√	1.Customization 2.Customization information 3.Customization Reset 4.Keyless ID registration 5.Keyless reception check	1.CODING
EUR	I	4WS/Electric Power Steering	√	√	√	√	√		
EUR	I	LIN	√	√	√	√			
EUR	I	KEYLESS OPERATION	√	√	√	√	√	1.Keyless Operation System key registration 2.Steering lock unit registration 3.Comm.Test 4.KOS Customization	
EUR	I-MIEV	ABS	√	√	√	√	√	Emission gas mode	

Mitsubishi V32.00Diagnostics List(Note:For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
EUR	I-MIEV	SRS		√	√	√	√		
EUR	I-MIEV	AC		√	√	√	√		
EUR	I-MIEV	METER	√	√	√	√	√	1.Service reminder 2.Test	
EUR	I-MIEV	ETACS	√	√	√	√		1.Customization 2.Customization information 3.Customization Reset 4.Keyless ID registration(*) 5.Keyless reception check(*)	1.CODING
EUR	I-MIEV	4WS/Electric Power Steering	√	√	√	√	√		
EUR	I-MIEV	STEERING ANGLE SENSOR	√	√	√			1.SAS calibration	
EUR	I-MIEV	IMMO	√	√	√	√		1.Key registration (key used) 2.Key registration (bar code number) 3.ENG key code&Chassis No.registration 4.Change password 5.Key Code agreement	1.CODING
EUR	I-MIEV	LIN	√	√	√	√			

Mitsubishi V32.00Diagnostics List(Note:For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
EUR	I-MIEV	KEYLESS OPERATION	√	√	√	√	√	1.Keyless Operation System key registration 2.Steering lock unit registration 3.Comm.Test 4.KOS Customization	
EUR	I-MIEV	EV-ECU	√	√	√	√	√	1.Initialization	1.CODING
EUR	I-MIEV	BMU	√	√	√	√	√	1.Test 2.Reset 3.Write learned value(Changed ECU) 4.Cell voltage smoothing 5.CMU ID numbering 6.Battery capacity measure(Ready) 7.Battery capacity measure(Action) 8.Battery auto capacity measured	
EUR	I-MIEV	COMP&HTR	√	√	√	√	√	1.Compressor drive history reset	
EUR	I-MIEV	MCU	√	√	√	√	√	1.Initial Phase Position Of Motor	
EUR	I-MIEV	CMU	√			√		1.Reset	

Mitsubishi **V32.00** Diagnostics List (Note: For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
EUR	I-MIEV	MiEV Remote System	√	√	√	√	√	Test	
EUR	L200(K6#,K7#)	ENGINE	√	√	√	√	√	1.Test 2.Learning 3.Initialization 4.Injector ID Writing(Exchanging Injector) 5.Injector ID Readout 6.DPF regeneration	1.CODING
EUR	L200(K6#,K7#)	ABS	√	√	√	√	√	1.Emission gas mode 2.Sensor calibration 3.Yaw rate sensor type reset	
EUR	L200(K6#,K7#)	SRS	√	√	√	√	√		
EUR	L200(K6#,K7#)	ETACS	√	√	√		√		1.CODING
EUR	L200(K6#,K7#)	IMMO	√	√	√	√		1.Key registration (key used) 2.Key registration (bar code number) 3.ENG key code&Chassis No.registration 4.Change password	1.CODING
EUR	L200(K6#,K7#)	AC	√	√	√	√	√		

Mitsubishi V32.00Diagnostics List(Note:For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
EUR	L200(KA#,KB#)	ENGINE	√	√	√	√	√	1.Initialization(Supply pump exchange service)(*) 2.Test(Fuel system leak detection)(*) 3.Learning(Micro injection adaptation)(*) 4.Injector ID Writing(Exchanging Injector)(*) 5.Injector ID Readout(*)	1.CODING
EUR	L200(KA#,KB#)	ABS	√	√	√	√	√		
EUR	L200(KA#,KB#)	SRS	√	√	√	√	√		
EUR	L200(KA#,KB#)	ETACS	√	√	√	√		1.Customization 2.Customization information 3.Customization Reset 4.Keyless ID registration(*) 5.Keyless reception check(*)	1.CODING
EUR	L200(KA#,KB#)	IMMO	√	√	√	√		1.Key registration (key used) 2.Key registration (bar code number) 3.ENG key code&Chassis No.registration 4.Change password	1.CODING

Mitsubishi **V32.00** Diagnostics List (Note: For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
EUR	L200(KA#,KB#)	LIN	√	√	√	√			
EUR	L200(KA#,KB#)	AT	√	√	√	√	√	1.Learned value reset 2.Test(INVECS-2 control stopped)	
EUR	L200(KA#,KB#)	AC	√	√	√	√	√		
EUR	L200(KA#,KB#)	SAS	√	√	√	√	√	1.SAS calibration	
EUR	L200(KA#,KB#)	DISPLAY	√	√	√				
EUR	L300	SRS	√	√	√	√	√		
EUR	LANCER(CS#,C T#)	ENGINE	√	√	√	√	√	1.test 2.learning 3.initialization 4.Injector ID Writing(Exchanging Injector) 5.Injector ID Readout 6.DPF regeneration	
EUR	LANCER(CS#,C T#)	ABS	√	√	√	√	√		
EUR	LANCER(CS#,C T#)	SRS	√	√	√	√	√		

Mitsubishi **V32.00** Diagnostics List (Note: For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
EUR	LANCER(CS#,C T#)	SWS	√	√	√	√	√		
EUR	LANCER(CS#,C T#)	AC	√	√	√	√	√		
EUR	LANCER(CS#,C T#)	IMMO	√	√	√	√	√	1.Key registration (key used) 2.Key registration (bar code number) 3.ENG key code&Chassis No.registration 4.Change password	
EUR	LANCER(CS#,C T#)	AT	√	√	√	√	√		
EUR	LANCER(CS#,C T#)	AYC/ACD	√	√	√	√	√		1.READINESS TEST 2.CODING

Mitsubishi **V32.00** Diagnostics List (Note: For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
EUR	LANCER(CY#)	AC	√	√	√	√	√		
EUR	LANCER(CY#)	METER	√	√	√	√	√	1.Head lamp Auto leveling Diag mode(*) 2.Service reminder(*) 3.Text	
EUR	LANCER(CY#)	ETACS	√	√	√	√	√	1.Customization 2.Customization information 3.Customization Reset 4.Alarm record (optional)(*)	
EUR	LANCER(CY#)	SAS	√	√	√	√	√	1.SAS calibration(*)	
EUR	LANCER(CY#)	IMMO	√	√	√	√	√	1.Change password 2.Key registration 3.Key registration (bar code number) 4.Keyless ID registration 5.Engine key code registration 6.ENGINE KEY CODE registration&VIN WRITING	
EUR	LANCER(CY#)	4WS/Electric Power Steering	√	√	√	√	√		
EUR	LANCER(CY#)	MULTI SELECT 4WD	√	√	√	√		Test	

Mitsubishi **V32.00** Diagnostics List (Note: For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
EUR	LANCER(CY#)	AFS/ACL	√	√	√	√	√	1.HS initial position Clear 2.HS initial position learning	
EUR	LANCER(CY#)	AND	√	√	√	√	√		
EUR	LANCER(CY#)	HFM	√	√	√	√	√		
EUR	LANCER(CY#)	AUDIO	√	√	√	√	√		
EUR	LANCER(CY#)	LIN	√	√	√	√	√		
EUR	LANCER(CY#)	AT	√	√	√	√	√	1.Learned value reset 2.Teach-In 3.test 4.Emission gas mode 5.CVT oil degradation level 6.Electronic oil pump air bleeding 7.Permit condition for AS&G	CODING
EUR	LANCER(CY#)	AUTO CRUISE	√	√	√	√			
EUR	LANCER(CY#)	AS&G	√	√	√	√			

Mitsubishi V32.00Diagnostics List(Note:For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
EUR	LANCER(CY#)	TPMS	√	√	√	√		1.Tire pressure sensor ID register 2.Tire pressure sensor ID check	
EUR	LANCER EVOLUTION	ENGINE	√	√	√	√	√	1.learning 2.Ethanol forced learning mode 3.Learned value reset 4.OBD test results (Mode \$06) 5.In-use performance tracking(ENH) 6.In-use performance tracking(OBD) 7.Timing chain maintenance 8.initialization	1.READINESS TEST 2.CODING
EUR	LANCER EVOLUTION	ABS	√	√	√	√	√	1.Emission gas mode 2.sensor calibration 3.Valve pressure learning	1.Freeze Frame
EUR	LANCER EVOLUTION	SRS	√	√	√	√	√		
EUR	LANCER EVOLUTION	AC	√	√	√	√	√		
EUR	LANCER EVOLUTION	METER	√	√	√	√	√	1.Head lamp Auto leveling Diag mode(*) 2.Service reminder(*)	

Mitsubishi **V32.00** Diagnostics List (Note: For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
EUR	LANCER EVOLUTION	ETACS	√	√	√	√	√	1.Customization 2.Customization information 3.Customization Reset 4.Alarm record (optional)(*)	1.CODING
EUR	LANCER EVOLUTION	SAS	√	√	√	√	√	1.SAS calibration(*)	
EUR	LANCER EVOLUTION	AFS/ACL	√	√	√	√	√	1.HS initial position Clear 2.HS initial position learning	
EUR	LANCER EVOLUTION	Shift Lever	√	√	√	√	√		
EUR	LANCER EVOLUTION	HFM	√	√	√	√	√		
EUR	LANCER EVOLUTION	AT	√	√	√	√	√	1.Learned value reset 2.Teach-In 3.test	CODING
EUR	LANCER EVOLUTION	AUTO CRUISE	√	√	√	√			
EUR	LANCER EVOLUTION	AUDIO	√	√	√	√	√		
EUR	LANCER EVOLUTION	AND	√	√	√	√	√		
EUR	LANCER EVOLUTION	LIN	√	√	√	√		Rain sensor adaptation	

Mitsubishi **V32.00** Diagnostics List (Note: For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
EUR	LANCER EVOLUTION	AYC/ACD	√	√	√	√	√	1.test 2.sensor calibration 3.Emission gas mode	1.READINESS TEST 2.CODING
EUR	LANCER EVOLUTION	IMMO	√	√	√	√	√	1.Change password 2.Key registration 3.Key registration (bar code number) 4.Keyless ID registration 5.Engine key code registration 6.ENGINE KEY CODE registration&VIN WRITING	
EUR	LANCER EVOLUTION	CORNER SENSOR	√	√	√	√			

Mitsubishi **V32.00** Diagnostics List (Note: For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
EUR	LANCER SPORTBACK	AC	√	√	√	√	√		
EUR	LANCER SPORTBACK	METER	√	√	√	√	√	1.Head lamp Auto leveling Diag mode(*) 2.Service reminder(*)	
EUR	LANCER SPORTBACK	ETACS	√	√	√	√	√	1.Customization 2.Customization information 3.Customization Reset 4.Alarm record (optional)	
EUR	LANCER SPORTBACK	SAS	√	√	√	√	√	1.SAS calibration(*)	1.CODING
EUR	LANCER SPORTBACK	AFS/ACL	√	√	√	√	√	1.HS initial position Clear 2.HS initial position learning	
EUR	LANCER SPORTBACK	4WS/Electric Power Steering	√	√	√	√	√		
EUR	LANCER SPORTBACK	AUDIO	√	√	√	√			
EUR	LANCER SPORTBACK	AND	√	√	√	√			
EUR	LANCER SPORTBACK	LIN	√	√	√	√		Rain sensor adaptation	

Mitsubishi **V32.00** Diagnostics List (Note: For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
EUR	LANCER SPORTBACK	AT	√	√	√	√	√	1.Learned value reset 2.Teach-In 3.test 4.Emission gas mode 5.CVT oil degradation level 6.Electronic oil pump air bleeding 7.Permit condition for AS&G	1.CODING
EUR	LANCER SPORTBACK	AYC/ACD	√	√	√	√	√	1.test 2.sensor calibration 3.Emission gas mode	
EUR	LANCER SPORTBACK	AUTO CRUISE	√	√	√	√			
EUR	LANCER SPORTBACK	IMMO	√	√	√	√	√	1.Change password 2.Key registration 3.Key registration (bar code number) 4.Keyless ID registration 5.Engine key code registration 6.ENGINE KEY CODE registration&VIN WRITING	1.CODING
EUR	LANCER SPORTBACK	HFM	√	√	√	√	√		
EUR	LANCER SPORTBACK	AS&G	√	√	√	√			

Mitsubishi V32.00Diagnostics List(Note:For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
EUR	LANCER SPORTBACK	Assist Battery	√	√	√				
EUR	LANCER SPORTBACK	CORNER SENSOR	√	√	√	√			
EUR	LANCER SPORTBACK	OCM	√	√	√	√		Zero Calibration&System Test	
EUR	LANCER SPORTBACK	Shift Lever	√	√	√	√	√		
EUR	LANCER WAGON	ENGINE	√	√	√	√	√		
EUR	LANCER WAGON	ABS	√	√	√	√	√		
EUR	LANCER WAGON	SRS	√	√	√	√	√		
EUR	LANCER WAGON	SWS	√	√	√	√	√		
EUR	LANCER WAGON	AC	√	√	√	√	√		
EUR	LANCER WAGON	IMMO	√	√	√	√	√		
EUR	LANCER WAGON	AT	√	√	√	√	√		
EUR	OUTLANDER(CU#)	ENGINE	√	√	√	√	√		

Mitsubishi V32.00Diagnostics List(Note:For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
EUR	OUTLANDER(CU#)	ABS	√	√	√	√	√		
EUR	OUTLANDER(CU#)	SRS	√	√	√	√	√		
EUR	OUTLANDER(CU#)	SWS	√	√	√	√	√		
EUR	OUTLANDER(CU#)	AC	√	√	√	√	√		
EUR	OUTLANDER(CU#)	IMMO	√	√	√	√	√		
EUR	OUTLANDER(CU#)	AND	√	√	√	√	√		
EUR	OUTLANDER(CU#)	AT	√	√	√	√	√		
EUR	OUTLANDER(CU#)	AUTO CRUISE	√	√	√	√			

Mitsubishi **V32.00** Diagnostics List (Note: For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
EUR	OUTLANDER(C W#)	AC	√	√	√	√	√		
EUR	OUTLANDER(C W#)	METER	√	√	√	√	√	1.Head lamp Auto leveling Diag mode(*) 2.Service reminder(*)	
EUR	OUTLANDER(C W#)	ETACS	√	√	√	√	√	1.Customization 2.Customization information 3.Customization Reset 4.Alarm record (optional)(*)	
EUR	OUTLANDER(C W#)	IMMO	√	√	√	√	√	1.Change password 2.Key registration 3.Key registration (bar code number) 4.Keyless ID registration 5.Engine key code registration 6.ENGINE KEY CODE registration&VIN WRITING	
EUR	OUTLANDER(C W#)	AUTO CRUISE	√	√	√	√			
EUR	OUTLANDER(C W#)	AND	√	√	√	√	√		
EUR	OUTLANDER(C W#)	LIN	√	√	√	√			

Mitsubishi **V32.00** Diagnostics List (Note: For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
EUR	OUTLANDER(C W#)	MULTI SELECT 4WD	√	√	√	√		Test	
EUR	OUTLANDER(C W#)	AUDIO	√	√	√	√	√		
EUR	OUTLANDER(C W#)	SAS	√	√	√	√	√	1.SAS calibration	
EUR	OUTLANDER(C W#)	HFM	√	√	√	√	√		
EUR	OUTLANDER(C W#)	AS&G	√	√	√	√			

Mitsubishi V32.00Diagnostics List(Note:For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
EUR	OUTLANDER(G F#)	ABS	√	√	√	√	√	1.Emission gas mode 2.Sensor calibration	
EUR	OUTLANDER(G F#)	SAS	√	√	√			1.SAS calibration	
EUR	OUTLANDER(G F#)	4WS/Electric Power Steering	√	√	√	√	√		
EUR	OUTLANDER(G F#)	SRS	√	√	√	√			CODING
EUR	OUTLANDER(G F#)	METER	√	√	√	√	√	1.Service reminder 2.Turn-signal sound customization 3.Test	
EUR	OUTLANDER(G F#)	AND	√	√	√	√			
EUR	OUTLANDER(G F#)	AUDIO	√	√	√	√			
EUR	OUTLANDER(G F#)	CORNER SENSOR/BACK SENSOR	√	√	√	√			
EUR	OUTLANDER(G F#)	LIN	√	√	√			1.Rain Sensor Adaptation	
EUR	OUTLANDER(G F#)	AWC	√	√	√	√		1.Reset 2.Test	
EUR	OUTLANDER(G F#)	SWS	√	√	√	√	√		

Mitsubishi **V32.00** Diagnostics List (Note: For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
EUR	OUTLANDER-PHEV	ENGINE	√	√	√	√	√	1.Learned value reset 2.Learning 3.OBD test results (Mode \$06) 4.In-use performance tracking(ENH) 5.In-use performance tracking(OBD) 6.Ethanol forced learning mode 7.Timing chain maintenance	1.READINESS TEST 2.CODING
EUR	OUTLANDER-PHEV	ABS	√	√	√	√			
EUR	OUTLANDER-PHEV	AC	√	√	√	√			
EUR	OUTLANDER-PHEV	SRS	√	√	√	√			
EUR	OUTLANDER-PHEV	METER	√	√	√	√	√	1.Service reminder 2.Turn-signal sound customization 3.Test	
EUR	OUTLANDER-PHEV	ETACS	√	√	√	√		1.Customization 2.Customization information 3.Customization Reset 4.Security alarm 5.HS initial position Clear 6.HS initial position learning	CODING

Mitsubishi V32.00Diagnostics List(Note:For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
EUR	OUTLANDER-PHEV	IMMO	√	√	√	√			
EUR	OUTLANDER-PHEV	4WS/Electric Power Steering	√	√	√	√			
EUR	OUTLANDER-PHEV	SAS	√	√	√	√		1.SAS Calibration	
EUR	OUTLANDER-PHEV	LIN	√	√	√	√		1.Rain Sensor Adaptation	
EUR	OUTLANDER-PHEV	BMU	√	√	√	√		1.CMU support forced release 2.Write learned value(Changed ECU) 3.Reset 4.Test 5.CMU ID numbering 6.Cell Voltage smoothing 7.Battery auto capacity measured	
EUR	OUTLANDER-PHEV	EV/MiEV Remote System	√	√	√	√			
EUR	OUTLANDER-PHEV	OSS	√	√	√	√		1. Forced power supply output 2. Forced power supply output(stop)	CODING
EUR	OUTLANDER-PHEV	AND	√	√	√	√			

Mitsubishi V32.00Diagnostics List(Note:For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
EUR	OUTLANDER-PHEV	ACC/FCM	√	√	√	√		1.Reset 2.Learning	
EUR	OUTLANDER-PHEV	AUDIO	√	√	√	√			
EUR	OUTLANDER-PHEV	CORNER SENSOR/BACK SENSOR	√	√	√	√			
EUR	OUTLANDER-PHEV	Compressor	√	√	√	√			
EUR	OUTLANDER-PHEV	F-MCU	√	√	√	√			
EUR	OUTLANDER-PHEV	GCU	√	√	√	√	√		
EUR	OUTLANDER-PHEV	Lane Keep	√	√	√	√	√	1.Reset 2.Learning	
EUR	OUTLANDER-PHEV	OBC	√	√	√	√			
EUR	OUTLANDER-PHEV	P LOCK	√	√	√	√			
EUR	OUTLANDER-PHEV	Power Gate	√	√	√	√			
EUR	OUTLANDER-PHEV	PHEV	√	√	√	√	√	1.Test 2.Initialization	CODING

Mitsubishi **V32.00** Diagnostics List (Note: For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
EUR	PAJERO / MONTERO(V6# ,V7#)	HBB	√	√	√		√		
EUR	PAJERO / MONTERO(V6# ,V7#)	AC	√	√	√	√	√		
EUR	PAJERO / MONTERO(V6# ,V7#)	AT	√	√	√	√	√		
EUR	PAJERO / MONTERO(V6# ,V7#)	AUTO CRUISE	√	√	√	√			
EUR	PAJERO / MONTERO(V6# ,V7#)	TCL/STABILITY CONTROL	√	√	√	√	√		1.READINESS TEST 2.CODING

Mitsubishi **V32.00** Diagnostics List (Note: For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
EUR	PAJERO / MONTERO(V8#,V9#)	ENGINE	√	√	√	√	√	1.Learned value reset 2.DPF regeneration 3.Test 4.OBD test results (Mode \$06) 5.Initialize 6.Injector ID Writing(Exchanging Injector) 7.reading Injector ID 8.In-use performance tracking(OBD) 9.In-use performance tracking(ENH) 10.Learning	1.READINESS TEST 2.CODING
EUR	PAJERO / MONTERO(V8#,V9#)	AT	√	√	√	√	√	1.Learned value reset 2.Test	
EUR	PAJERO / MONTERO(V8#,V9#)	ABS	√	√	√	√	√		
EUR	PAJERO / MONTERO(V8#,V9#)	LIN	√	√	√			Rain sensor adaptation	

Mitsubishi **V32.00** Diagnostics List (Note: For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
EUR	PAJERO / MONTERO(V8#,V9#)	SRS	√	√	√	√	√		
EUR	PAJERO / MONTERO(V8#,V9#)	SWS	√	√	√	√	√		
EUR	PAJERO / MONTERO(V8#,V9#)	AC	√	√	√	√	√		
EUR	PAJERO / MONTERO(V8#,V9#)	METER	√	√	√	√	√	1.Serve Reminder(*)	1.CODING
EUR	PAJERO / MONTERO(V8#,V9#)	ETACS	√	√	√	√			1.CODING
EUR	PAJERO / MONTERO(V8#,V9#)	IMMO	√	√	√	√		1.Change password(*) 2.Register Key 3.ENGINE KEY CODE registration&VIN WRITING	1.CODING
EUR	PAJERO / MONTERO(V8#,V9#)	AUTO CRUISE	√	√	√	√			

Mitsubishi **V32.00** Diagnostics List (Note: For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
EUR	PAJERO / MONTERO(V8#,V9#)	SS4II	√	√	√	√	√		
EUR	PAJERO / MONTERO(V8#,V9#)	DISPLAY	√	√	√	√	√		
EUR	PAJERO / MONTERO(V8#,V9#)	CAN/LIN/SWS co	√	√	√	√		1.Customization 2.Customization Information 3.Reset	
EUR	PAJERO SPORT / MONTERO SPORT (K9#)	ENGINE	√	√	√	√	√		
EUR	PAJERO SPORT / MONTERO SPORT (K9#)	ABS	√	√	√	√	√		
EUR	PAJERO SPORT / MONTERO SPORT (K9#)	SRS	√	√	√	√			
EUR	PAJERO SPORT / MONTERO SPORT (K9#)	AC	√	√	√	√	√		
EUR	PAJERO SPORT / MONTERO SPORT (K9#)	ETACS	√	√	√	√			

Mitsubishi V32.00Diagnostics List(Note:For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
EUR	PAJERO SPORT / MONTERO SPORT (K9#)	IMMO	√	√	√	√			
EUR	PAJERO SPORT / MONTERO SPORT (K9#)	AUTO CRUISE	√	√	√	√			
EUR	PAJERO SPORT / MONTERO SPORT (K9#)	AT	√	√	√	√	√		
EUR	PAJERO SPORT / MONTERO SPORT(KH#)	ENGINE	√	√	√	√		1.Learned value reset 2.Learning 3.Test 4.Initialize(*) 5.Injector ID Writing(Exchanging Injector) 6.Reading Injector ID	1.READINESS TEST 2.CODING
EUR	PAJERO SPORT / MONTERO SPORT(KH#)	AT	√	√	√	√	√	1.Learned value reset 2.Test	
EUR	PAJERO SPORT / MONTERO SPORT(KH#)	ABS	√	√	√	√	√	1.Lateral G Sensor Calibratio	

Mitsubishi V32.00Diagnostics List(Note:For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
EUR	PAJERO SPORT / MONTERO SPORT(KH#)	SRS	√	√	√	√	√		
EUR	PAJERO SPORT / MONTERO SPORT(KH#)	AC	√	√	√	√	√		
EUR	PAJERO SPORT / MONTERO SPORT(KH#)	ETACS	√	√	√	√		1.Customization 2.Customization information 3.Customization Reset 4.Keyless ID registration(*) 5.Keyless reception check(*)	1.CODING
EUR	PAJERO SPORT / MONTERO SPORT(KH#)	SAS	√	√	√	√		1.SAS Calibration(*)	
EUR	PAJERO SPORT / MONTERO SPORT(KH#)	LIN	√	√	√				

Mitsubishi **V32.00** Diagnostics List (Note: For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
EUR	PAJERO SPORT / MONTERO SPORT(KH#)	IMMO	√	√	√	√		1.Change password 2.Key registration 3.Key registration (bar code number) 4.Keyless ID registration 5.Engine key code registration 6.ENGINE KEY CODE registration&VIN WRITING	1.CODING
EUR	PAJERO SPORT / MONTERO SPORT(KH#)	AUTO CRUISE	√	√	√	√			
EUR	PAJERO SPORT / MONTERO SPORT(KH#)	DISPLAY	√	√	√	√	√		1.READINESS TEST 2.CODING
EUR	SPACE STAR	ENGINE	√	√	√	√	√	1.Learned value reset 2.OBD test results (Mode \$06) 3.In-use performance tracking(ENH) 4.In-use performance tracking(OBD) 5.Timing chain maintenance	1.READINESS TEST 2.CODING

Mitsubishi V32.00Diagnostics List(Note:For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
EUR	SPACE STAR	AT	√	√	√	√		1.Emission gas mode 2.CVT oil degradation level 3.Sensor calibration 4.Electronic oil pump air bleeding 5.Reset	
EUR	SPACE STAR	ABS	√	√	√	√	√	1.Emission gas mode 2.Sensor calibration	
EUR	SPACE STAR	AC	√	√	√	√			
EUR	SPACE STAR	SRS	√	√	√	√			
EUR	SPACE STAR	METER	√	√	√	√			
EUR	SPACE STAR	ETACS	√	√	√	√			
EUR	SPACE STAR	IMMO	√	√	√	√			
EUR	SPACE STAR	4WS/Electric Power Steering	√	√	√	√			
EUR	SPACE STAR	SAS	√	√	√	√			
EUR	SPACE STAR	LIN	√	√	√	√			
EUR	SPACE STAR	OSS	√	√	√	√			
EUR	SPACE STAR	TPMS	√	√	√	√		1.Tire PRS. Sensor ID Reg 2.Tire PRS. Sensor ID check 3.Tire PRS. Sensor ID Reg.(Set2)	

Mitsubishi V32.00Diagnostics List(Note:For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
USA	ECLIPSE	ENGINE	√	√	√	√	√	1.Learned value reset(*) 2.OBD test results (Mode \$06) 3.In-use performance tracking(ENH) 4.In-use performance tracking(OBD)	1. CODING
USA	ECLIPSE	ABS	√	√	√	√	√	1.Sensor calibration 2.SAS calibration 3.Lateral G sensor calibration 4.M/C pressure calibration	
USA	ECLIPSE	SRS	√	√	√	√	√	Seat Weight sensor Accuracy Check	
USA	ECLIPSE	SWS	√	√	√	√	√		
USA	ECLIPSE	AC	√	√	√	√	√		
USA	ECLIPSE	METER	√	√	√	√	√		
USA	ECLIPSE	ETACS	√	√	√				
USA	ECLIPSE	IMMO	√	√	√	√		1.Key registration (Use the key) 2.Key registration(The number of the bar code) 3.ENGINE KEY CODE registration&VIN WRITING	1.CODING
USA	ECLIPSE	AUTO CRUISE	√	√	√	√			
USA	ECLIPSE	AT	√	√	√	√	√	1.Test 2.Learned Value Reset	

Mitsubishi **V32.00** Diagnostics List (Note: For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
USA	ECLIPSE	TCL/STABILITY CONTROL	√	√	√	√	√	1.Key registration	
USA	ECLIPSE	TPMS	√	√	√	√	√	1.Tire pressure sensor ID registration(*) 2.Tire pressure sensor ID check(*) 3.Tire pressure sensor ID check(REQUIRES TOOL)(*)	
USA	ECLIPSE	SAS	√	√	√	√		1.SAS calibration	
USA	ECLIPSE SPYDER	ENGINE	√	√	√	√	√	1.Learned value reset(*) 2.OBD test results (Mode \$06) 3.In-use performance tracking(ENH) 4.In-use performance tracking(OBD)	1. READINESS TEST 2. CODING
USA	ECLIPSE SPYDER	ABS	√	√	√	√	√	1.Sensor calibration 2.SAS calibration 3.Lateral G sensor calibration 4.M/C pressure calibration	
USA	ECLIPSE SPYDER	SRS	√	√	√	√	√	Seat Weight sensor Accuracy Check	
USA	ECLIPSE SPYDER	SWS	√	√	√	√	√		
USA	ECLIPSE SPYDER	AC	√	√	√	√	√		

Mitsubishi **V32.00** Diagnostics List (Note: For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
USA	ECLIPSE SPYDER	METER	√	√	√	√	√		
USA	ECLIPSE SPYDER	ETACS	√	√	√				
USA	ECLIPSE SPYDER	IMMO	√	√	√	√	√	1.Key registration (Use the key) 2.Key registration(The number of the bar code) 3.ENGINE KEY CODE registration&VIN WRITING	1.CODING
USA	ECLIPSE SPYDER	AUTO CRUISE	√	√	√	√			
USA	ECLIPSE SPYDER	RHT/TOPSTACK	√	√	√	√	√		
USA	ECLIPSE SPYDER	AT	√	√	√	√	√	1.Test 2.Learned Value Reset	
USA	ECLIPSE SPYDER	TCL/STABILITY CONTROL	√	√	√	√	√		
USA	ECLIPSE SPYDER	TPMS	√	√	√	√	√	1.Tire pressure sensor ID registration(*) 2.Tire pressure sensor ID check(*) 3.Tire pressure sensor ID check(REQUIRES TOOL)(*)	
USA	ECLIPSE SPYDER	SAS	√	√	√	√		1.SAS calibration	

Mitsubishi V32.00Diagnostics List(Note:For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
USA	ENDEAVOR	ENGINE	√	√	√	√	√	1.Learned value reset(*) 2.OBD test results (Mode \$06) 3.In-use performance tracking(ENH) 4.In-use performance tracking(OBD)	1. READINESS TEST 2. CODING
USA	ENDEAVOR	AT	√	√	√	√	√	1.Test 2.Learned Value Reset	
USA	ENDEAVOR	ABS	√	√	√	√	√		
USA	ENDEAVOR	SRS	√	√	√	√	√	Seat Weight sensor Accuracy Check	
USA	ENDEAVOR	SWS	√	√	√	√	√		
USA	ENDEAVOR	AC	√	√	√	√	√		
USA	ENDEAVOR	METER	√	√	√	√	√		
USA	ENDEAVOR	ETACS	√	√	√				
USA	ENDEAVOR	IMMO	√	√	√	√	√	1.Key registration (Use the key) 2.Key registration(The number of the bar code) 3.ENGINE KEY CODE registration&VIN WRITING	1.CODING
USA	ENDEAVOR	AUTO CRUISE	√	√	√	√			

Mitsubishi V32.00Diagnostics List(Note:For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
USA	ENDEAVOR	TPMS	√	√	√	√	√	1.Tire pressure sensor ID registration(*) 2.Tire pressure sensor ID check(*) 3.Tire pressure sensor ID check(REQUIRES TOOL)(*)	
USA	ENDEAVOR	TCL/STABILITY CONTROL	√	√	√	√	√		
USA	ENDEAVOR	DISPLAY	√	√	√	√			
USA	ENDEAVOR	SAS	√	√	√	√		1.SAS calibration	
USA	ENDEAVOR	CORNER SENSOR	√	√	√	√			
USA	GALANT	ENGINE	√	√	√	√	√	1.Learned value reset(*) 2.OBD test results (Mode \$06) 3.In-use performance tracking(ENH) 4.In-use performance tracking(OBD)	1. READINESS TEST 2. CODING
USA	GALANT	AT	√	√	√	√	√	1.Test 2.Learned Value Reset	
USA	GALANT	ABS	√	√	√	√	√	1.Sensor calibration 2.SAS calibration 3.Lateral G sensor calibration 4.M/C pressure calibration	
USA	GALANT	SRS	√	√	√	√	√	Seat Weight sensor Accuacy Check	

Mitsubishi **V32.00** Diagnostics List (Note: For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
USA	GALANT	SWS	√	√	√	√	√		
USA	GALANT	AC	√	√	√	√	√		
USA	GALANT	METER	√	√	√	√	√		
USA	GALANT	ETACS	√	√	√	√			
USA	GALANT	IMMO	√	√	√	√	√	1.Key registration (Use the key) 2.Key registration(The number of the bar code) 3.ENGINE KEY CODE registration&VIN WRITING	
USA	GALANT	AUTO CRUISE	√	√	√	√			
USA	GALANT	SAS	√	√	√	√		1.SAS calibration	
USA	GALANT	TPMS	√	√	√	√	√	1.Tire pressure sensor ID registration(*) 2.Tire pressure sensor ID check(*) 3.Tire pressure sensor ID check(REQUIRES TOOL)(*)	
USA	GALANT	DISPLAY	√	√	√	√	√		
USA	GALANT	TCL/STABILITY CONTROL	√	√	√	√	√		
USA	LANCER(CS#,C T#)	ENGINE	√	√	√	√	√		
USA	LANCER(CS#,C T#)	ABS	√	√	√	√	√		

Mitsubishi **V32.00** Diagnostics List (Note: For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
USA	LANCER(CS#,C T#)	SRS	√	√	√	√	√		
USA	LANCER(CS#,C T#)	SWS	√	√	√	√	√		
USA	LANCER(CS#,C T#)	AUTO CRUISE	√	√	√	√			
USA	LANCER(CS#,C T#)	AT	√	√	√	√	√		
USA	LANCER(CS#,C T#)	IMMO	√	√	√	√	√		
USA	LANCER(CS#,C T#)	AYC/ACD	√	√	√	√	√		
USA	LANCER(CY#)	ENGINE	√	√	√	√	√	1.Learned value reset(*) 2.OBD test results (Mode \$06) 3.In-use performance tracking(ENH) 4.In-use performance tracking(OBD) 5.Ethanol forced learning mode 6.Timing chain maintenance 7.Learning	1.READINESS TEST 2.CODING
USA	LANCER(CY#)	ABS	√	√	√	√	√	1.Emission gas mode(*) 2.All sensors calibration(*) 3.Frozen Keys	

Mitsubishi **V32.00** Diagnostics List (Note: For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
USA	LANCER(CY#)	SRS	√	√	√	√	√		
USA	LANCER(CY#)	AC	√	√	√	√	√		
USA	LANCER(CY#)	METER	√	√	√	√	√	1.Head lamp Auto leveling Diag mode(*) 2.Service reminder(*) 3.Test	
USA	LANCER(CY#)	ETACS	√	√	√	√	√	1.Customization 2.Customization information 3.Customization Reset 4.Alarm record (optional)(*)	
USA	LANCER(CY#)	IMMO	√	√	√	√	√	1.Key registration (Use the key) 2.Key registration(The number of the bar code) 3.Engine Key Code registration 4.Short of key ID Registration (*) 5.ENGINE KEY CODE registration&VIN WRITING 6.Change Password	1.CODING
USA	LANCER(CY#)	HFM	√	√	√	√	√		
USA	LANCER(CY#)	AUDIO	√	√	√	√	√		
USA	LANCER(CY#)	4WS/Electric Power Steering	√	√	√	√	√		
USA	LANCER(CY#)	OCM	√	√	√	√	√	1.Zero Calibratio&Sys Check	
USA	LANCER(CY#)	AUTO CRUISE	√	√	√	√			

Mitsubishi V32.00Diagnostics List(Note:For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
USA	LANCER(CY#)	Shift Lever	√	√	√	√	√		
USA	LANCER(CY#)	AND	√	√	√	√	√		
USA	LANCER(CY#)	SATELLITE RADIO	√	√	√	√	√		
USA	LANCER(CY#)	SAS	√	√	√			1.SAS calibration(*)	
USA	LANCER(CY#)	LIN	√	√	√	√		Rain sensor adaptation	
USA	LANCER(CY#)	AYC/ACD	√	√	√	√	√	1.Emission gas mode 2.Sensor calibration 3.Test	
USA	LANCER(CY#)	AT	√	√	√	√	√	1.Electronic oil pump air bleeding 2.CVT oil degradation level (*) 3.Teach-in 4.Emission gas mode	1.CODING
USA	LANCER(CY#)	TPMS	√	√	√	√		1.Tire pressure sensor ID registration(*) 2.Tire pressure sensor ID check(*)	
USA	LANCER(CY#)	Auto Stop & Go	√	√	√	√			

Mitsubishi **V32.00** Diagnostics List (Note: For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
USA	LANCER EVOLUTION	ENGINE	√	√	√	√	√	1.Learned value reset(*) 2.OBD test results (Mode \$06) 3.In-use performance tracking(ENH) 4.In-use performance tracking(OBD) 5.Ethanol forced learning mode 6.Timing chain maintenance 7.Learning	1.READINESS TEST 2.CODING
USA	LANCER EVOLUTION	AT	√	√	√	√	√	1.Teach-in	1.CODING
USA	LANCER EVOLUTION	ABS	√	√	√	√	√	1.Valve pressure learning 2.Emission gas mode(*) 3.Sensor calibration(*)	
USA	LANCER EVOLUTION	SRS	√	√	√	√	√		
USA	LANCER EVOLUTION	AC	√	√	√	√	√		
USA	LANCER EVOLUTION	METER	√	√	√	√	√	1.Head lamp Auto leveling Diag mode(*) 2.Service reminder(*) 3.Test	

Mitsubishi **V32.00** Diagnostics List (Note: For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
USA	LANCER EVOLUTION	AUTO CRUISE	√	√	√	√			
USA	LANCER EVOLUTION	AND	√	√	√	√	√		
USA	LANCER EVOLUTION	LIN	√	√	√	√		Rain sensor adaptation	
USA	LANCER EVOLUTION	AUDIO	√	√	√	√	√		
USA	LANCER EVOLUTION	OCM	√	√	√	√	√	1.Zero Calibratio&Sys Check	
USA	LANCER EVOLUTION	SATELLITE RADIO	√	√	√	√	√		
USA	LANCER EVOLUTION	SHIFT LEVER	√	√	√	√	√		
USA	LANCER SPORTBACK(CS #)	ENGINE	√	√	√	√	√		
USA	LANCER SPORTBACK(CS #)	AT	√	√	√	√	√		
USA	LANCER SPORTBACK(CS #)	ABS	√	√	√	√	√		

Mitsubishi **V32.00** Diagnostics List (Note: For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
USA	LANCER SPORTBACK(CS #)	SRS	√	√	√	√			
USA	LANCER SPORTBACK(CS #)	SWS	√	√	√	√	√		
USA	LANCER SPORTBACK(CX #)	ENGINE	√	√	√	√	√	1.Learned value reset(*) 2.OBD test results (Mode \$06) 3.In-use performance tracking(ENH) 4.In-use performance tracking(OBD) 5.Ethanol forced learning mode 6.Timing chain maintenance 7.Learning	1.READINESS TEST 2.CODING
USA	LANCER SPORTBACK(CX #)	AT	√	√	√	√	√	1.Electronic oil pump air bleeding 2.CVT oil degradation level (*) 3.Teach-in 4.Emission gas mode	1.CODING
USA	LANCER SPORTBACK(CX #)	ABS	√	√	√	√	√	1.Forzen Key 2.Emission gas mode(*) 3.Sensor calibration(*)	

Mitsubishi **V32.00** Diagnostics List (Note: For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
USA	LANCER SPORTBACK(CX #)	SRS	√	√	√	√	√		
USA	LANCER SPORTBACK(CX #)	AC	√	√	√	√	√		
USA	LANCER SPORTBACK(CX #)	METER	√	√	√	√	√	1. Head lamp Auto leveling Diag mode(*) 2. Service reminder(*) 3. Test	
USA	LANCER SPORTBACK(CX #)	ETACS	√	√	√	√	√	1. Customization 2. Customization information 3. Customization Reset 4. Alarm record (optional)(*)	1. CODING
USA	LANCER SPORTBACK(CX #)	SAS	√	√	√			1. SAS calibration(*)	
USA	LANCER SPORTBACK(CX #)	IMMO	√	√	√	√	√	1. ENGINE KEY CODE registration & VIN WRITING 2. Change password(*) 3. Key Registration 4. Short of key ID Registration(*)	1. CODING

Mitsubishi V32.00Diagnostics List(Note:For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
USA	LANCER SPORTBACK(CX #)	AUTO CRUISE	√	√	√	√			
USA	LANCER SPORTBACK(CX #)	4WS/Electric Power Steering	√	√	√	√	√		
USA	LANCER SPORTBACK(CX #)	AYC/ACD	√	√	√	√	√	1.Test 2.Sensor Calibratio 3.Air bleeding	
USA	LANCER SPORTBACK(CX #)	AND	√	√	√	√	√		
USA	LANCER SPORTBACK(CX #)	LIN	√	√	√	√		Rain sensor adaptation	
USA	LANCER SPORTBACK(CX #)	AUDIO	√	√	√	√	√		
USA	LANCER SPORTBACK(CX #)	HFM	√	√	√	√	√		
USA	LANCER SPORTBACK(CX #)	OCM	√	√	√	√	√	1.Zero Calibratio&Sys Check	

Mitsubishi **V32.00** Diagnostics List (Note: For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
USA	LANCER SPORTBACK(CX #)	SATELLITE RADIO	√	√	√	√	√		
USA	LANCER SPORTBACK(CX #)	SHIFT LEVER	√	√	√	√	√		
USA	MIRAGE	ENGINE	√	√	√	√	√	1.Learned value reset 2.OBD test results (Mode \$06) 3.In-use performance tracking(ENH) 4.In-use performance tracking(OBD) 5.Timing chain maintenance	1.READINESS TEST 2.CODING
USA	MIRAGE	AT	√	√	√	√		1.Emission gas mode 2.CVT oil degradation level 3.Sensor calibration 4.Electronic oil pump air bleeding 5.Reset	
USA	MIRAGE	ABS	√	√	√	√	√	1.Emission gas mode 2.Sensor calibration	
USA	MIRAGE	AC	√	√	√	√	√		
USA	MIRAGE	SRS	√	√	√	√	√		1.CODING

Mitsubishi **V32.00** Diagnostics List (Note: For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
USA	MIRAGE	METER	√	√	√	√	√	1.Service reminder 2.Turn-signal sound customization 3.test	
USA	MIRAGE	ETACS	√	√	√	√		1.Customized 2.Customized information 3.Custom reset	1.CODING
USA	MIRAGE	TPMS	√	√	√	√		1.Tire pressure sensor ID registration 2.Tire pressure sensor ID check 3.Tire pressure sensor ID registration(Set2)	
USA	MIRAGE	IMMO	√	√	√	√		1.Change Code 2.Keyless ID Registration 3.Keyless Reception Check 4.Key Registration 5.Key registration (bar code number) 6.ENG. Key code Reg. 7.ENG KEY CODE & Chassis No/VIN Reg	1.CODING

Mitsubishi **V32.00** Diagnostics List (Note: For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
USA	MIRAGE	4WS/Electric Power Steering	√	√	√	√	√		
USA	MIRAGE	SAS	√	√	√			1.SAS calibration	
USA	MIRAGE	OSS	√	√	√	√	√	1.Forced power supply output 2.Forced power supply output(stop)	1.CODING
USA	MIRAGE	OCM	√	√	√	√			
USA	MONTERO	ENGINE	√	√	√	√	√		
USA	MONTERO	AT	√	√	√	√	√		
USA	MONTERO	ABS	√	√	√	√	√		
USA	MONTERO	SRS	√	√	√	√	√		
USA	MONTERO	SWS	√	√	√	√	√		
USA	MONTERO	IMMO	√	√	√	√	√		
USA	MONTERO	AUTO CRUISE	√	√	√	√			
USA	MONTERO	TPMS	√	√	√	√	√	1.Tire pressure sensor ID registration(*) 2.Tire pressure sensor ID check(*) 3.Tire pressure sensor ID check(REQUIRES TOOL)(*)	
USA	MONTERO	TCL/STABILITY CONTROL	√	√	√	√	√		
USA	MONTERO	SS4II	√	√	√	√	√		
USA	MONTERO	AC	√	√	√	√	√		
USA	MONTERO	HBB	√	√	√	√	√		

Mitsubishi V32.00Diagnostics List(Note:For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
USA	OUTLANDER(CU#)	ENGINE	√	√	√	√	√		
USA	OUTLANDER(CU#)	ABS	√	√	√	√	√		
USA	OUTLANDER(CU#)	SRS	√	√	√	√	√		
USA	OUTLANDER(CU#)	SWS	√	√	√	√	√		
USA	OUTLANDER(CU#)	IMMO	√	√	√	√	√		
USA	OUTLANDER(CU#)	AND	√	√	√	√	√		
USA	OUTLANDER(CU#)	AT	√	√	√	√	√		
USA	OUTLANDER(CU#)	AUTO CRUISE	√	√	√	√			
USA	OUTLANDER(CU#)	AC	√	√	√	√	√		

Mitsubishi **V32.00** Diagnostics List (Note: For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
USA	OUTLANDER(C W#)	ENGINE	√	√	√	√	√	1.Learned value reset(*) 2.OBD test results (Mode \$06) 3.In-use performance tracking(ENH) 4.In-use performance tracking(OBD) 5.Ethanol forced learning mode 6.Timing chain maintenance 7.Learning	1.READINESS TEST 2.CODING
USA	OUTLANDER(C W#)	AT	√	√	√	√	√	1.Electronic oil pump air bleeding 2.CVT oil degradation level (*) 3.Permit condition for AS&G 4.Emission gas mode	
USA	OUTLANDER(C W#)	ABS	√	√	√	√	√	1.Forzen key 2.Emission gas mode(*) 3.All sensors calibration(*)	
USA	OUTLANDER(C W#)	SRS	√	√	√	√	√		
USA	OUTLANDER(C W#)	AC	√	√	√	√	√		
USA	OUTLANDER(C W#)	METER	√	√	√	√	√	1.test 2.Head lamp Auto leveling Diag mode(*) 3.Service reminder(*)	

Mitsubishi **V32.00** Diagnostics List (Note: For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
USA	OUTLANDER(CW#)	ETACS	√	√	√	√	√	1.Alarm record (optional)(*) 2.Customization(*) 3.Customization Information(*) 4.Customization Reset(*)	1.CODING
USA	OUTLANDER(CW#)	SAS	√	√	√			1.SAS calibration(*)	
USA	OUTLANDER(CW#)	TPMS	√	√	√	√		1.Tire pressure sensor ID registration(*) 2.Tire pressure sensor ID check(*)	
USA	OUTLANDER(CW#)	IMMO	√	√	√	√	√	1.ENGINE KEY CODE registration&VIN WRITING 2.Steering lock unit registration 3.Key registration (bar code number)(*) 4.Key&KOS (Keyless Operation System) 5.key registration (*) 6.Engine Key Code registration 7.Security application file generation 8.Comm. Test 9.Change Password	
USA	OUTLANDER(CW#)	AUTO CRUISE	√	√	√	√			

Mitsubishi **V32.00** Diagnostics List (Note: For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
USA	OUTLANDER(C W#)	AND	√	√	√				
USA	OUTLANDER(C W#)	LIN	√	√	√	√		Rain sensor adaptation	
USA	OUTLANDER(C W#)	AUDIO	√	√	√	√			
USA	OUTLANDER(C W#)	HFM	√	√	√	√	√		
USA	OUTLANDER(C W#)	OCM	√	√	√	√	√	1.Zero Calibratio&Sys Check	
USA	OUTLANDER(C W#)	SATELLITE RADIO	√	√	√				
USA	OUTLANDER(C W#)	MULTI SELECT 4WD	√	√	√	√		Test	
USA	OUTLANDER(C W#)	AWC	√	√	√	√		1.Reset 2.Test	

Mitsubishi **V32.00** Diagnostics List (Note: For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
USA	OUTLANDER(G F#)	ENGINE	√	√	√	√	√	1.Learned value reset(*) 2.OBD test results (Mode \$06) 3.In-use performance tracking(ENH) 4.In-use performance tracking(OBD) 5.Ethanol forced learning mode 6.Timing chain maintenance 7.Learning	1.READINESS TEST 2.CODING
USA	OUTLANDER(G F#)	AT	√	√	√	√		1.Emission gas mode 2.CVT oil degradation level 3.Electronic oil pump air bleeding 4.Permit condition for AS&G	
USA	OUTLANDER(G F#)	ABS	√	√	√	√			
USA	OUTLANDER(G F#)	AC	√	√	√	√	√		
USA	OUTLANDER(G F#)	SRS	√	√	√	√	√		1.CODING
USA	OUTLANDER(G F#)	METER	√	√	√	√	√	1.Service reminder 2.Turn-signal sound customization 3.Test	

Mitsubishi V32.00Diagnostics List(Note:For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
USA	OUTLANDER(G F#)	ETACS	√	√	√	√	√	1.Customization 2.Customization information 3.Customization Reset 4.Security alarm 5.HS initial position Clear 6.HS initial position learning	1.CODING
USA	OUTLANDER(G F#)	TPMS	√	√	√	√		1.Tire pressure sensor ID registration 2.Tire pressure sensor ID check 3.Tire pressure sensor ID registration(Set2)	
USA	OUTLANDER(G F#)	IMMO	√	√	√	√	√	1.Comm.Test 2.KOS key registration	CODING
USA	OUTLANDER(G F#)	AUTO CRUISE	√	√	√	√			
USA	OUTLANDER(G F#)	4WS/Electric Power Steering	√	√	√	√	√		
USA	OUTLANDER(G F#)	SAS	√	√	√			1.SAS Calibration	
USA	OUTLANDER(G F#)	LIN	√	√	√	√		1.Rain Sensor Adaptation	
USA	OUTLANDER(G F#)	AWC	√	√	√	√		1.Reset 2.Test	

Mitsubishi V32.00Diagnostics List(Note:For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
USA	OUTLANDER(G F#)	OSS	√	√	√	√	√	1. Forced power supply output 2. Forced power supply output(stop)	1.CODING
USA	OUTLANDER(G F#)	AND	√	√	√				
USA	OUTLANDER(G F#)	ACC/FCM	√	√	√	√		1.Reset 2.Learning	
USA	OUTLANDER(G F#)	AUDIO	√	√	√				
USA	OUTLANDER(G F#)	Lane Keep	√	√	√	√	√	1.Reset 2.Learning	
USA	OUTLANDER(G F#)	Power Gate	√	√	√	√	√		
USA	OUTLANDER(G F#)	CORNER SENSOR	√	√	√	√			
USA	OUTLANDER(G F#)	OCM	√	√	√	√			

Mitsubishi V32.00Diagnostics List(Note:For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
USA	OUTLANDER SPORT/RVR	ETACS	√	√	√	√	√	1.Customization 2.Customization information 3.Customization Reset 4.Alarm record (optional)(*)	1.CODING
USA	OUTLANDER SPORT/RVR	METER	√	√	√	√	√	1 Head lamp Auto leveling Diag mode(*) 2.Service reminder(*) 3.Test	
USA	OUTLANDER SPORT/RVR	SAS	√	√	√			1.SAS Calibration	
USA	OUTLANDER SPORT/RVR	MULTI SELECT 4WD	√	√	√	√		Test	
USA	OUTLANDER SPORT/RVR	AND	√	√	√	√	√		
USA	OUTLANDER SPORT/RVR	LIN	√	√	√	√		Rain sensor adaptation	
USA	OUTLANDER SPORT/RVR	AUDIO	√	√	√	√	√		
USA	OUTLANDER SPORT/RVR	OCM	√	√	√	√	√	1.Zero Calibratio&Sys Check	
USA	OUTLANDER SPORT/RVR	SATELLITE RADIO	√	√	√	√			

Mitsubishi **V32.00** Diagnostics List (Note: For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
USA	I-MIEV	BMU	√	√	√	√	√	1.Text 2.CMU ID numbering 3.Cell voltage smoothing 4.Write learned value(Changed ECU) 5.Reset 6.CMU ID numbering 7.Cell voltage smoothing 8.Battery auto capacity measured 9.CMU support forced release 10.Battery capacity measure(Ready) 11.Battery capacity measure(Action)	
USA	I-MIEV	EV/MiEV Remote	√	√	√	√	√	1.Text	
USA	I-MIEV	Keyless Operatio	√	√	√	√	√	1.KOS key Registration 2.Steering lock unit Reg. 3.Comm.Test 4.KOS Customization	
USA	I-MIEV	DC/DC Converter	√	√	√	√			
USA	I-MIEV	OBC	√	√	√	√			
USA	I-MIEV	COMP&HTR	√	√	√	√	√	1.Compressor drive history reset	

Mitsubishi V32.00Diagnostics List(Note:For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
USA	I-MIEV	CMU	√	√	√	√		1.Reset	
AUSTRALIA	380	ENGINE	√	√	√	√	√	1.Learned Value Reset	1.READINESS TEST 2.CODING
AUSTRALIA	380	ABS	√	√	√	√	√		
AUSTRALIA	380	SRS	√	√	√	√	√		
AUSTRALIA	380	SWS	√	√	√	√	√		
AUSTRALIA	380	AC	√	√	√	√	√		
AUSTRALIA	380	METER	√	√	√	√	√		
AUSTRALIA	380	ETACS	√	√	√				
AUSTRALIA	380	IMMO	√	√	√	√		1.Change password(*) 2.Key registration (bar code number)(*) 3.Key&KOS (Keyless Operation System) key registration (*) 4.Key registration (key used)	1.CODING
AUSTRALIA	380	AUTO CRUISE	√			√			
AUSTRALIA	380	TCL/STABILITY CONTROL	√	√	√	√	√		
AUSTRALIA	380	DISPLAY	√	√	√		√		
AUSTRALIA	380	AT	√	√	√	√	√	1.Learned Value Reset 2.Test	
AUSTRALIA	380	RHT/Topstack	√	√	√	√	√		

Mitsubishi V32.00Diagnostics List(Note:For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
AUSTRALIA	ASX	SRS	√	√	√	√	√		1.CODING
AUSTRALIA	ASX	AUTO CRUISE	√	√	√	√			
AUSTRALIA	ASX	4WS/ELECTRIC POWER STEERING	√	√	√	√	√		
AUSTRALIA	ASX	ETACS	√	√	√	√		1.Customization 2.Customization information 3.Customization Reset 4.Alarm record (optional)	1.CODING
AUSTRALIA	ASX	METER	√	√	√	√	√	1.Head lamp Auto leveling Diag mode 2.Service reminder 3.Test	
AUSTRALIA	ASX	SAS	√	√	√			SAS calibration	
AUSTRALIA	ASX	MULTI SELECT 4WD	√	√	√	√		Test	
AUSTRALIA	ASX	AND	√	√	√				
AUSTRALIA	ASX	AUDIO	√	√	√	√			
AUSTRALIA	ASX	LIN	√	√	√	√		Rain sensor adaptation	

Mitsubishi **V32.00** Diagnostics List (Note: For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
AUSTRALIA	CHALLENGER(K9#)	SRS	√	√	√	√	√		
AUSTRALIA	CHALLENGER(K9#)	ETACS	√	√	√	√	√		
AUSTRALIA	CHALLENGER(K9#)	IMMO	√	√	√	√	√		
AUSTRALIA	CHALLENGER(K9#)	AUTO CRUISE	√	√	√	√			
AUSTRALIA	CHALLENGER(K9#)	AT	√	√	√	√	√		
AUSTRALIA	CHALLENGER (KG#,KH#)	ENGINE	√	√	√	√	√	1.Learning 2.Test 3.Initialize(*) 4.Injector ID Writing(Exchanging Injector) 5.Reading Injector ID 6.In-use Performance Tracking (OBD)	1.CODING
AUSTRALIA	CHALLENGER (KG#,KH#)	AT	√	√	√	√	√	1.Learned value reset 2.Test	
AUSTRALIA	CHALLENGER (KG#,KH#)	ABS	√	√	√	√	√	1.Lateral G Sensor Calibration	
AUSTRALIA	CHALLENGER (KG#,KH#)	AC	√	√	√	√	√		

Mitsubishi **V32.00** Diagnostics List (Note: For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
AUSTRALIA	CHALLENGER (KG#,KH#)	SRS		√	√	√	√		
AUSTRALIA	CHALLENGER (KG#,KH#)	ETACS	√	√	√	√		1.Customization 2.Customization Information 3.Customization Reset 4.Short of key ID Registration 5.Short or Key Access Check 6.Reset	1.CODING
AUSTRALIA	CHALLENGER (KG#,KH#)	IMMO	√	√	√	√		1.Key Registration(using key) 2.Key Registration(bar code number) 3.Change password 4.ENGINE KEY CODE registration&VIN WRITING	1.CODING
AUSTRALIA	CHALLENGER (KG#,KH#)	LIN	√	√	√	√			
AUSTRALIA	CHALLENGER (KG#,KH#)	SAS	√	√	√			SAS Calibration	
AUSTRALIA	CHALLENGER (KG#,KH#)	DISPLAY	√	√	√				
AUSTRALIA	COLT	ENGINE	√	√	√	√	√		
AUSTRALIA	COLT	AT	√	√	√	√	√		

Mitsubishi **V32.00** Diagnostics List (Note: For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
AUSTRALIA	COLT	ABS	√	√	√	√	√	1.Emissions Gas Mode(*) 2.SAS Calibration(*) 3.Yaw rate sensor type reset	
AUSTRALIA	COLT	SRS	√	√	√	√	√		
AUSTRALIA	COLT	SWS	√	√	√	√	√		
AUSTRALIA	COLT	AC	√	√	√	√	√		
AUSTRALIA	COLT	METER	√	√	√	√	√		
AUSTRALIA	COLT	ETACS	√	√	√	√	√		
AUSTRALIA	COLT	IMMO	√	√	√	√	√		
AUSTRALIA	COLT	4WS/Electric Power Steering	√	√	√	√	√		
AUSTRALIA	COLT CABRIOLET	ENGINE	√	√	√	√	√	1.Learning	1.READINESS TEST 2.CODING
AUSTRALIA	COLT CABRIOLET	ABS	√	√	√	√	√	1.Emissions Gas Mode 2.SAS Calibration 3.Yaw rate sensor type reset	1.CODING
AUSTRALIA	COLT CABRIOLET	SRS	√	√	√	√	√	SRS ECU Initialize	
AUSTRALIA	COLT CABRIOLET	AC	√	√	√	√	√		
AUSTRALIA	COLT CABRIOLET	METER	√	√	√	√	√	Service reminder	1.CODING
AUSTRALIA	COLT CABRIOLET	ETACS	√	√	√	√	√	1.Customization 2.Customization Information	1.CODING

Mitsubishi V32.00Diagnostics List(Note:For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
AUSTRALIA	COLT CABRIOLET	IMMO	√	√	√	√		1.Key registration 2.Master Key Search 3.Change Password 4.Engine ECU<=>ETACS Matching	
AUSTRALIA	COLT CABRIOLET	4WS/Electric Power Steering	√	√	√	√	√		1.CODING
AUSTRALIA	COLT CABRIOLET	DISPLAY	√	√	√	√	√		
AUSTRALIA	COLT CABRIOLET	RHT/TOPSTACK		√	√	√	√	1.Studying 2.Function Test	1.CODING
AUSTRALIA	EXPRESS(PB#)	ENGINE	√	√	√	√	√		
AUSTRALIA	EXPRESS(PB#)	ABS	√	√	√	√	√		
AUSTRALIA	EXPRESS(PB#)	SRS	√	√	√	√	√		
AUSTRALIA	EXPRESS(PB#)	ETACS	√	√	√	√	√		
AUSTRALIA	EXPRESS(PB#)	IMMO	√	√	√	√	√		
AUSTRALIA	EXPRESS / STAR WAGON(P0#,P1#)	ENGINE	√	√	√	√	√		
AUSTRALIA	GRANDIS	ENGINE	√	√	√	√	√		
AUSTRALIA	GRANDIS	AT	√	√	√	√	√		
AUSTRALIA	GRANDIS	ABS	√	√	√	√	√		
AUSTRALIA	GRANDIS	SRS	√	√	√	√	√		
AUSTRALIA	GRANDIS	SWS	√	√	√	√	√		

Mitsubishi V32.00Diagnostics List(Note:For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
AUSTRALIA	GRANDIS	AC	√	√	√	√	√		
AUSTRALIA	GRANDIS	METER	√	√	√	√	√		
AUSTRALIA	GRANDIS	ETACS	√	√	√	√	√		
AUSTRALIA	GRANDIS	IMMO	√	√	√	√	√		
AUSTRALIA	GRANDIS	AUTO CRUISE	√	√	√	√			
AUSTRALIA	GRANDIS	AND	√	√	√	√	√		
AUSTRALIA	I-MIEV	ABS	√	√	√	√	√	Emission gas mode	
AUSTRALIA	I-MIEV	AC		√	√	√	√		
AUSTRALIA	I-MIEV	SRS		√	√	√	√		
AUSTRALIA	I-MIEV	4WS/Electric Power Steering	√	√	√	√	√		
AUSTRALIA	I-MIEV	ETACS	√	√	√	√		1.Customization 2.Customization Information 3.Customization Reset 4.Short of key ID Registration 5.Short or Key Access Check	1.CODING
AUSTRALIA	I-MIEV	METER	√	√	√	√	√	1.Test 2.Service reminder	1.CODING
AUSTRALIA	I-MIEV	SAS	√	√	√			SAS Calibration	
AUSTRALIA	I-MIEV	LIN	√	√	√	√			

Mitsubishi **V32.00** Diagnostics List (Note: For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
AUSTRALIA	I-MIEV	Keyless Operation	√	√	√	√	√	1.Keyless Operation System key registration 2.Steering lock unit registration 3.Comm.Test 4.KOS Customization	
AUSTRALIA	I-MIEV	IMMO	√	√	√	√		1.key Registration key(using key) 2.Key Registration(bar code number) 3.Change password 4.ENGINE KEY CODE registration&VIN WRITING 5.Key Code agreement	1.CODING
AUSTRALIA	I-MIEV	BMU	√	√	√	√	√	1.Test 2.Reset 3.Write learned value(Changed ECU) 4.Cell voltage smoothing 5.CMU ID numbering 6.Battery capacity measure(Ready) 7.Battery capacity measure(Action) 8.Battery auto capacity measured	
AUSTRALIA	I-MIEV	COMP&HTR	√	√	√	√	√	Compressor drive history reset	

Mitsubishi V32.00Diagnostics List(Note:For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
AUSTRALIA	I-MIEV	EV-ECU	√	√	√	√	√	1.Initialization	1.CODING
AUSTRALIA	I-MIEV	MCU	√	√	√	√	√	Initial Phase Position Of Motor	1.CODING
AUSTRALIA	I-MIEV	CMU	√			√		reset	
AUSTRALIA	I-MIEV	MiEV Remote System	√	√	√	√	√	Test	
AUSTRALIA	I-MIEV	DC/DC Converter	√	√	√	√			
AUSTRALIA	I-MIEV	OBC	√	√	√	√			
AUSTRALIA	LANCER	ENGINE	√	√	√	√	√	1.Learned value reset 2.Learning 3.OBD test results (Mode \$06) 4.In-use performance tracking(ENH) 5.In-use performance tracking(OBD) 6.Ethanol forced learning mode 7.Timing chain maintenance	1.READINESS TEST 2.CODING
AUSTRALIA	LANCER	AT	√	√	√	√	√	1.CVT oil degradation level 2.Electronic oil pump air bleeding 3.Permit condition for AS&G 4.Teach-in 5.Emission gas mode	1.CODING
AUSTRALIA	LANCER	ABS	√	√	√	√	√	1.Emission gas mode(*) 2.All sensors calibration(*)	1.Freeze Frame
AUSTRALIA	LANCER	SRS	√	√	√	√	√		

Mitsubishi **V32.00** Diagnostics List (Note: For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
AUSTRALIA	LANCER	AC	√	√	√	√	√		
AUSTRALIA	LANCER	4WS/Electric Power Steering	√	√	√	√	√		
AUSTRALIA	LANCER	AYC/ACD	√	√	√	√		1.Sensor calibration 2.Air bleeding 3.Test	
AUSTRALIA	LANCER	METER	√	√	√	√	√	1.Head lamp Auto leveling Diag mode(*) 2.Service reminder(*) 3.Test	
AUSTRALIA	LANCER	ETACS	√	√	√	√		1.Customization 2.Customization information 3.Customization Reset 4.Alarm record (optional)(*)	1.CODING
AUSTRALIA	LANCER	SAS	√	√	√			1.SAS calibration(*)	

Mitsubishi **V32.00** Diagnostics List (Note: For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
AUSTRALIA	LANCER	IMMO	√	√	√	√	√	1.Change password 2.Key registration (bar code number) 3.Key&KOS (Keyless Operation System) key registration 4.Steering lock unit registration 5.Comm.Test 6.ENG key code registration 7.ENG key code&Chassis No.registration 8.Key Registration 9.Keyless ID registration	1.CODING
AUSTRALIA	LANCER	AUTO CRUISE	√	√	√	√			
AUSTRALIA	LANCER	LIN	√	√	√	√		Rain sensor adaptation	
AUSTRALIA	LANCER	AUDIO	√	√	√	√			
AUSTRALIA	LANCER	AND	√	√	√				
AUSTRALIA	LANCER	HFM	√	√	√	√	√		
AUSTRALIA	LANCER	AFS/ACL	√	√	√	√	√	1.HS initial postion Clear 2.HS initial postion Learning	
AUSTRALIA	LANCER	SHIFT LEVER	√	√	√	√	√		
AUSTRALIA	LANCER	CORNER SENSOR/BACK SENSOR	√	√	√	√			

Mitsubishi V32.00Diagnostics List(Note:For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
AUSTRALIA	LANCER EVOLUTION	ENGINE	√	√	√	√	√	1.Learned value reset 2.Learning 3.OBD test results (Mode \$06) 4.In-use performance tracking(ENH) 5.In-use performance tracking(OBD) 6.Ethanol forced learning mode 7.Timing chain maintenance	1.READINESS TEST 2.CODING
AUSTRALIA	LANCER EVOLUTION	AT	√	√	√	√		1.Provisional DTCs 2.Teach-in	
AUSTRALIA	LANCER EVOLUTION	ABS	√	√	√	√	√	1.Emission gas mode(*) 2.All sensors calibration(*) 3.Valve pressure learning	1.Freeze Frame
AUSTRALIA	LANCER EVOLUTION	SRS	√	√	√	√	√		
AUSTRALIA	LANCER EVOLUTION	SHIFT LEVER	√	√	√	√	√		
AUSTRALIA	LANCER EVOLUTION	AC	√	√	√	√	√		
AUSTRALIA	LANCER EVOLUTION	METER	√	√	√	√	√	1.Head lamp Auto leveling Diag mode(*) 2.Service reminder(*) 3.Test	

Mitsubishi V32.00Diagnostics List(Note:For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
AUSTRALIA	LANCER EVOLUTION	ETACS	√	√	√	√		1.Customization 2.Customization information 3.Customization Reset 4.Alarm record (optional)(*)	1.CODING
AUSTRALIA	LANCER EVOLUTION	SAS	√	√	√			1.SAS calibration	
AUSTRALIA	LANCER EVOLUTION	IMMO	√	√	√	√	√	1.Change password 2.Key registration (bar code number) 3.Key&KOS (Keyless Operation System) key registration 4.Steering lock unit registration 5.Comm.Test 6.ENG key code registration 7.ENG key code&Chassis No.registration 8.Key Registration 9.Keyless ID registration	1.CODING
AUSTRALIA	LANCER EVOLUTION	AUTO CRUISE	√	√	√	√			
AUSTRALIA	LANCER EVOLUTION	AFS/ACL	√	√	√	√	√	1.HS initial postion Clear 2.HS initial postion Learning	

Mitsubishi V32.00Diagnostics List(Note:For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
AUSTRALIA	LANCER EVOLUTION	AYC/ACD	√	√	√	√		1.Sensor Calibration 2.Air bleeding 3.Test	
AUSTRALIA	LANCER EVOLUTION	AND	√	√	√				
AUSTRALIA	LANCER EVOLUTION	LIN	√	√	√	√		Rain sensor adaptation	
AUSTRALIA	LANCER EVOLUTION	AUDIO	√	√	√	√			
AUSTRALIA	LANCER EVOLUTION	HFM	√	√	√	√	√		
AUSTRALIA	LANCER EVOLUTION	CORNER SENSOR	√	√	√	√			
AUSTRALIA	LANCER SEDAN	ENGINE	√	√	√	√	√		
AUSTRALIA	LANCER SEDAN	ABS	√	√	√	√	√		
AUSTRALIA	LANCER SEDAN	SRS	√	√	√	√	√		
AUSTRALIA	LANCER SEDAN	SWS	√	√	√	√	√		
AUSTRALIA	LANCER SEDAN	IMMO	√	√	√	√	√		
AUSTRALIA	LANCER SEDAN	AUTO CRUISE	√	√	√	√			
AUSTRALIA	LANCER SEDAN	AT	√	√	√	√	√		
AUSTRALIA	LANCER SEDAN	AC	√	√	√	√	√		
AUSTRALIA	LANCER SEDAN	AYC/ACD	√	√	√	√	√		

Mitsubishi **V32.00** Diagnostics List (Note: For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
AUSTRALIA	LANCER SPORTBACK	METER	√	√	√	√	√	1.Head lamp Auto leveling Diag mode(*) 2.Service reminder(*) 3.Test	
AUSTRALIA	LANCER SPORTBACK	ETACS	√	√	√	√		1.Customization 2.Customization information 3.Customization Reset 4.Alarm record (optional)(*)	1.CODING
AUSTRALIA	LANCER SPORTBACK	SAS	√	√	√			1.SAS calibration	
AUSTRALIA	LANCER SPORTBACK	IMMO	√	√	√	√	√	1.Change password 2.Key registration (bar code number) 3.Key&KOS (Keyless Operation System) key registration 4.Steering lock unit registration 5.Comm.Test 6.ENG key code registration 7.ENG key code&Chassis No.registration 8.Key Registration 9.Keyless ID registration	1.CODING
AUSTRALIA	LANCER SPORTBACK	AUTO CRUISE	√	√	√	√			

Mitsubishi **V32.00** Diagnostics List (Note: For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
AUSTRALIA	LANCER SPORTBACK	4WS/Electric Power Steering	√	√	√	√	√		
AUSTRALIA	LANCER SPORTBACK	AFS/ACL	√	√	√	√	√	1.HS initial position Clear 2.HS initial position Learning	
AUSTRALIA	LANCER SPORTBACK	AYC/ACD	√	√	√	√	√	1.Sensor Calibration 2.Air bleeding 3.Test	
AUSTRALIA	LANCER SPORTBACK	AND	√	√	√				
AUSTRALIA	LANCER SPORTBACK	LIN	√	√	√	√		Rain sensor adaptation	
AUSTRALIA	LANCER SPORTBACK	AUDIO	√	√	√	√			
AUSTRALIA	LANCER SPORTBACK	HFM	√	√	√	√	√		
AUSTRALIA	LANCER SPORTBACK	CORNER SENSOR/BACK SENSOR	√	√	√	√			
AUSTRALIA	LANCER WAGON	ENGINE	√	√	√	√	√		
AUSTRALIA	LANCER WAGON	ABS	√	√	√	√	√		
AUSTRALIA	LANCER WAGON	SRS	√	√	√	√	√		

Mitsubishi **V32.00** Diagnostics List (Note: For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
AUSTRALIA	LANCER WAGON	SWS	√	√	√	√	√		
AUSTRALIA	LANCER WAGON	AC	√	√	√	√	√		
AUSTRALIA	LANCER WAGON	IMMO	√	√	√	√	√		
AUSTRALIA	LANCER WAGON	AUTO CRUISE	√	√	√	√			
AUSTRALIA	LANCER WAGON	AT	√	√	√	√	√		
AUSTRALIA	MIRAGE(A0#)	ENGINE	√	√	√	√	√	1.Learned value reset 2.OBD test results (Mode \$06) 3.In-use performance tracking(ENH) 4.In-use performance tracking(OBD) 5.Timing chain maintenance	1.READINESS TEST 2.CODING
AUSTRALIA	MIRAGE(A0#)	AT	√	√	√	√		1.Emission gas mode 2.CVT oil degradation level 3.Sensor calibration 4.Electronic oil pump air bleeding 5.Reset	
AUSTRALIA	MIRAGE(A0#)	ABS	√	√	√	√	√	1.Emission gas mode 2.Sensor calibration	

Mitsubishi **V32.00** Diagnostics List (Note: For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
AUSTRALIA	MIRAGE(A0#)	AC	√	√	√	√	√		
AUSTRALIA	MIRAGE(A0#)	SRS	√	√	√	√	√		1.CODING
AUSTRALIA	MIRAGE(A0#)	METER	√	√	√	√	√	1.Maintenance reminder 2.Turn-signal sound customization 3.text	
AUSTRALIA	MIRAGE(A0#)	ETACS	√	√	√	√		1.Customized 2.Customized information 3.Custom reset	1.CODING
AUSTRALIA	MIRAGE(A0#)	IMMO	√	√	√	√			
AUSTRALIA	MIRAGE(A0#)	4WS/Electric Power Steering	√	√	√	√	√		
AUSTRALIA	MIRAGE(A0#)	SAS	√	√	√	√			
AUSTRALIA	MIRAGE(A0#)	LIN	√	√	√	√		1.Rain Sensor Adaptation	
AUSTRALIA	MIRAGE(A0#)	OSS	√	√	√	√	√	1. Forced power supply output 2. Forced power supply output(stop)	1.CODING
AUSTRALIA	MIRAGE(A1#)	ENGINE	√	√	√	√	√	1.Learned value reset 2.OBD test results (Mode \$06) 3.In-use performance tracking(ENH) 4.In-use performance tracking(OBD) 5.Timing chain maintenance	1.READINESS TEST 2.CODING

Mitsubishi **V32.00** Diagnostics List (Note: For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
AUSTRALIA	MIRAGE(A1#)	AT	√	√	√	√		1.Emission gas mode 2.CVT oil degradation level 3.Sensor calibration 4.Electronic oil pump air bleeding 5.Reset	
AUSTRALIA	MIRAGE(A1#)	ABS	√	√	√	√	√	1.Emission gas mode 2.Sensor calibration	
AUSTRALIA	MIRAGE(A1#)	AC	√	√	√	√	√		
AUSTRALIA	MIRAGE(A1#)	SRS	√	√	√	√			
AUSTRALIA	MIRAGE(A1#)	METER	√	√	√	√	√	1.Maintenance reminder 2.Turn-signal sound customization 3.test	
AUSTRALIA	MIRAGE(A1#)	ETACS	√	√	√	√		1.Customized 2.Customized information 3.Custom reset	1.CODING
AUSTRALIA	MIRAGE(A1#)	IMMO	√	√	√	√			
AUSTRALIA	MIRAGE(A1#)	4WS/Electric Power Steering	√	√	√	√			
AUSTRALIA	MIRAGE(A1#)	SAS	√	√	√	√			
AUSTRALIA	MIRAGE(A1#)	LIN	√	√	√	√		1.Rain Sensor Adaptation	
AUSTRALIA	OUTLANDER(CU#)	ENGINE	√	√	√	√	√		

Mitsubishi **V32.00** Diagnostics List (Note: For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
AUSTRALIA	OUTLANDER(CU#)	AT	√	√	√	√	√		
AUSTRALIA	OUTLANDER(CU#)	ABS	√	√	√	√	√		
AUSTRALIA	OUTLANDER(CU#)	SRS	√	√	√	√	√		
AUSTRALIA	OUTLANDER(CU#)	SWS	√	√	√	√	√		
AUSTRALIA	OUTLANDER(CU#)	AC	√	√	√	√	√		
AUSTRALIA	OUTLANDER(CU#)	IMMO	√	√	√	√	√		
AUSTRALIA	OUTLANDER(CU#)	AUTO CRUISE	√	√	√	√			
AUSTRALIA	OUTLANDER(CW#)	ENGINE	√	√	√	√	√	1.Learned value reset 2.Learning 3.OBD test results (Mode \$06) 4.In-use performance tracking(ENH) 5.In-use performance tracking(OBD) 6.Ethanol forced learning mode 7.Timing chain maintenance	1.READINESS TEST 2.CODING

Mitsubishi **V32.00** Diagnostics List (Note: For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
AUSTRALIA	OUTLANDER(C W#)	AT	√	√	√	√	√	1.CVT oil degradation level 2.Electronic oil pump air bleeding 3.Permit condition for AS&G 4.Teach-in 5.Emission gas mode	CODING
AUSTRALIA	OUTLANDER(C W#)	ABS	√	√	√	√	√	1.Emission gas mode(*) 2.All sensors calibration(*)	
AUSTRALIA	OUTLANDER(C W#)	SRS	√	√	√	√	√		
AUSTRALIA	OUTLANDER(C W#)	AC	√	√	√	√	√		
AUSTRALIA	OUTLANDER(C W#)	METER	√	√	√	√	√	1.Head lamp Auto leveling Diag mode(*) 2.Service reminder(*) 3.Test	
AUSTRALIA	OUTLANDER(C W#)	ETACS	√	√	√	√		1.Customization 2.Customization information 3.Customization Reset 4.Alarm record (optional)(*)	

Mitsubishi **V32.00** Diagnostics List (Note: For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
AUSTRALIA	OUTLANDER(C W#)	IMMO	√	√	√	√	√	1.Change password 2.Key registration (bar code number) 3.Key&KOS (Keyless Operation System) key registration 4.Steering lock unit registration 5.Comm.Test 6.ENG key code registration 7.ENG key code&Chassis No.registration 8.Key Registration 9.Keyless ID registration	1.CODING
AUSTRALIA	OUTLANDER(C W#)	AUTO CRUISE	√	√	√	√			
AUSTRALIA	OUTLANDER(C W#)	AFS/ACL	√	√	√	√	√	1.HS initial position Clear 2.HS initial position Learning	
AUSTRALIA	OUTLANDER(C W#)	AND	√	√	√				
AUSTRALIA	OUTLANDER(C W#)	LIN	√	√	√	√		Rain sensor adaptation	
AUSTRALIA	OUTLANDER(C W#)	MULTI SELECT 4WD	√	√	√	√		Test	
AUSTRALIA	OUTLANDER(C W#)	AUDIO	√	√	√	√			

Mitsubishi V32.00Diagnostics List(Note:For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
AUSTRALIA	OUTLANDER(C W#)	SAS	√	√	√			1.SAS calibration	
AUSTRALIA	OUTLANDER(C W#)	HFM	√	√	√	√	√		
AUSTRALIA	OUTLANDER(C W#)	AWC	√	√	√	√		1.Reset 2.Test	
AUSTRALIA	OUTLANDER(C W#)	CORNER SENSOR/BACK SENSOR	√	√	√	√			
AUSTRALIA	OUTLANDER(C W#)	OSS	√	√	√	√	√	1. Forced power supply output 2. Forced power supply output(stop)	1.CODING
AUSTRALIA	OUTLANDER(C W#)	Power Gate	√	√	√	√	√		

Mitsubishi **V32.00** Diagnostics List (Note: For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
AUSTRALIA	OUTLANDER(G F#)	ENGINE	√	√	√	√	√	1.Test 2.Learning 3.Initialization 4.Injector ID Writing(Exchanging Injector) 5.Injector ID Readout 6.In-use performance tracking(OBD) 7.Write learned value(changed ECU) 8.DPF regeneration 9.In-use performance tracking(ENH) 10.Timing chain maintenance 11.Learned value reset 12.Ethanol forced learning mode	1.CODING 2.READINESS TEST
AUSTRALIA	OUTLANDER(G F#)	AT	√	√	√	√			
AUSTRALIA	OUTLANDER(G F#)	ABS	√	√	√	√			
AUSTRALIA	OUTLANDER(G F#)	AC	√	√	√	√			
AUSTRALIA	OUTLANDER(G F#)	SRS	√	√	√	√			

Mitsubishi **V32.00** Diagnostics List (Note: For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
AUSTRALIA	OUTLANDER(G F#)	METER	√	√	√	√	√	1.Service reminder 2.Turn-signal sound customization 3.Test	
AUSTRALIA	OUTLANDER(G F#)	ETACS	√	√	√	√			
AUSTRALIA	OUTLANDER(G F#)	IMMO	√	√	√	√			
AUSTRALIA	OUTLANDER(G F#)	AUTO CRUISE	√	√	√	√			
AUSTRALIA	OUTLANDER(G F#)	4WS/Electric Power Steering	√	√	√	√			
AUSTRALIA	OUTLANDER(G F#)	SAS	√	√	√	√			
AUSTRALIA	OUTLANDER(G F#)	LIN	√	√	√	√			
AUSTRALIA	OUTLANDER(G F#)	AWC	√	√	√	√			
AUSTRALIA	OUTLANDER(G F#)	OSS	√	√	√	√			
AUSTRALIA	OUTLANDER(G F#)	AND	√	√	√	√			
AUSTRALIA	OUTLANDER(G F#)	ACC/FCM	√	√	√	√		1.Reset 2.Learning	

Mitsubishi **V32.00** Diagnostics List (Note: For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
AUSTRALIA	OUTLANDER(G F#)	AUDIO	√	√	√	√			
AUSTRALIA	OUTLANDER(G F#)	CORNER SENSOR/BACK SENSOR	√	√	√	√			
AUSTRALIA	OUTLANDER(G F#)	Power Gate	√	√	√	√			
AUSTRALIA	OUTLANDER-PHEV	ENGINE	√	√	√	√	√	1.Learned value reset 2.Learning 3.OBD test results (Mode \$06) 4.In-use performance tracking(ENH) 5.In-use performance tracking(OBD) 6.Ethanol forced learning mode 7.Timing chain maintenance	1.READINESS TEST 2.CODING
AUSTRALIA	OUTLANDER-PHEV	ABS	√	√	√	√			
AUSTRALIA	OUTLANDER-PHEV	AC	√	√	√	√			
AUSTRALIA	OUTLANDER-PHEV	SRS	√	√	√	√			

Mitsubishi V32.00Diagnostics List(Note:For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
AUSTRALIA	OUTLANDER-PHEV	METER	√	√	√	√	√	1.Service reminder 2.Turn-signal sound customization 3.Test	1.CODING
AUSTRALIA	OUTLANDER-PHEV	ETACS	√	√	√	√	√	1.Customization 2.Customization information 3.Customization Reset 4.Security alarm 5.HS initial position Clear 6.HS initial position learning	
AUSTRALIA	OUTLANDER-PHEV	IMMO	√	√	√	√	√	1.Comm.Test 2.KOS key registration	CODING
AUSTRALIA	OUTLANDER-PHEV	4WS/Electric Power Steering	√	√	√	√	√		
AUSTRALIA	OUTLANDER-PHEV	SAS	√	√	√	√			
AUSTRALIA	OUTLANDER-PHEV	LIN	√	√	√	√		1.Rain Sensor Adaptation	

Mitsubishi V32.00Diagnostics List(Note:For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
AUSTRALIA	OUTLANDER-PHEV	BMU	√	√	√	√	√	1.CMU support forced release 2.Write learned value(Changed ECU) 3.Reset 4.Test 5.CMU ID numbering 6.Cell Voltage smoothing 7.Battery auto capacity measured	
AUSTRALIA	OUTLANDER-PHEV	EV/MiEV Remote System	√	√	√	√	√		
AUSTRALIA	OUTLANDER-PHEV	OSS	√	√	√	√	√	1. Forced power supply output 2. Forced power supply output(stop)	1.CODING
AUSTRALIA	OUTLANDER-PHEV	AND	√	√	√				
AUSTRALIA	OUTLANDER-PHEV	ACC/FCM	√	√	√	√		1.Reset 2.Learning	
AUSTRALIA	OUTLANDER-PHEV	AUDIO	√	√	√	√			
AUSTRALIA	OUTLANDER-PHEV	CORNER SENSOR/BACK SENSOR	√	√	√	√			

Mitsubishi **V32.00** Diagnostics List (Note: For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
AUSTRALIA	OUTLANDER-PHEV	Compressor	√	√	√	√			
AUSTRALIA	OUTLANDER-PHEV	F-MCU	√	√	√	√			
AUSTRALIA	OUTLANDER-PHEV	GCU	√	√	√	√	√		
AUSTRALIA	OUTLANDER-PHEV	OBC	√	√	√	√			
AUSTRALIA	OUTLANDER-PHEV	P LOCK	√	√	√	√			
AUSTRALIA	OUTLANDER-PHEV	Power Gate	√	√	√	√			
AUSTRALIA	OUTLANDER-PHEV	PHEV	√	√	√	√	√	1.Test 2.Initialization	CODING
AUSTRALIA	OUTLANDER-PHEV	R-MCU	√	√	√	√			CODING
AUSTRALIA	OUTLANDER-PHEV	CMU	√	√	√	√		1.Reset	
AUSTRALIA	PAJERO(V7#)	ENGINE	√	√	√	√	√		
AUSTRALIA	PAJERO(V7#)	ABS	√	√	√	√	√		
AUSTRALIA	PAJERO(V7#)	SRS	√	√	√	√	√		
AUSTRALIA	PAJERO(V7#)	SWS	√	√	√	√	√		
AUSTRALIA	PAJERO(V7#)	IMMO	√	√	√	√	√		
AUSTRALIA	PAJERO(V7#)	AUTO CRUISE	√	√	√	√			

Mitsubishi **V32.00** Diagnostics List (Note: For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
AUSTRALIA	PAJERO(V7#)	TCL/STABILITY CONTROL	√	√	√	√	√		
AUSTRALIA	PAJERO(V7#)	SS4II	√	√	√	√	√		
AUSTRALIA	PAJERO(V7#)	AT	√	√	√	√	√		
AUSTRALIA	PAJERO(V7#)	AC	√	√	√	√	√		
AUSTRALIA	PAJERO(V8#,V9#)	ENGINE	√	√	√	√	√	1.Test 2.Learning 3.Initialization 4.Injector ID Writing(Exchanging Injector) 5.Injector ID Readout 6.DPF regeneration 7.Write learned value(Changed ECU) 8.Learning value reset 9.OBD test results (Mode \$06) 10.In-use performance tracking(ENH) 11.In-use performance tracking(OBD)	1.READINESS TEST 2.CODING
AUSTRALIA	PAJERO(V8#,V9#)	AT	√	√	√	√	√	1.Learn value reset(*) 2.Test(INVECS-2 control stopped)(*)	

Mitsubishi **V32.00** Diagnostics List (Note: For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
AUSTRALIA	PAJERO(V8#,V9#)	ABS	√	√	√	√	√		
AUSTRALIA	PAJERO(V8#,V9#)	SRS	√	√	√	√	√		
AUSTRALIA	PAJERO(V8#,V9#)	SWS	√	√	√	√	√		
AUSTRALIA	PAJERO(V8#,V9#)	AC		√	√	√	√		
AUSTRALIA	PAJERO(V8#,V9#)	METER	√	√	√	√	√	1.Service reminder(*)	
AUSTRALIA	PAJERO(V8#,V9#)	ETACS	√	√	√	√	√		
AUSTRALIA	PAJERO(V8#,V9#)	IMMO	√	√	√	√		1.Change password(*) 2.Key registration (using key) 3.Key&KOS (Keyless Operation System) key registration (*)	
AUSTRALIA	PAJERO(V8#,V9#)	AUTO CRUISE	√	√	√	√			
AUSTRALIA	PAJERO(V8#,V9#)	SS4II	√	√	√	√	√		
AUSTRALIA	PAJERO(V8#,V9#)	DISPLAY	√	√	√				
AUSTRALIA	PAJERO(V8#,V9#)	LIN	√	√	√	√		Rain sensor adaptation	

Mitsubishi **V32.00** Diagnostics List (Note: For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
AUSTRALIA	PAJERO(V8#,V9#)	CAN/LIN/SWS converter	√	√	√	√		1.Customization 2.Customization information 3.Reset	
AUSTRALIA	TRITON(K6#,K7#)	ENGINE	√	√	√	√	√		
AUSTRALIA	TRITON(K6#,K7#)	IMMO	√	√	√	√	√		
AUSTRALIA	TRITON(K6#,K7#)	ETACS	√	√	√	√	√		
AUSTRALIA	TRITON(K6#,K7#)	ABS	√	√	√	√	√		
AUSTRALIA	TRITON(K6#,K7#)	SRS	√	√	√	√	√		
AUSTRALIA	TRITON(K6#,K7#)	AT	√	√	√	√	√		
AUSTRALIA	TRITON(KA#,KB#)	ENGINE	√	√	√	√	√	1.Learn valued Reset(*) 2.Test 3.Initialize(*) 4.Injector ID Writing(Exchanging Injector) 5.Injector ID Readout	1.CODING
AUSTRALIA	TRITON(KA#,KB#)	ABS	√	√	√	√	√		

Mitsubishi **V32.00** Diagnostics List (Note: For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
AUSTRALIA	TRITON(KA#,K B#)	SRS		√	√	√	√		
AUSTRALIA	TRITON(KA#,K B#)	ETACS	√	√	√	√		1.Customization 2.Customization information 3.Customization Reset 4.Keyless ID registration(*) 5.Keyless reception check(*)	1.CODING
AUSTRALIA	TRITON(KA#,K B#)	IMMO	√	√	√	√	√	1.Change password(*) 2.Key registration (bar code number)(*) 3.Key registration (using key) 4.ENGINE KEY CODE registration&VIN WRITING	1.CODING
AUSTRALIA	TRITON(KA#,K B#)	AT	√	√	√	√	√	1.Learned value reset 2.Test	
AUSTRALIA	TRITON(KA#,K B#)	AC	√	√	√	√	√		
AUSTRALIA	TRITON(KA#,K B#)	LIN	√	√	√	√			
AUSTRALIA	TRITON(KA#,K B#)	DISPLAY	√	√	√				
AUSTRALIA	TRITON(KA#,K B#)	SAS	√	√	√			SAS Calibration	

Mitsubishi V32.00Diagnostics List(Note:For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
GENERAL	380	ENGINE	√	√	√	√	√	1.Learn valued Reset(*)	1.READINESS TEST 2.CODING
GENERAL	380	ABS	√	√	√	√	√		
GENERAL	380	SRS	√	√	√	√	√		
GENERAL	380	SWS	√	√	√	√	√		
GENERAL	380	AC	√	√	√	√	√		
GENERAL	380	METER	√	√	√	√	√		
GENERAL	380	ETACS	√	√	√				
GENERAL	380	IMMO	√	√	√	√	√	1.Key registration (key used) 2.Key registration (bar code number) 3.ENG key code&Chassis No.registration 4.Change password	1.CODING
GENERAL	380	AUTO CRUISE	√	√	√	√			
GENERAL	380	TCL/STABILITY CONTROL	√	√	√	√	√		
GENERAL	380	DISPLAY	√	√	√	√	√		
GENERAL	380	AT	√	√	√	√	√	1.Test 2.Learned Value Reset(*)	
GENERAL	ADVENTURE	ENGINE	√	√	√	√	√		
GENERAL	ADVENTURE	AT	√	√	√	√	√		

Mitsubishi **V32.00** Diagnostics List (Note: For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
GENERAL	ASX / OUTLANDER SPORT / RVR	ENGINE	√	√	√	√	√	1.Learning 2.Learned Value Reset(*) 3.Timing chain maintenance 4.OBD test results (Mode \$06) 5.In-use performance tracking(ENH) 6.In-use performance tracking(OBD) 7.Ethanol forced learning mode 8.Test 9.initialization 10.Injector ID Writing(Exchanging Injector) 11.Injector ID Readout 12.DPF regeneration 13.Write learned value(changed ECU)	1.READINESS TEST 2.CODING
GENERAL	ASX / OUTLANDER SPORT / RVR	AT	√	√	√	√		1.Electronic oil pump air bleeding 2.CVT oil degradation level 3.Emission gas mode 4.Control valve learning mode 5.Calibration value reset 6.Reset	

Mitsubishi **V32.00** Diagnostics List (Note: For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
GENERAL	ASX / OUTLANDER SPORT / RVR	ABS	√	√	√	√	√	1.Sensor calibration 2.Emission gas mode	
GENERAL	ASX / OUTLANDER SPORT / RVR	AC	√	√	√	√	√		
GENERAL	ASX / OUTLANDER SPORT / RVR	SRS	√	√	√	√	√		
GENERAL	ASX / OUTLANDER SPORT / RVR	AUTO CRUISE	√	√	√	√			
GENERAL	ASX / OUTLANDER SPORT / RVR	4WS/Electric Power Steering	√	√	√	√	√		
GENERAL	ASX / OUTLANDER SPORT / RVR	ETACS	√	√	√	√	√	1.Customization 2.Customization information 3.Customization Reset 4.4.Alarm record (optional)(*)	
GENERAL	ASX / OUTLANDER SPORT / RVR	METER	√	√	√	√	√	1.Head lamp Auto leveling Diag mode(*) 2.Service reminder(*) 3.Test	

Mitsubishi V32.00Diagnostics List(Note:For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
GENERAL	ASX / OUTLANDER SPORT / RVR	SAS	√	√	√			1.SAS calibration(*)	
GENERAL	ASX / OUTLANDER SPORT / RVR	MULTI SELECT 4WD	√	√	√	√		Test	
GENERAL	ASX / OUTLANDER SPORT / RVR	AND	√	√	√				
GENERAL	ASX / OUTLANDER SPORT / RVR	LIN	√	√	√	√		Rain sensor adaptation	
GENERAL	ASX / OUTLANDER SPORT / RVR	AUDIO	√	√	√	√			

Mitsubishi **V32.00** Diagnostics List (Note: For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
GENERAL	ASX / OUTLANDER SPORT / RVR	IMMO	√	√	√	√	√	1.Change password(*) 2.Engine Key Code registration 3.Key&KOS (Keyless Operation System) key registration (*) 4.ENGINE KEY CODE registration&VIN WRITING 5.Steering lock unit registration 6.Comm. test 7.Key registration (bar code number)(*)	1.CODING
GENERAL	ASX / OUTLANDER SPORT / RVR	AFS/ACL	√	√	√	√	√	1.HS initial position Clear 2.HS initial position learning	
GENERAL	ASX / OUTLANDER SPORT / RVR	OSS	√	√	√	√	√	1.Forced power supply output 2.Forced power supply output(stop)	1.CODING
GENERAL	ASX / OUTLANDER SPORT / RVR	CORNER SENSOR/BACK SENSOR	√	√	√	√			

Mitsubishi V32.00Diagnostics List(Note:For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
GENERAL	ATTRAGE/MIRAGE G4	ENGINE	√	√	√	√	√	1.Learned value reset 2.OBD test results (Mode \$06) 3.In-use performance tracking(ENH) 4.In-use performance tracking(OBD) 5.Timing chain maintenance	1.READINESS TEST 2.CODING
GENERAL	ATTRAGE/MIRAGE G4	AT	√	√	√	√		1.Emission gas mode 2.CVT oil degradation level 3.Sensor calibration 4.Electronic oil pump air bleeding 5.Reset	
GENERAL	ATTRAGE/MIRAGE G4	ABS	√	√	√	√			
GENERAL	ATTRAGE/MIRAGE G4	AC	√	√	√	√			
GENERAL	ATTRAGE/MIRAGE G4	SRS	√	√	√	√			
GENERAL	ATTRAGE/MIRAGE G4	METER	√	√	√	√			
GENERAL	ATTRAGE/MIRAGE G4	ETACS	√	√	√	√			

Mitsubishi **V32.00** Diagnostics List (Note: For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
GENERAL	ATTRAGE/MIRAGE G4	IMMO	√	√	√	√	√	1.Change Password 2.Keyless ID registration 3.Keyless Reception Check 4.Key registration 5.Key registration (bar code number) 6.Engine Key Code registration 7.ENGINE KEY CODE registration&VIN WRITING 8.Comm. Test 9.KOS Key registration	
GENERAL	ATTRAGE/MIRAGE G4	4WS/Electric Power Steering	√	√	√	√			
GENERAL	ATTRAGE/MIRAGE G4	OSS	√	√	√	√			
GENERAL	CHARIOT	ENGINE	√	√	√	√	√		
GENERAL	CHARIOT	AT	√	√	√	√	√		
GENERAL	CHARIOT	ABS	√	√	√	√	√		
GENERAL	CHARIOT	SWS	√	√	√	√	√		
GENERAL	CHARIOT	AC	√	√	√	√	√		
GENERAL	CHARIOT	IMMO	√	√	√	√	√		
GENERAL	CHARIOT	SRS	√	√	√	√	√		
GENERAL	COLT CABRIOLET	ENGINE	√	√	√	√	√	1.Learning	1.READINESS TEST 2.CODING

Mitsubishi **V32.00** Diagnostics List (Note: For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
GENERAL	COLT CABRIOLET	ABS	√	√	√	√	√	1.YAW rate Sensor type reset 2.Emissions Gas Mode(*) 3.SAS Calibration(*)	1.CODING
GENERAL	COLT CABRIOLET	SRS	√	√	√	√	√	1.SRS ECU Initialize	
GENERAL	COLT CABRIOLET	AC	√	√	√	√	√		
GENERAL	COLT CABRIOLET	METER	√	√	√	√	√	1.Service reminder	
GENERAL	COLT CABRIOLET	ETACS	√	√	√	√	√	1.Customization 2.Customization information	1.CODING
GENERAL	COLT CABRIOLET	IMMO	√	√	√	√		1.Key registration 2.Master Key Search 3.Change Password 4.Engine ECU<=>ETACS Matching	
GENERAL	COLT CABRIOLET	4WS/Electric Power Steering	√	√	√	√	√		
GENERAL	COLT CABRIOLET	DISPLAY	√	√	√	√			
GENERAL	COLT CABRIOLET	RHT/TOPSTACK	√	√	√	√	√	1.Studying 2.Function Test	1.CODING
GENERAL	COLT T120SS	ENGINE	√	√	√	√	√		
GENERAL	COLT/COLT PLUS	ENGINE	√	√	√	√	√		

Mitsubishi **V32.00** Diagnostics List (Note: For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
GENERAL	COLT/COLT PLUS	ABS	√	√	√	√	√	1.YAW rate Sensor type reset 2.Emissions Gas Mode(*) 3.SAS Calibration(*)	
GENERAL	COLT/COLT PLUS	SRS	√	√	√	√	√		
GENERAL	COLT/COLT PLUS	SWS	√	√	√	√	√		
GENERAL	COLT/COLT PLUS	AC	√	√	√	√	√		
GENERAL	COLT/COLT PLUS	METER	√	√	√	√	√		
GENERAL	COLT/COLT PLUS	ETACS	√	√	√	√	√		
GENERAL	COLT/COLT PLUS	IMMO	√	√	√	√	√		
GENERAL	COLT/COLT PLUS	4WS/Electric Power Steering	√	√	√	√	√		
GENERAL	COLT/COLT PLUS	AT	√	√	√	√	√		
GENERAL	COLT/COLT PLUS	POWER GATE	√	√	√				

Mitsubishi **V32.00** Diagnostics List (Note: For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
GENERAL	DELICA D:5	ENGINE	√	√	√	√	√	1.Learning 2.Learned Value Reset(*) 3.Timing chain maintenance 4.OBD test results (Mode \$06) 5.In-use performance tracking(ENH) 6.In-use performance tracking(OBD) 7.Ethanol forced learning mode	1.READINESS TEST 2.CODING
GENERAL	DELICA D:5	AT	√	√	√	√		1.Electronic oil pump air bleeding 2.CVT oil degradation level 3.Emission gas mode	
GENERAL	DELICA D:5	ABS	√	√	√	√	√	1.Emission gas mode(*) 2.All sensors calibration(*) 3.Frozen key	
GENERAL	DELICA D:5	SRS	√	√	√	√	√		
GENERAL	DELICA D:5	AC	√	√	√	√	√		
GENERAL	DELICA D:5	METER	√	√	√	√	√	1.Test 2.Head lamp Auto leveling Diag mode(*) 3.Service reminder(*)	

Mitsubishi V32.00Diagnostics List(Note:For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
GENERAL	DELICA PICK UP	ENGINE	√	√	√	√	√		
GENERAL	DION	ENGINE	√	√	√	√	√		
GENERAL	DION	ABS	√	√	√	√	√		
GENERAL	DION	SRS	√	√	√	√	√		
GENERAL	DION	SWS	√	√	√	√	√		
GENERAL	DION	IMMO	√	√	√	√	√		
GENERAL	DION	AC	√	√	√	√	√		
GENERAL	ECLIPSE	ENGINE	√	√	√	√	√	1.OBD test results (Mode \$06) 2.Learned Value Reset(*) 3.In-use performance tracking(ENH) 4.In-use performance tracking(OBD)	1.READINESS TEST 2.CODING
GENERAL	ECLIPSE	AT	√	√	√	√	√	1.Test 2.Learn Value Reset(*)	
GENERAL	ECLIPSE	ABS	√	√	√	√	√	1.Sensor calibration 2.Lateral G sensor calibration 3.SAS Calibration(*) 4.M/C pressure calibration	
GENERAL	ECLIPSE	SRS	√	√	√	√	√	Seat Weight sensor Accuracy Check	
GENERAL	ECLIPSE	SWS	√	√	√	√	√		
GENERAL	ECLIPSE	AC	√	√	√	√	√		

Mitsubishi V32.00Diagnostics List(Note:For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
GENERAL	ECLIPSE	METER	√	√	√	√	√		
GENERAL	ECLIPSE	ETACS	√	√	√				
GENERAL	ECLIPSE	SAS	√	√	√			1.SAS calibration(*)	
GENERAL	ECLIPSE	IMMO	√	√	√	√		1.Key registration (bar code number)(*) 2.Key&KOS (Keyless Operation System) key registration (*) 3.ENGINE KEY CODE registration&VIN WRITING	1.CODING
GENERAL	ECLIPSE	AUTO CRUISE	√	√	√	√			
GENERAL	EXPRESS	ENGINE	√	√	√	√	√		
GENERAL	EXPRESS	ABS	√	√	√	√	√		
GENERAL	EXPRESS	SRS	√	√	√	√	√		
GENERAL	EXPRESS	ETACS	√	√	√	√	√		
GENERAL	EXPRESS	IMMO	√	√	√	√	√		
GENERAL	GALANT (DJ#,DL#,DM#)	ENGINE	√	√	√	√	√	1.OBD test results (Mode \$06) 2.Learned Value Reset(*) 3.In-use performance tracking(ENH) 4.In-use performance tracking(OBD)	1.READINESS TEST 2.CODING
GENERAL	GALANT (DJ#,DL#,DM#)	AT	√	√	√	√	√	1.Test 2.Learned value reset	

Mitsubishi V32.00Diagnostics List(Note:For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
GENERAL	GALANT (DJ#,DL#,DM#)	ABS	√	√	√	√	√		
GENERAL	GALANT (DJ#,DL#,DM#)	SRS	√	√	√	√	√	Seat Weight sensor Accuracy Check	
GENERAL	GALANT (DJ#,DL#,DM#)	SWS	√	√	√	√	√		
GENERAL	GALANT (DJ#,DL#,DM#)	AC	√	√	√	√	√		
GENERAL	GALANT (DJ#,DL#,DM#)	METER	√	√	√	√	√		
GENERAL	GALANT (DJ#,DL#,DM#)	ETACS	√	√	√				
GENERAL	GALANT (DJ#,DL#,DM#)	IMMO	√	√	√	√		1.Key registration (key used) 2.Key registration (bar code number) 3.ENG key code&Chassis No.registration 4.Change password	1.CODING
GENERAL	GALANT (DJ#,DL#,DM#)	AUTO CRUISE	√	√	√	√			
GENERAL	GALANT (DJ#,DL#,DM#)	TCL/STABILITY CONTROL	√	√	√	√	√		
GENERAL	GALANT(EA#)	ENGINE	√	√	√	√	√		
GENERAL	GALANT(EA#)	ABS	√	√	√	√	√		

Mitsubishi V32.00Diagnostics List(Note:For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
GENERAL	GALANT(EA#)	SRS	√	√	√	√	√		
GENERAL	GALANT(EA#)	ETACS	√	√	√	√	√		
GENERAL	GALANT(EA#)	IMMO	√	√	√	√	√		
GENERAL	GALANT(EA#)	AC	√	√	√	√	√		
GENERAL	GALANT(EA#)	AT	√	√	√	√	√		
GENERAL	GALANT(EA#)	AUTO CRUISE	√	√	√	√			
GENERAL	GALANT(EA#)	TCL/STABILITY CONTROL	√	√	√	√	√		
GENERAL	GRANDIS	ENGINE	√	√	√	√	√		
GENERAL	GRANDIS	ABS	√	√	√	√	√		
GENERAL	GRANDIS	SRS	√	√	√	√	√		
GENERAL	GRANDIS	SWS	√	√	√	√	√		
GENERAL	GRANDIS	AC	√	√	√	√	√		
GENERAL	GRANDIS	METER	√	√	√	√	√		
GENERAL	GRANDIS	ETACS	√	√	√	√	√		
GENERAL	GRANDIS	AND	√	√	√	√	√		
GENERAL	GRANDIS	IMMO	√	√	√	√	√		
GENERAL	GRANDIS	AT	√	√	√	√	√		
GENERAL	GRANDIS	AUTO CRUISE	√	√	√	√			
GENERAL	GRANDIS	KEYLESS OPERATION	√	√	√	√			
GENERAL	GRANDIS	SAS	√	√	√	√	√	1.SAS calibration	
GENERAL	GRANDIS	DISPLAY	√	√	√	√	√		
GENERAL	GRANDIS	POWER GATE	√	√	√				

Mitsubishi **V32.00** Diagnostics List (Note: For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
GENERAL	L200 (K5#,K6#,K7#)	ENGINE	√	√	√	√	√		
GENERAL	L200 (K5#,K6#,K7#)	ABS	√	√	√	√	√		
GENERAL	L200 (K5#,K6#,K7#)	AT	√	√	√	√	√		
GENERAL	L200 (K5#,K6#,K7#)	SRS	√	√	√	√	√		
GENERAL	L200 (K5#,K6#,K7#)	ETACS	√	√	√	√	√		
GENERAL	L200 (K5#,K6#,K7#)	IMMO	√	√	√	√	√		
GENERAL	L300/DELICA WAGON	ENGINE	√	√	√	√	√		
GENERAL	LANCER(CK#)	ENGINE	√	√	√	√	√		
GENERAL	LANCER(CK#)	ABS	√	√	√	√	√		
GENERAL	LANCER(CK#)	SWS	√	√	√	√	√		
GENERAL	LANCER(CK#)	SRS	√	√	√	√	√		
GENERAL	LANCER(CK#)	AT	√	√	√	√	√		
GENERAL	LANCER(CS#,C T#)	ENGINE	√	√	√	√	√		
GENERAL	LANCER(CS#,C T#)	SWS	√	√	√	√	√		

Mitsubishi **V32.00** Diagnostics List (Note: For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
GENERAL	LANCER(CS#,CT#)	ABS	√	√	√	√	√		
GENERAL	LANCER(CS#,CT#)	SRS	√	√	√	√	√		
GENERAL	LANCER(CS#,CT#)	IMMO	√	√	√	√	√		
GENERAL	LANCER(CS#,CT#)	AT	√	√	√	√	√		
GENERAL	LANCER(CS#,CT#)	AC	√	√	√	√	√		
GENERAL	LANCER(CS#,CT#)	AUTO CRUISE	√	√	√	√			
GENERAL	LANCER(CS#,CT#)	AYC/ACD	√	√	√	√	√		
GENERAL	LANCER/LANCER EX(CY#)	ENGINE	√	√	√	√	√	1.Learning 2.Learned Value Reset(*) 3.Timing chain maintenance 4.OBD test results (Mode \$06) 5.In-use performance tracking(ENH) 6.In-use performance tracking(OBD) 7.Ethanol forced learning mode	1.READINESS TEST 2.CODING

Mitsubishi **V32.00** Diagnostics List (Note: For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
GENERAL	LANCER/LANCER EX(CY#)	AT	√	√	√	√	√	1.Teach-In 2.Learn Value Reset 3.Test 4.CVT oil degradation level(*) 5.Electronic oil pump air bleeding 6.Emission gas mode	
GENERAL	LANCER/LANCER EX(CY#)	ABS	√	√	√	√	√	1.Emission gas mode(*) 2.All sensors calibration(*)	
GENERAL	LANCER/LANCER EX(CY#)	SRS	√	√	√	√	√		
GENERAL	LANCER/LANCER EX(CY#)	AC	√	√	√	√	√		
GENERAL	LANCER/LANCER EX(CY#)	METER	√	√	√	√	√	1.Head lamp Auto leveling Diag mode(*) 2.Service reminder(*)	
GENERAL	LANCER/LANCER EX(CY#)	ETACS	√	√	√	√	√	1.Customization 2.Customization information 3.Customization Reset 4.Alarm record (optional)(*)	
GENERAL	LANCER/LANCER EX(CY#)	SAS	√	√	√	√	√	1.SAS calibration(*)	

Mitsubishi **V32.00** Diagnostics List (Note: For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
GENERAL	LANCER/LANCER EX(CY#)	IMMO	√	√	√	√	√	1.Change password(*) 2.Engine Key Code registration 3.Key&KOS (Keyless Operation System) key registration (*) 4.ENGINE KEY CODE registration&VIN WRITING 5.Steering lock unit registration 6.Comm. test 7.Key registration (bar code number)(*)	
GENERAL	LANCER/LANCER EX(CY#)	4WS/Electric Power Steering	√	√	√	√	√		
GENERAL	LANCER/LANCER EX(CY#)	AFS/ACL	√	√	√	√	√	1.HS initial position Clear 2.HS initial position learning	
GENERAL	LANCER/LANCER EX(CY#)	LIN	√	√	√	√		Rain sensor adaptation	
GENERAL	LANCER/LANCER EX(CY#)	AND	√	√	√	√	√		
GENERAL	LANCER/LANCER EX(CY#)	AUDIO	√	√	√	√	√		
GENERAL	LANCER/LANCER EX(CY#)	OCM	√	√	√	√	√	1.Zero Calibration&Sys Check	
GENERAL	LANCER/LANCER EX(CY#)	AUTO CRUISE	√	√	√	√			

Mitsubishi **V32.00** Diagnostics List (Note: For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
GENERAL	LANCER/LANCER EX(CY#)	HFM	√	√	√	√			
GENERAL	LANCER EVOLUTION	ENGINE	√	√	√	√	√	1.Learning 2.Learned Value Reset(*) 3.Timing chain maintenance 4.OBD test results (Mode \$06) 5.In-use performance tracking(ENH) 6.In-use performance tracking(OBD) 7.Ethanol forced learning mode	1.READINESS TEST 2.CODING
GENERAL	LANCER EVOLUTION	AT	√	√	√	√	√	1.Teach-In	
GENERAL	LANCER EVOLUTION	ABS	√	√	√	√	√	1.Valve pressure learning 2.Emissions Gas Mode 3.Sensor Calibration(*)	
GENERAL	LANCER EVOLUTION	SRS	√	√	√	√	√		
GENERAL	LANCER EVOLUTION	AC	√	√	√	√	√		
GENERAL	LANCER EVOLUTION	METER	√	√	√	√	√	1.Head lamp Auto leveling Diag mode(*) 2.Service reminder(*) 3.Test	

Mitsubishi **V32.00** Diagnostics List (Note: For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
GENERAL	LANCER EVOLUTION	AYC/ACD	√	√	√	√	√	1.Test 2.Sensor Calibration(*) 3.Air bleeding	
GENERAL	LANCER EVOLUTION	SAS	√	√	√			1.SAS calibration(*)	
GENERAL	LANCER EVOLUTION	AND	√	√	√	√	√		
GENERAL	LANCER EVOLUTION	LIN	√	√	√	√		Rain sensor adaptation	
GENERAL	LANCER EVOLUTION	AUDIO	√	√	√	√	√		
GENERAL	LANCER EVOLUTION	OCM	√	√	√	√	√	1.Zero Calibration&Sys Check	
GENERAL	LANCER EVOLUTION	SHIFT LEVER	√	√	√	√	√		
GENERAL	LANCER SPORTBACK	ENGINE	√	√	√	√	√	1.Learning 2.Learned Value Reset(*) 3.Timing chain maintenance 4.OBD test results (Mode \$06) 5.In-use performance tracking(ENH) 6.In-use performance tracking(OBD) 7.Ethanol forced learning mode	1.READINESS TEST 2.CODING

Mitsubishi V32.00Diagnostics List(Note:For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
GENERAL	LANCER SPORTBACK	AT	√	√	√	√	√	1.Electronic oil pump air bleeding 2.CVT oil degradation level 3.Teach-in 4.Emission gas mode	
GENERAL	LANCER SPORTBACK	ABS	√	√	√	√	√	1.Frozen key 2.Emissions Gas Mode(*) 3.SAS Calibration(*)	
GENERAL	LANCER SPORTBACK	SRS	√	√	√	√	√		
GENERAL	LANCER SPORTBACK	AC	√	√	√	√	√		
GENERAL	LANCER SPORTBACK	METER	√	√	√	√	√	1.Head lamp Auto leveling Diag mode(*) 2.Service reminder(*) 3.Test	
GENERAL	LANCER SPORTBACK	4WS/Electric Power Steering	√	√	√	√	√		
GENERAL	LANCER SPORTBACK	ETACS	√	√	√	√		1.Alarm record(*) 2.Customization 3.Customization information 4.Customization reset(*)	
GENERAL	LANCER SPORTBACK	SAS	√	√	√			1.SAS calibration(*)	

Mitsubishi V32.00Diagnostics List(Note:For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
GENERAL	LANCER SPORTBACK	HFM	√	√	√	√	√		
GENERAL	LANCER SPORTBACK	SHIFT LEVER	√	√	√	√	√		
GENERAL	LANCER WAGON	ENGINE	√	√	√	√	√		
GENERAL	LANCER WAGON	ABS	√	√	√	√	√		
GENERAL	LANCER WAGON	SRS	√	√	√	√	√		
GENERAL	LANCER WAGON	SWS	√	√	√	√	√		
GENERAL	LANCER WAGON	AC	√	√	√	√	√		
GENERAL	LANCER WAGON	IMMO	√	√	√	√	√		
GENERAL	LANCER WAGON	AUTO CRUISE	√	√	√	√			
GENERAL	LANCER WAGON	AT	√	√	√	√	√		
GENERAL	MAVEN	ENGINE	√	√	√	√	√		
GENERAL	MINICAB-MiEV	ABS	√	√	√	√			
GENERAL	MINICAB-MiEV	SRS	√	√	√	√			
GENERAL	MINICAB-MiEV	METER	√	√	√	√			

Mitsubishi **V32.00** Diagnostics List (Note: For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
GENERAL	MINICAB-MiEV	ETACS	√	√	√	√			
GENERAL	MINICAB-MiEV	4WS/Electric Power Steering	√	√	√	√			
GENERAL	MINICAB-MiEV	EV-ECU	√	√	√	√			
GENERAL	MINICAB-MiEV	BMU	√	√	√	√			
GENERAL	MINICAB-MiEV	MCU	√	√	√	√			
GENERAL	MINICAB-MiEV	COMP&HTR	√	√	√	√			
GENERAL	MINICAB-MiEV	CMU	√			√			
GENERAL	MIRAGE/SPACE STAR	ENGINE	√	√	√	√	√	1.Learned value reset 2.OBD test results (Mode \$06) 3.In-use performance tracking(ENH) 4.In-use performance tracking(OBD) 5.Timing chain maintenance	1.READINESS TEST 2.CODING
GENERAL	MIRAGE/SPACE STAR	AT	√	√	√	√	√	1.Emission gas mode 2.Learn Value Reset 3.Sensor calibration 4.CVT oil degradation level 5.Electronic oil pump air bleeding 6.Reset	
GENERAL	MIRAGE/SPACE STAR	ABS	√	√	√	√	√	1.Emission gas mode 2.Sensor calibration	

Mitsubishi V32.00Diagnostics List(Note:For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
GENERAL	MIRAGE/SPACE STAR	SRS	√	√	√	√	√		CODING
GENERAL	MIRAGE/SPACE STAR	AC	√	√	√	√	√		
GENERAL	MIRAGE/SPACE STAR	4WS/Electric Power Steering	√	√	√	√	√		
GENERAL	MIRAGE/SPACE STAR	ETACS	√	√	√	√		1.Customization 2.Customization Information 3.Customization Reset	CODING
GENERAL	MIRAGE/SPACE STAR	METER	√	√	√	√	√	1.Service reminder 2.Turn-signal sound customization 3.Test	

Mitsubishi **V32.00** Diagnostics List (Note: For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
GENERAL	OUTLANDER(CU#)	AT	√	√	√	√	√		
GENERAL	OUTLANDER(CU#)	AC	√	√	√	√	√		
GENERAL	OUTLANDER(CU#)	AUTO CRUISE	√	√	√	√			
GENERAL	OUTLANDER(CU#)	IMMO	√	√	√	√	√	1.Change password(*) 2.Key registration (bar code number)(*) 3.Key&KOS (Keyless Operation System) key registration (*)	
GENERAL	OUTLANDER / OUTLANDER EX (CW#)	ENGINE	√	√	√	√	√	1.Learning 2.Learned Value Reset(*) 3.Timing chain maintenance 4.OBD test results (Mode \$06) 5.In-use performance tracking(ENH) 6.In-use performance tracking(OBD) 7.Ethanol forced learning mode	1.READINESS TEST 2.CODING
GENERAL	OUTLANDER / OUTLANDER EX (CW#)	AT	√	√	√	√	√	1.Electronic oil pump air bleeding 2.CVT oil degradation level 3.Permit condition for AS&G 4.Emission gas mode	

Mitsubishi **V32.00** Diagnostics List (Note: For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
GENERAL	OUTLANDER / OUTLANDER EX (CW#)	ABS	√	√	√	√	√	1.Emission gas mode(*) 2.All sensors calibration(*) 3.Frozen key	
GENERAL	OUTLANDER / OUTLANDER EX (CW#)	SRS	√	√	√	√	√		
GENERAL	OUTLANDER / OUTLANDER EX (CW#)	AC	√	√	√	√	√		
GENERAL	OUTLANDER / OUTLANDER EX (CW#)	METER	√	√	√	√	√	1.Head lamp Auto leveling Diag mode(*) 2.Service reminder(*) 3.Test	
GENERAL	OUTLANDER / OUTLANDER EX (CW#)	ETACS	√	√	√	√		1.Customization 2.Customization information 3.Customization Reset 4.Alarm record (optional)(*)	
GENERAL	OUTLANDER / OUTLANDER EX (CW#)	SAS	√	√	√			1.SAS calibration(*)	

Mitsubishi **V32.00** Diagnostics List (Note: For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
GENERAL	OUTLANDER / OUTLANDER EX (CW#)	IMMO	√	√	√	√	√	1.Change password(*) 2.Key registration (bar code number)(*) 3.Key&KOS (Keyless Operation System) key registration (*)	1.CODING
GENERAL	OUTLANDER / OUTLANDER EX (CW#)	AND	√	√	√	√	√		
GENERAL	OUTLANDER / OUTLANDER EX (CW#)	LIN	√	√	√	√		Rain sensor adaptation	
GENERAL	OUTLANDER / OUTLANDER EX (CW#)	MULTI SELECT 4WD	√	√	√	√		Test	
GENERAL	OUTLANDER / OUTLANDER EX (CW#)	AUDIO	√	√	√	√	√		
GENERAL	OUTLANDER / OUTLANDER EX (CW#)	AUTO CRUISE	√	√	√	√			

Mitsubishi **V32.00** Diagnostics List (Note: For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
GENERAL	OUTLANDER(G F#)	ENGINE	√	√	√	√	√	1.Test 2.Learning 3.Initialization 4.Injector ID Writing(Exchanging Injector) 5.Injector ID Readout 6.In-use performance tracking(OBD) 7.Write learned value(changed ECU) 8.DPF regeneration 9.In-use performance tracking(ENH) 10.Timing chain maintenance 11.Learned value reset 12.Ethanol forced learning mode	1.CODING 2.READINESS TEST
GENERAL	OUTLANDER(G F#)	AT	√	√	√	√		1.Emission gas mode 2.Electronic oil pump air bleeding 3.CVT oil degradation level 4.Permit condition for AS&G	
GENERAL	OUTLANDER(G F#)	ABS	√	√	√	√			
GENERAL	OUTLANDER(G F#)	AC	√	√	√	√			

Mitsubishi **V32.00** Diagnostics List (Note: For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
GENERAL	OUTLANDER(G F#)	SRS	√	√	√	√			
GENERAL	OUTLANDER(G F#)	METER	√	√	√	√	√	1.Service reminder 2.Turn-signal sound customization 3.Test	
GENERAL	OUTLANDER(G F#)	ETACS	√	√	√	√			
GENERAL	OUTLANDER(G F#)	TPMS	√	√	√	√		1.Tire pressure sensor ID registration 2.Tire pressure sensor ID check 3.Tire pressure sensor ID registration(Set2)	
GENERAL	OUTLANDER(G F#)	IMMO	√	√	√	√	√	1.Change Password 2.Keyless ID registration 3.Key registration 4.Key registration (bar code number) 5.Engine Key Code registration 6.ENGINE KEY CODE registration&VIN WRITING 7.Comm. Test 8.KOS Key registration	
GENERAL	OUTLANDER(G F#)	AUTO CRUISE	√	√	√	√			

Mitsubishi V32.00Diagnostics List(Note:For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
GENERAL	OUTLANDER(G F#)	4WS/Electric Power Steering	√	√	√	√			
GENERAL	OUTLANDER(G F#)	SAS	√	√	√	√			
GENERAL	OUTLANDER(G F#)	LIN	√	√	√	√			
GENERAL	OUTLANDER(G F#)	AS&G	√	√	√	√			
GENERAL	OUTLANDER(G F#)	AWC	√	√	√	√			
GENERAL	OUTLANDER(G F#)	OSS	√	√	√	√			
GENERAL	OUTLANDER(G F#)	AND	√	√	√	√			
GENERAL	OUTLANDER(G F#)	ACC/FCM	√	√	√	√		1.Reset 2.Learning	
GENERAL	OUTLANDER(G F#)	AUDIO	√	√	√	√			
GENERAL	OUTLANDER(G F#)	CORNER SENSOR/BACK SENSOR	√	√	√	√			
GENERAL	OUTLANDER(G F#)	OCM	√	√	√	√			

Mitsubishi **V32.00** Diagnostics List (Note: For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
GENERAL	OUTLANDER(G F#)	Power Gate	√	√	√	√			
GENERAL	OUTLANDER-PHEV	ENGINE	√	√	√	√	√	1.Learned value reset 2.Learning 3.OBD test results (Mode \$06) 4.In-use performance tracking(ENH) 5.In-use performance tracking(OBD) 6.Ethanol forced learning mode 7.Timing chain maintenance	1.READINESS TEST 2.CODING
GENERAL	OUTLANDER-PHEV	ABS	√	√	√	√			
GENERAL	OUTLANDER-PHEV	AC	√	√	√	√			
GENERAL	OUTLANDER-PHEV	SRS	√	√	√	√			
GENERAL	OUTLANDER-PHEV	METER	√	√	√	√	√	1.Service reminder 2.Turn-signal sound customization 3.Test	
GENERAL	OUTLANDER-PHEV	ETACS	√	√	√	√			
GENERAL	OUTLANDER-PHEV	IMMO	√	√	√	√	√	1.Comm.Test 2.KOS key registration	CODING

Mitsubishi V32.00Diagnostics List(Note:For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
GENERAL	OUTLANDER-PHEV	4WS/Electric Power Steering	√	√	√	√			
GENERAL	OUTLANDER-PHEV	SAS	√	√	√	√			
GENERAL	OUTLANDER-PHEV	LIN	√	√	√	√			
GENERAL	OUTLANDER-PHEV	BMU	√	√	√	√			
GENERAL	OUTLANDER-PHEV	EV/MiEV Remote System	√	√	√	√			
GENERAL	OUTLANDER-PHEV	OSS	√	√	√	√			
GENERAL	OUTLANDER-PHEV	AND	√	√	√	√			
GENERAL	OUTLANDER-PHEV	ACC/FCM	√	√	√	√		1.Reset 2.Learning	
GENERAL	OUTLANDER-PHEV	AUDIO	√	√	√	√			
GENERAL	OUTLANDER-PHEV	CORNER SENSOR/BACK SENSOR	√	√	√	√			
GENERAL	OUTLANDER-PHEV	Compressor	√	√	√	√			

Mitsubishi **V32.00** Diagnostics List (Note: For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
GENERAL	OUTLANDER-PHEV	F-MCU	√	√	√	√			
GENERAL	OUTLANDER-PHEV	GCU	√	√	√	√	√		
GENERAL	OUTLANDER-PHEV	Lane Keep	√	√	√	√	√	1.Reset 2.Learning	
GENERAL	OUTLANDER-PHEV	OBC	√	√	√	√			
GENERAL	OUTLANDER-PHEV	P LOCK	√	√	√	√			
GENERAL	OUTLANDER-PHEV	Power Gate	√	√	√	√			
GENERAL	OUTLANDER-PHEV	PHEV	√	√	√	√	√	1.Test 2.Initialization	CODING
GENERAL	OUTLANDER-PHEV	R-MCU	√	√	√	√			CODING
GENERAL	OUTLANDER-PHEV	CMU	√			√			
GENERAL	PAJERO/MONTERO(V6#,V7#)	ENGINE	√	√	√	√	√		
GENERAL	PAJERO/MONTERO(V6#,V7#)	AT	√	√	√	√	√		
GENERAL	PAJERO/MONTERO(V6#,V7#)	ABS	√	√	√	√	√		

Mitsubishi **V32.00** Diagnostics List (Note: For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
GENERAL	PAJERO/MONTERO(V6#,V7#)	SRS	√	√	√	√	√		
GENERAL	PAJERO/MONTERO(V6#,V7#)	SWS	√	√	√	√	√		
GENERAL	PAJERO/MONTERO(V6#,V7#)	AC	√	√	√	√	√		
GENERAL	PAJERO/MONTERO(V6#,V7#)	TCL/STABILITY CONTROL	√	√	√	√	√		
GENERAL	PAJERO/MONTERO(V6#,V7#)	SS4II	√	√	√	√	√		
GENERAL	PAJERO/MONTERO(V6#,V7#)	HBB	√	√	√	√	√		
GENERAL	PAJERO/MONTERO(V6#,V7#)	IMMO	√	√	√	√	√	1.Change password(*) 2.Key registration (bar code number)(*) 3.Key&KOS (Keyless Operation System) key registration (*)	
GENERAL	PAJERO/MONTERO(V6#,V7#)	AUTO CRUISE	√	√	√	√			
GENERAL	PAJERO/MONTERO(V8#,V9#)	ENGINE	√	√	√	√	√	1.Learn valued Reset(*) 2.Initialize 3.Injector ID Writing(Exchanging Injector) 4.Injector ID Readout	1.READINESS TEST 2.CODING

Mitsubishi **V32.00** Diagnostics List (Note: For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
GENERAL	PAJERO/MONTERO(V8#,V9#)	AT	√	√	√	√	√	1.Learn value test 2.Test	
GENERAL	PAJERO/MONTERO(V8#,V9#)	ABS	√	√	√	√	√		
GENERAL	PAJERO/MONTERO(V8#,V9#)	SRS	√	√	√	√	√		
GENERAL	PAJERO/MONTERO(V8#,V9#)	SWS	√	√	√	√	√		
GENERAL	PAJERO/MONTERO(V8#,V9#)	AC	√	√	√	√	√		
GENERAL	PAJERO/MONTERO(V8#,V9#)	METER	√	√	√	√	√	1.Service reminder	
GENERAL	PAJERO/MONTERO(V8#,V9#)	ETACS	√	√	√	√	√		
GENERAL	PAJERO/MONTERO(V8#,V9#)	IMMO	√	√	√	√	√	1.Change password(*) 2.Key registration 3.ENGINE KEY CODE registration&VIN WRITING	1.CODING
GENERAL	PAJERO/MONTERO(V8#,V9#)	AUTO CRUISE	√	√	√	√			
GENERAL	PAJERO/MONTERO(V8#,V9#)	SS4II	√	√	√	√	√		
GENERAL	PAJERO/MONTERO(V8#,V9#)	HBB	√	√	√		√		

Mitsubishi V32.00Diagnostics List(Note:For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
GENERAL	PAJERO SPORT/MONTERO SPORT(K8#,K9#)	ETACS	√	√	√	√	√		
GENERAL	PAJERO SPORT/MONTERO SPORT(K8#,K9#)	AT	√	√	√	√	√		
GENERAL	PAJERO SPORT/MONTERO SPORT(K8#,K9#)	AUTO CRUISE	√	√	√	√			
GENERAL	PAJERO SPORT/MONTERO SPORT(K8#,K9#)	AC	√	√	√	√	√		

Mitsubishi V32.00Diagnostics List(Note:For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
GENERAL	PAJERO/MONTERO(V6#,V7#)	AT	√	√	√	√	√		
GENERAL	PAJERO/MONTERO(V6#,V7#)	ABS	√	√	√	√	√		
GENERAL	PAJERO/MONTERO(V6#,V7#)	SRS	√	√	√	√	√		
GENERAL	PAJERO/MONTERO(V6#,V7#)	SWS	√	√	√	√	√		
GENERAL	PAJERO/MONTERO(V6#,V7#)	AC	√	√	√	√	√		
GENERAL	PAJERO/MONTERO(V6#,V7#)	TCL/STABILITY CONTROL	√	√	√	√	√		
GENERAL	PAJERO/MONTERO(V6#,V7#)	SS4II	√	√	√	√	√		
GENERAL	PAJERO/MONTERO(V6#,V7#)	HBB	√	√	√	√	√		
GENERAL	PAJERO/MONTERO(V6#,V7#)	IMMO	√	√	√	√	√		
GENERAL	PAJERO/MONTERO(V6#,V7#)	AUTO CRUISE	√	√	√	√			

Mitsubishi **V32.00** Diagnostics List (Note: For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
GENERAL	PAJERO/MONTERO(V8#,V9#)	AC		√	√	√	√		
GENERAL	PAJERO/MONTERO(V8#,V9#)	METER	√	√	√	√	√	1.Service reminder	
GENERAL	PAJERO/MONTERO(V8#,V9#)	ETACS	√	√	√	√	√		
GENERAL	PAJERO/MONTERO(V8#,V9#)	IMMO	√	√	√	√	√	1.Change password 2.Key registration 3.ENGINE KEY CODE registration&VIN WRITING	1.CODING
GENERAL	PAJERO/MONTERO(V8#,V9#)	AUTO CRUISE	√	√	√	√			
GENERAL	PAJERO/MONTERO(V8#,V9#)	SS4II	√	√	√	√	√		
GENERAL	PAJERO/MONTERO(V8#,V9#)	HBB	√	√	√		√		
GENERAL	PAJERO/MONTERO(V8#,V9#)	DISPLAY	√	√	√				
GENERAL	PAJERO/MONTERO(V8#,V9#)	LIN	√	√	√	√		Rain sensor adaptation	
GENERAL	PAJERO/MONTERO(V8#,V9#)	CAN/LIN/SWS CONVERTER	√	√	√	√		1.Customization 2.Customization information 3.Reset	

Mitsubishi **V32.00** Diagnostics List (Note: For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
GENERAL	PAJERO SPORT / NATIVA / MONTERO SPORT / CHALLENGER(KG#,KH#)	ENGINE	√	√	√	√	√	1.Test 2.Learning 3.Initialization 4.Injector ID Writing(Exchanging Injector) 5.Injector ID Readout 6.Learning value reset	
GENERAL	PAJERO SPORT / NATIVA / MONTERO SPORT / CHALLENGER(KG#,KH#)	AT	√	√	√	√	√	1.Test 2.Learning value reset	
GENERAL	PAJERO SPORT / NATIVA / MONTERO SPORT / CHALLENGER(KG#,KH#)	ABS	√	√	√	√	√	Lateral G Sensor Calibration	

Mitsubishi **V32.00** Diagnostics List (Note: For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
GENERAL	PAJERO SPORT / NATIVA / MONTERO SPORT / CHALLENGER(KG#,KH#)	AC	√	√	√	√	√		
GENERAL	PAJERO SPORT / NATIVA / MONTERO SPORT / CHALLENGER(KG#,KH#)	SRS		√	√	√	√		
GENERAL	PAJERO SPORT / NATIVA / MONTERO SPORT / CHALLENGER(KG#,KH#)	AUTO CRUISE	√	√	√	√			
GENERAL	PAJERO SPORT / NATIVA / MONTERO SPORT / CHALLENGER(KG#,KH#)	ETACS	√	√	√	√		1. Customization 2. Customization information 3. Customization Reset 4. Keyless ID registration 5. Keyless reception check	

Mitsubishi V32.00Diagnostics List(Note:For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
GENERAL	PAJERO SPORT / NATIVA / MONTERO SPORT / CHALLENGER(KG#,KH#)	DISPLAY	√	√	√				
GENERAL	PAJERO SPORT / NATIVA / MONTERO SPORT / CHALLENGER(KG#,KH#)	SAS	√	√	√			SAS Calibration	
GENERAL	PAJERO SPORT / NATIVA / MONTERO SPORT / CHALLENGER(KG#,KH#)	LIN	√	√	√	√			

Mitsubishi **V32.00** Diagnostics List (Note: For reference only)

District	Vehicle	System	Functions							
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others	
GENERAL	PAJERO SPORT / NATIVA / MONTERO SPORT / CHALLENGER(KG#,KH#)	IMMO	√	√	√	√			1.Change password 2.Key registration (bar code number) 3.Key registration (using key) 4.ENGINE KEY CODE registration&VIN WRITING 5.Key Code agreement	1.CODING
GENERAL	PAJERO IO / PAJERO TR4	ENGINE	√	√	√	√	√			
GENERAL	PAJERO IO / PAJERO TR4	AT	√	√	√	√	√			
GENERAL	PAJERO IO / PAJERO TR4	ABS	√	√	√	√	√			
GENERAL	PAJERO IO / PAJERO TR4	SRS	√	√	√	√	√			
GENERAL	PAJERO IO / PAJERO TR4	SWS	√	√	√	√	√			
GENERAL	TRITON / L200 / STRADA (KA#,KB#,KC#,KD#)	ENGINE	√	√	√	√	√		1.Initialization 2.Test 3.Learning 4.Injector ID Writing(Exchanging Injector) 5.Injector ID Readout 6.Learning value reset	1.READINESS TEST 2.CODING

Mitsubishi **V32.00** Diagnostics List (Note: For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
GENERAL	TRITON / L200 / STRADA (KA#,KB#,KC#,KD#)	ETACS	√	√	√	√		1.Customization 2.Customization information 3.Customization Reset 4.Keyless ID registration(*) 5.Keyless reception check(*)	1.CODING
GENERAL	TRITON / L200 / STRADA (KA#,KB#,KC#,KD#)	ABS	√	√	√	√	√		
GENERAL	TRITON / L200 / STRADA (KA#,KB#,KC#,KD#)	SRS		√	√	√	√		
GENERAL	TRITON / L200 / STRADA (KA#,KB#,KC#,KD#)	AT	√	√	√	√	√	1.Learn Value Reset 2.Test	
GENERAL	TRITON / L200 / STRADA (KA#,KB#,KC#,KD#)	DISPLAY	√	√	√				

Mitsubishi **V32.00** Diagnostics List (Note: For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
GENERAL	ZINGER/FUZION	ENGINE	√	√	√	√	√	1.Initialization 2.Test 3.Learning 4.Injector ID Writing(Exchanging Injector) 5.Injector ID Readout 6.Learning value reset	1.READINESS TEST 2.CODING
GENERAL	ZINGER/FUZION	ETACS	√	√	√	√	√	1.Customization 2.Customization information 3.Customization Reset 4.Keyless ID registration(*) 5.Keyless reception check(*)	1.CODING
GENERAL	ZINGER/FUZION	SRS		√	√	√	√		
GENERAL	ZINGER/FUZION	AT	√	√	√	√	√		
GENERAL	ZINGER/FUZION	ABS	√	√	√	√	√		
GENERAL	ZINGER/FUZION	AC		√	√	√	√		
GENERAL	I	ENGINE	√	√	√	√	√	1.Learned value reset(*)	1.READINESS TEST
GENERAL	I	AT	√	√	√	√	√	1.Learned value reset	
GENERAL	I	ABS	√	√	√	√	√		
GENERAL	I	SRS		√	√	√	√		

Mitsubishi V32.00Diagnostics List(Note:For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
GENERAL	I	AC		√	√	√	√		
GENERAL	I	METER	√	√	√	√	√	1.Service reminder(*)	
GENERAL	I	ETACS	√	√	√	√	√	1.Customization 2.Customization information 3.Customization Reset 4.Keyless ID registration(*) 5.Keyless reception check(*)	1.CODING
GENERAL	I	4WS/Electric Power Steering	√	√	√	√	√		
GENERAL	I	LIN	√	√	√	√			
GENERAL	I	KEYLESS OPERATION	√	√	√	√	√	1.Keyless Operation System key registration 2.Steering lock unit registration 3.Comm.Test 4.KOS Customization	
GENERAL	I-MIEV	ABS	√	√	√	√	√	Emission gas mode	
GENERAL	I-MIEV	SRS		√	√	√	√		
GENERAL	I-MIEV	AC		√	√	√	√		
GENERAL	I-MIEV	METER	√	√	√	√	√	1.Service reminder 2.Test	

Mitsubishi V32.00Diagnostics List(Note:For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
GENERAL	I-MIEV	ETACS	√	√	√	√		1.Customization 2.Customization information 3.Customization Reset 4.Keyless ID registration(*) 5.Keyless reception check(*)	1.CODING
GENERAL	I-MIEV	4WS/Electric Power Steering	√	√	√	√	√		
GENERAL	I-MIEV	STEERING ANGLE SENSOR	√	√	√			1.SAS calibration	
GENERAL	I-MIEV	IMMO	√	√	√	√		1.Key registration (key used) 2.Key registration (bar code number) 3.ENG key code&Chassis No.registration 4.Change password 5.Key Code agreement	1.CODING
GENERAL	I-MIEV	LIN	√	√	√	√			
GENERAL	I-MIEV	KEYLESS OPERATION	√	√	√	√	√	1.Keyless Operation System key registration 2.Steering lock unit registration 3.Comm.Test 4.KOS Customization	
GENERAL	I-MIEV	EV-ECU	√	√	√	√	√	1.Initialization	

Mitsubishi **V32.00** Diagnostics List (Note: For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
GENERAL	I-MIEV	BMU	√	√	√	√	√	1.Test 2.Reset 3.Write learned value(Changed ECU) 4.Cell voltage smoothing 5.CMU ID numbering 6.Battery capacity measure(Ready) 7.Battery capacity measure(Action) 8.Battery auto capacity measured	
GENERAL	I-MIEV	COMP&HTR	√	√	√	√	√	1.Compressor drive history reset	
GENERAL	I-MIEV	MCU	√	√	√	√	√	Initial Phase Position Of Motor	
GENERAL	I-MIEV	CMU	√			√		1.Reset	
GENERAL	I-MIEV	MiEV Remote System	√	√	√	√	√	Test	
GENERAL	ATTRAGE / MIRAGE G4 / MIRAGE (A1#)	ENGINE	√	√	√	√	√	1.Learned value reset 2.OBD test results (Mode \$06) 3.In-use performance tracking(ENH) 4.In-use performance tracking(OBD) 5.Timing chain maintenance	1.READINESS TEST 2.CODING

Mitsubishi **V32.00** Diagnostics List (Note: For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
GENERAL	ATTRAGE / MIRAGE G4 / MIRAGE (A1#)	AT	√	√	√	√		1.Emission gas mode 2.CVT oil degradation level 3.Sensor calibration 4.Electronic oil pump air bleeding 5.Reset	
GENERAL	ATTRAGE / MIRAGE G4 / MIRAGE (A1#)	ABS	√	√	√	√	√		
GENERAL	ATTRAGE / MIRAGE G4 / MIRAGE (A1#)	SRS	√	√	√	√			1.CODING
GENERAL	ATTRAGE / MIRAGE G4 / MIRAGE (A1#)	AC	√	√	√	√			
GENERAL	ATTRAGE / MIRAGE G4 / MIRAGE (A1#)	IMMO	√	√	√	√		1.Change Code 2.Keyless ID Registration 3.Keyless Reception Check 4.Key Registration 5.Key registration (bar code number) 6.ENG. Key code Reg. 7.ENG KEY CODE & Chassis No/VIN Reg	1.CODING

Mitsubishi **V32.00** Diagnostics List (Note: For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
GENERAL	ATTRAGE / MIRAGE G4 / MIRAGE (A1#)	METER	√	√	√	√	√	1.Service reminder 2.Turn-signal sound customization 3.test	
GENERAL	ATTRAGE / MIRAGE G4 / MIRAGE (A1#)	ETACS	√	√	√	√		1.Customized 2.Customized information 3.Custom reset	1.CODING
GENERAL	ATTRAGE / MIRAGE G4 / MIRAGE (A1#)	4WS/Electric Power Steering	√	√	√	√	√		
GENERAL	ATTRAGE / MIRAGE G4 / MIRAGE (A1#)	SAS	√	√	√			1.SAS calibration	
GENERAL	ATTRAGE / MIRAGE G4 / MIRAGE (A1#)	LIN	√	√	√	√		1.Rain Sensor Adaptation	
GENERAL	ATTRAGE / MIRAGE G4 / MIRAGE (A1#)	AFS/ACL/Levelin g	√	√	√	√			
GENERAL	ATTRAGE / MIRAGE G4 / MIRAGE (A1#)	OSS	√	√	√	√	√	1. Forced power supply output 2.Forced power supply output(stop)	1.CODING

Mitsubishi **V32.00** Diagnostics List (Note: For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
GENERAL	MIRAGE / SPACE STAR (AO#)	ENGINE	√	√	√	√	√	1.Learned value reset 2.OBD test results (Mode \$06) 3.In-use performance tracking(ENH) 4.In-use performance tracking(OBD) 5.Timing chain maintenance	1.READINESS TEST 2.CODING
GENERAL	MIRAGE / SPACE STAR (AO#)	AT	√	√	√	√		1.Emission gas mode 2.CVT oil degradation level 3.Sensor calibration 4.Electronic oil pump air bleeding 5.Reset	
GENERAL	MIRAGE / SPACE STAR (AO#)	ABS	√	√	√	√	√		
GENERAL	MIRAGE / SPACE STAR (AO#)	SRS	√	√	√	√			1.CODING
GENERAL	MIRAGE / SPACE STAR (AO#)	AC	√	√	√	√			

Mitsubishi **V32.00** Diagnostics List (Note: For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
GENERAL	MIRAGE / SPACE STAR (A0#)	IMMO	√	√	√	√		1.Change Code 2.Keyless ID Registration 3.Keyless Reception Check 4.Key Registration 5.Key registration (bar code number) 6.ENG. Key code Reg. 7.ENG KEY CODE & Chassis No/VIN Reg	1.CODING
GENERAL	MIRAGE / SPACE STAR (A0#)	METER	√	√	√	√	√	1.Service reminder 2.Test	
GENERAL	MIRAGE / SPACE STAR (A0#)	ETACS	√	√	√	√		1.Customized 2.Customized information 3.Custom reset	1.CODING
GENERAL	MIRAGE / SPACE STAR (A0#)	4WS/Electric Power Steering	√	√	√	√	√		
GENERAL	MIRAGE / SPACE STAR (A0#)	SAS	√	√	√			1.SAS calibration	

Mitsubishi **V32.00** Diagnostics List (Note: For reference only)

District	Vehicle	System	Functions						
			Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
GENERAL	MIRAGE / SPACE STAR (AO#)	LIN	√	√	√	√		1.Rain Sensor Adaptation	
GENERAL	MIRAGE / SPACE STAR (AO#)	OSS	√	√	√	√	√	1. Forced power supply output 2.Forced power supply output(stop)	1.CODING
GENERAL	MIRAGE / SPACE STAR (AO#)	OCM	√	√	√	√			

(*):Tested;

(?):Manual on website(www.x431.com);

Note:The final interpretation of the products belongs to LAUNCH TECH CO.,LTD.