

### Suzuki **V36.61** Diagnostics List (Note: For reference only)

Areas	Vehicle		Type	Engine model	Year	Functions					
						Sys. Info.	Read code	Clear code	Data stream	Actua tion	Special functions
ALTO		ENGINE	HA12S	F6A-NA	98.10 -- 00.12	√	√	√	√		
				F6A-TURBO	99.10 -- 00.12	√	√	√	√		
					98.10 -- 00.12	√	√	√	√		
			HA12V	F6A-NA	99.10 -- 00.12	√	√	√	√		
			HA22S	K6A-TURBO	98.10 -- 00.12	√	√	√	√		
						√	√	√	√		
				K6A-NA-ESS	98.10 -- 01.04	√	√	√	√		
				K6A-TURBO-VVT	98.10 -- 99.10	√	√	√	√		
				K6A-NA	98.10 -- 99.10	√	√	√	√		
				K6A-NA-VVT	99.10 -- 00.12	√	√	√	√		
						√	√	√	√		
			HA23S	K6A-NA	00.12 --	√	√	√	√	√	
				K6A-NA-VVT	00.12 -- 02.04	√	√	√	√	√	
				K6A-NA-ESS	01.04 --	√	√	√	√	√	
				K6A-NA-VVT U-LEV	02.04 -- 03.06	√	√	√	√	√	
						√	√	√	√	√	
			HA23V	K6A-NA	00.12 --	√	√	√	√	√	
				K6A-NA-VVT U-LEV	02.04 -- 03.06	√	√	√	√	√	
						√	√	√	√	√	
			A/T	HA22S(Only 2WD)		99.10 -- 00.12	√	√	√	√	
				HA12V		98.10 -- 99.10	√	√	√	√	
				HA22S		99.05 -- 01.04	√	√	√	√	
				HA23S		01.04 -- 01.06	√	√	√	√	
				HA12V		98.10 -- 00.12	√	√	√	√	
				HA12S		98.10 -- 01.04	√	√	√	√	

## Suzuki **V36.61** Diagnostics List (Note:For reference only)

Areas	Vehicle		Type	Engine model	Year	Functions						
						Sys. Info.	Read code	Clear code	Data stream	Actua tion	Special functions	
		ABS	HA22S		98.10 -- 01.04	√	√	√	√			
			HA23V		00.12 --	√	√	√	√	√		
			HA23S		00.12 --	√	√	√	√	√		
		SRS	HA12V		98.10 -- 00.12	√	√	√	√			
			HA12S		98.10 -- 01.04	√	√	√	√			
			HA22S		98.10 -- 01.04	√	√	√	√			
			HA23V		00.12 --	√	√	√	√			
			HA23S		00.12 --	√	√	√	√			
		JIMNY	ENGINE	JB23W	K6A-TURBO	98.10 -- 99.10	√	√	√	√		
						99.10 -- 02.01	√	√	√	√		
						02.01 --	√	√	√	√	√	
			A/T	JB23W		98.10 --	√	√	√	√		
			ABS	JB23W		98.10 -- 00.04	√	√	√	√		
						00.04 --	√	√	√	√	√	
SRS	JB23W		98.10 --	√	√	√	√					
JIMNY WIDE	ENGINE	JB33W	G13B	98.01 -- 00.04	√	√	√	√				
		JB43W	M13A-NA-VVT	00.04 --	√	√	√	√	√			
	A/T	JB33W		98.01 -- 00.04	√	√	√	√				
		JB43W		00.04 --	√	√	√	√				
	ABS	JB33W		98.01 -- 00.04	√	√	√	√				
		JB43W		00.04 --	√	√	√	√	√			
	SRS	JB33W		98.10 -- 00.04	√	√	√	√				
		JB43W		00.04 --	√	√	√	√				
JIMNY 1300 SIFERRA	ABS	JB32W		96.09 -- 98.01	√	√	√	√				

## Suzuki **V36.61** Diagnostics List (Note: For reference only)

Areas	Vehicle		Type	Engine model	Year	Functions						
						Sys. Info.	Read code	Clear code	Data stream	Actua tion	Special functions	
	<b>JIMNY 660</b>	<b>ABS</b>			96.09 -- 98.10	√	√	√	√			
			<b>ENGINE</b>	HN21S	K6A-TURBO	98.10 -- 01.04	√	√	√	√		
					K6A-TURBO	98.10 -- 01.04(4WD)	√	√	√	√		
					K6A-TURBO	98.10 -- 99.10(2WD)	√	√	√	√		
					K6A-NA	98.10 -- 99.03	√	√	√	√		
					K6A-NA-VVT	00.10 -- 01.04	√	√	√	√	√	
					K6A-TURBO-NS control	99.10 -- 01.04(2WD)	√	√	√	√		
					K6A-NA-VVT	00.10 -- 01.04	√	√	√	√		
				HN11S	F6A-TURBO	98.10 -- 01.04	√	√	√	√		
					F6A-TURBO	98.10 -- 99.10	√	√	√	√		
					F6A-TURBO	99.10 -- 01.04	√	√	√	√		
				HN12S	F6A-TURBO	01.04 -- 01.11	√	√	√	√		
					F6A-TURBO	01.04 -- 01.11	√	√	√	√	√	
					K6A-NA-VVT	01.04 -- 01.11	√	√	√	√	√	
					K6A-NA-VVT	01.04 -- 01.11	√	√	√	√	√	
			K6A-TURBO		01.04 -- 01.11	√	√	√	√	√		
			K6A-TURBO		01.04 -- 01.11(4WD)	√	√	√	√	√		
			K6A-TURBO-NS control		01.04 -- 01.11(2WD)	√	√	√	√	√		
			K6A-NA-VVT		01.11 -- 02.11	√	√	√	√	√		
			K6A-NA-VVT		01.11 -- 02.04	√	√	√	√	√		

## Suzuki **V36.61** Diagnostics List (Note:For reference only)

Areas	Vehicle		Type	Engine model	Year	Functions					
						Sys. Info.	Read code	Clear code	Data stream	Action	Special functions
	Kei		HN22S	K6A-M TURBO	01.11 --	√	√	√	√	√	
				K6A-TURBO	01.11 --	√	√	√	√	√	
				K6A-M TURBO	01.11 -- 03.05	√	√	√	√	√	
				K6A-TURBO	01.11 -- 03.05	√	√	√	√	√	
				K6A-TURBO anti-alip control(2WD)	01.11 -- 03.05	√	√	√	√	√	
				K6A-NA-VVT U-LEV	02.04 -- 03.06(2WD)	√	√	√	√	√	
				K6A-NA-VVT U-LEV (2WD)	02.11 -- (2WD)	√	√	√	√	√	
				K6A-M TURBO	03.05 --	√	√	√	√	√	
				K6A-TURBO	03.05 --	√	√	√	√	√	
				K6A-TURBO anti-alip control(2WD)	03.05 --	√	√	√	√	√	
				K6A-NA-VVT U-LEV (2WD)	03.06 -- (2WD)	√	√	√	√	√	
		A/T	HN11S		99.03 -- 99.10	√	√	√	√		
		ABS	HN11S		00.10 -- 01.04	√	√	√	√	√	
			HN21S		00.10 -- 01.04	√	√	√	√	√	
			HN12S		01.04 --	√	√	√	√	√	
			HN22S		01.04 --	√	√	√	√	√	
			HN11S		98.10 -- 00.10	√	√	√	√		
			HN21S		98.10 -- 00.10	√	√	√	√		
			HN22S		01.04 --	√	√	√	√	√	

## Suzuki **V36.61** Diagnostics List (Note: For reference only)

Areas	Vehicle		Type	Engine model	Year	Functions					
						Sys. Info.	Read code	Clear code	Data stream	Actua tion	Special functions
		<b>SRS</b>	HN11S		98.10 -- 01.04	√	√	√	√		
			HN21S		98.10 -- 01.04	√	√	√	√		
			HN12S		01.04 --	√	√	√	√		
			HN22S		01.04 --	√	√	√	√		
		<b>EMCD</b>	HN22S		02.11 -- 03.03	√	√	√	√		
			MC11S	F6A-NA	98.10 -- 99.10	√	√	√	√		
				F6A-TURBO	98.10 -- 00.12	√	√	√	√		
				F6A-TURBO	98.10 -- 00.12	√	√	√	√		
				F6A-TURBO	99.10 -- 00.12	√	√	√	√		
			MC21S	K6A-NA	98.10 -- 99.10	√	√	√	√		
				K6A-NA-VVT	98.10 -- 00.12	√	√	√	√		
				K6A-TURBO	98.10 -- 00.12	√	√	√	√		
				K6A-TURBO-NS control	98.10 -- 99.10	√	√	√	√		
				K6A-NA-VVT	99.04 -- 00.12	√	√	√	√		
				K6A-TURBO	99.10 -- 00.12	√	√	√	√		
				K6A-TURBO-NS control	99.10 -- 00.12	√	√	√	√		
			MC11S repit	F6A-NA-CNG	99.07 -- 01.03	√	√	√	√		
			MC12S	F6A-TURBO	00.12 -- 01.11	√	√	√	√		
				F6A-TURBO	00.12 -- 01.11	√	√	√	√	√	
				K6A-NA-VVT	00.12 -- 01.11	√	√	√	√	√	
				K6A-NA-VVT	00.12 -- 01.11	√	√	√	√	√	
		K6A-TURBO		00.12 -- 01.11	√	√	√	√	√		
		K6A-TURBO		00.12 -- 01.11(4WD)	√	√	√	√	√		

## Suzuki **V36.61** Diagnostics List (Note:For reference only)

Areas	Vehicle		Type	Engine model	Year	Functions					
						Sys. Info.	Read code	Clear code	Data stream	Actua tion	Special functions
				K6A-TURBO-NS control	00.12 -- 01.11(2WD)	√	√	√	√	√	
				K6A-NA-VVT	01.11 -- (4WD)	√	√	√	√	√	
				K6A-NA-VVT	01.11 -- 02.09(2WD)	√	√	√	√	√	
				K6A-NA-VVT	01.11 -- 03.06(4WD)	√	√	√	√	√	
				K6A-NA-VVT	01.11 -- 02.04(2WD)	√	√	√	√	√	
				K6A-M TURBO	01.11 -- 03.05	√	√	√	√	√	
				K6A-TURBO	01.11 -- 03.05	√	√	√	√	√	
				K6A-TURBO anti-alip control(2WD)	01.11 -- 03.05	√	√	√	√	√	
			MC22S	K6A-NA-VVT U-LEV	02.04 -- (2WD)	√	√	√	√	√	
				K6A-NA-VVT U-LEV	02.04 -- 03.06(2WD)	√	√	√	√	√	
				K6A-NA-VVT U-LEV	02.09 -- (2WD)	√	√	√	√	√	
				K6A-NA(无VVT) U-LEV	02.09 -- (2WD)	√	√	√	√	√	
				K6A-HEVanti-alip control additional locking function	02.09 -- (2WD)	√	√	√	√	√	

## Suzuki **V36.61** Diagnostics List (Note:For reference only)

Areas	Vehicle		Type	Engine model	Year	Functions					
						Sys. Info.	Read code	Clear code	Data stream	Actua tion	Special functions
				K6A-M TURBO	03.05 --	√	√	√	√	√	
				K6A-TURBO	03.05 --	√	√	√	√	√	
				K6A-TURBO anti-alip control(2WD)	03.05 --	√	√	√	√	√	
				K6A-NA-VVT (4WD)	03.06 --	√	√	√	√	√	
				K6A-NA-VVT U-LEV (2WD)	03.06 --	√	√	√	√	√	
			MC22S repit	K6A-NA-VVT-CNG	01.03 -- 03.05	√	√	√	√	√	
				K6A-NA-VVT-CNG	03.06 --	√	√	√	√	√	
			A/T	MC21S		98.10 -- 99.10	√	√	√	√	
						98.10 -- 01.06	√	√	√	√	
			ABS	MC11S		98.10 -- 00.12	√	√	√	√	
		MC21S			98.10 -- 00.12	√	√	√	√		
		MC12S			00.12 --	√	√	√	√	√	
		MC22S			00.12 --	√	√	√	√	√	
		SRS	MC11S		98.10 -- 00.12	√	√	√	√		
			MC21S		98.10 -- 00.12	√	√	√	√		
			MC12S		00.12 --	√	√	√	√		
			MC22S		00.12 --	√	√	√	√		
					01.05 --	√	√	√	√		
			DA52V	F6A-NA	99.01 -- 01.09	√	√	√	√		
				F6A-TURBO	99.01 -- 01.09	√	√	√	√		
				F6A-TURBO	99.01 -- 01.09	√	√	√	√		
				F6A-NA	99.01 -- 01.09	√	√	√	√		

## Suzuki **V36.61** Diagnostics List (Note: For reference only)

Areas	Vehicle		Type	Engine model	Year	Functions					
						Sys. Info.	Read code	Clear code	Data stream	Actuation	Special functions
EVERY	ENGINE	DB52V	F6A-TURBO	99.01 -- 01.09	√	√	√	√			
			F6A-TURBO	99.01 -- 01.09	√	√	√	√			
		DA52V repit	F6A-NA-CNG	99.12 -- 01.11	√	√	√	√			
		DA62V	K6A-NA	01.09 --	√	√	√	√	√		
			K6A-TURBO	01.09 -- (MT)	√	√	√	√	√		
			K6A-TURBO	01.09 -- 03.06(AT)	√	√	√	√	√		
			K6A-TURBO	03.06 -- (AT)	√	√	√	√	√		
		DA62V repit	K6A-NA-CNG	01.11 --	√	√	√	√	√		
			K6A-NA-CNG	01.11 --	√	√	√	√	√		
		A/T	DA52V		99.11 -- 01.09	√	√	√	√		
			DB52V		99.11 -- 01.09	√	√	√	√		
			DA62V		01.09 --	√	√	√	√		
		ABS	DA52V		99.11 -- 01.09	√	√	√	√		
			DB52V		99.11 -- 01.09	√	√	√	√		
	DA62V			01.09 --	√	√	√	√	√		
	SRS	DA52V	two seats airbag and two seats pretensioner	00.05 -- 01.09	√	√	√	√			
		DB52V		00.05 -- 01.09	√	√	√	√			
		DA62V		01.09 --	√	√	√	√			
		DA52V	driver seat airbag or two seats airbag	99.01 -- 00.05	√	√	√	√			
		DB52V		99.01 -- 00.05	√	√	√	√			
	ENGINE	DA52T	F6A-NA	99.01 -- 01.09	√	√	√	√			
			F6A-TURBO	99.01 -- 01.09	√	√	√	√			
					√	√	√	√			
		DB52T	F6A-NA	99.01 -- 01.09	√	√	√	√			
			F6A-TURBO	99.01 -- 01.09	√	√	√	√			



## Suzuki **V36.61** Diagnostics List (Note:For reference only)

Areas	Vehicle		Type	Engine model	Year	Functions					
						Sys. Info.	Read code	Clear code	Data stream	Actua tion	Special functions
						√	√	√	√		
	<b>CARRY</b>		DA62T	K6A-NA	01.09 -- 02.04	√	√	√	√	√	
				K6A-TURBO	01.09 -- 02.05	√	√	√	√	√	
			DA63T	K6A-NA	02.05 --	√	√	√	√	√	
		<b>ABS</b>	DA52T		00.05 -- 01.09	√	√	√	√	√	
			DB52T		00.05 -- 01.09	√	√	√	√	√	
		<b>SRS</b>	DA52T	two seats airbag and two seats pretensioner	00.05 -- 01.09	√	√	√	√		
			DB52T		00.05 -- 01.09	√	√	√	√		
			DA62T		01.09 -- 02.04	√	√	√	√		
			DA63T		02.05 --	√	√	√	√		
			DA52T	driver seat airbag	99.01 -- 00.05	√	√	√	√		
			DB52T	or two seats airbag	99.01 -- 00.05	√	√	√	√		
		<b>EVERY WAGON</b>	<b>ENGINE</b>	DA52W	F6A-TURBO	99.06 -- 01.09(MT)	√	√	√	√	
	F6A-TURBO				99.06 -- 01.09(3AT)	√	√	√	√		
	DA62W			K6A-NA	01.09 --	√	√	√	√	√	
				K6A-TURBO	01.09 -- (MT)	√	√	√	√	√	
				K6A-TURBO	01.09 -- 03.06(AT)	√	√	√	√	√	
			K6A-TURBO	03.06 -- (AT)	√	√	√	√	√		
	<b>A/T</b>		DA52W		99.11 -- 01.09	√	√	√	√		
			DA62W		01.09 --	√	√	√	√	√	
	<b>ABS</b>		DA52W		99.11 -- 01.09	√	√	√	√		
			DA62W		01.09 --	√	√	√	√	√	

## Suzuki **V36.61** Diagnostics List (Note: For reference only)

Areas	Vehicle		Type	Engine model	Year	Functions					
						Sys. Info.	Read code	Clear code	Data stream	Action	Special functions
JAPAN	MR WAGON	ENGINE	MF21S	K6A-NA-VVT	01.12 -- 03.06(4WD)	√	√	√	√	√	
				K6A-NA-VVT	01.12 -- 02.04(2WD)	√	√	√	√	√	
				K6A-M TURBO	01.12 -- 03.05	√	√	√	√	√	
				K6A-TURBO	02.06 -- 03.05	√	√	√	√	√	
				K6A-TURBO anti-alip control(2WD)	02.06 -- 03.05	√	√	√	√	√	
				K6A-NA-VVT U-LEV	02.04 -- (2WD)	√	√	√	√	√	
				K6A-NA-VVT U-LEV	02.04 -- 03.06(2WD)	√	√	√	√	√	
				K6A-M TURBO	03.05 --	√	√	√	√	√	
				K6A-TURBO		√	√	√	√	√	
				K6A-TURBO anti-alip control(2WD)	03.05 --	√	√	√	√	√	
				K6A-NA-VVT	03.06 -- (4WD)	√	√	√	√	√	
				K6A-NA-VVT U-LEV	03.06 -- (2WD)	√	√	√	√	√	
		ABS	MF21S		01.12 --	√	√	√	√	√	
			two seats airbag and two seats pretensioner	01.12 --	√	√	√	√			

## Suzuki **V36.61** Diagnostics List (Note:For reference only)

Areas	Vehicle		Type	Engine model	Year	Functions					
						Sys. Info.	Read code	Clear code	Data stream	Actua tion	Special functions
		<b>SRS</b>	MF21S	two seats airbag and two seats pretensioner and driver seat CRD	01.07 --	√	√	√	√		
<b>LAPIN</b>	<b>ENGINE</b>		HE21S	K6A-NA-VVT	02.01 -- 03.06(4WD)	√	√	√	√	√	
				K6A-NA-VVT	02.01 -- 02.04(2WD)	√	√	√	√	√	
				K6A-M TURBO	02.10 -- 03.05	√	√	√	√	√	
				K6A-NA-VVT U-LEV	02.04 -- (2WD)	√	√	√	√	√	
				K6A-NA-VVT U-LEV	02.04 -- 03.06(2WD)	√	√	√	√	√	
				K6A-M TURBO	03.05 --	√	√	√	√	√	
				K6A-TURBO	03.05 --	√	√	√	√	√	
				K6A-NA-VVT	03.06 -- (4WD)	√	√	√	√	√	
				K6A-NA-VVT U-LEV	03.06 -- (2WD)	√	√	√	√	√	
						<b>ABS</b>	HE21S		02.01 --	√	√
		<b>SRS</b>	HE21S		02.01 --	√	√	√	√		
			FC22C	K6A-NA-VVT U-LEV	03.01 --	√	√	√	√	√	
				K6A-NA(no VVT) U-LEV	03.01 --	√	√	√	√	√	

## Suzuki **V36.61** Diagnostics List (Note:For reference only)

Areas	Vehicle		Type	Engine model	Year	Functions						
						Sys. Info.	Read code	Clear code	Data stream	Actua tion	Special functions	
	TWIN	ENGINE	EC22S	K6A-HEV anti-alip control additional locking function	03.01 --	√	√	√	√	√		
			EC22S改装	K6A-NA-VVT U-LEV	03.01 --	√	√	√	√	√		
				K6A-NA(no VVT) U-LEV	03.01 --	√	√	√	√	√		
				K6A-HEV anti-alip control additional locking function	03.01 --	√	√	√	√	√		
		ABS	EC22S		03.01 --	√	√	√	√	√		
	SRS	EC22S		03.01 --	√	√	√	√				
				TA01W	G16A	96.02 -- 96.10	√	√	√	√		
						96.10 -- 97.11(OnlyMT)	√	√	√	√		
						96.10 -- 97.11(OnlyAT)	√	√	√	√		
						96.02 -- 96.10	√	√	√	√		
96.10 -- 97.11(OnlyMT)						√	√	√	√			
96.10 -- 97.11(OnlyAT)						√	√	√	√			
TA01R				G16A	96.02 -- 96.10	√	√	√	√			
					96.10 -- 97.11(OnlyMT)	√	√	√	√			
					96.10 -- 97.11(OnlyAT)	√	√	√	√			
TD01W	G16A	96.02 -- 96.10	√	√	√	√						
		96.10 -- 97.11(OnlyMT)	√	√	√	√						
		96.10 -- 97.11(OnlyAT)	√	√	√	√						

## Suzuki **V36.61** Diagnostics List (Note: For reference only)

Areas	Vehicle		Type	Engine model	Year	Functions					
						Sys. Info.	Read code	Clear code	Data stream	Action	Special functions
ESCUDO	ENGINE	TA11W	H20A	96.02 -- 96.10(OnlyAT)	√	√	√	√			
				96.02 -- 96.10(OnlyAT)	√	√	√	√			
		TD11W	H20A	96.02 -- 96.10(OnlyAT)	√	√	√	√			
				96.02 -- 96.10(OnlyAT)	√	√	√	√			
		TA51W	J20A	96.10 -- 97.11(OnlyAT)	√	√	√	√			
				96.10 -- 97.11(OnlyAT)	√	√	√	√			
				97.11 -- 00.04	√	√	√	√			
		TD51W	J20A	96.10 -- 97.11(OnlyAT)	√	√	√	√			
				96.10 -- 97.11(OnlyAT)	√	√	√	√			
				97.11 -- 00.04	√	√	√	√			
		TD61W	H25A	96.10 -- 98.03	√	√	√	√			
				98.02 -- 00.04	√	√	√	√			
		TD62W	H25A	98.02 -- 00.04	√	√	√	√			
				00.04 --	√	√	√	√	√		
		TA02W	G16A	97.11 -- 00.04	√	√	√	√			
				00.04 -- 00.12	√	√	√	√	√		
		TD02W	G16A	97.11 -- 00.04	√	√	√	√			
		TD52W	J20A	97.11 -- 00.04	√	√	√	√			

## Suzuki **V36.61** Diagnostics List (Note:For reference only)

Areas	Vehicle		Type	Engine model	Year	Functions					
						Sys. Info.	Read code	Clear code	Data stream	Actua tion	Special functions
			TA52W	J20A	00.12 -- 02.11	√	√	√	√	√	
			TL52W	J20A	00.04 --	√	√	√	√	√	
		A/T	TA01W		96.02 -- 96.10	√	√	√	√		
			TA01R		96.02 -- 96.10	√	√	√	√		
			TD01W		96.02 -- 96.10	√	√	√	√		
			TA02W		00.04 -- 00.12	√	√	√	√		
			TA52W		00.12 -- 02.11	√	√	√	√		
			TL52W		00.04 --	√	√	√	√		
		ABS	TA02W		00.04 -- 00.12	√	√	√	√	√	
			TA52W		00.12 -- 02.11	√	√	√	√	√	
			TL52W		00.04 --	√	√	√	√	√	
			TD62W		00.04 --	√	√	√	√	√	
		SRS	all vehicles		97.11 -- 02.11	√	√	√	√		
			TL52W		02.11 --	√	√	√	√		
			TD62W		02.11 --	√	√	√	√		
		A/C	TL52W		02.11 --	√	√	√	√		
			TD62W		02.11 --	√	√	√	√		
		BCM	TL52W		02.11 -- 03.06	√	√	√	√	√	
			TD62W		02.11 -- 03.06	√	√	√	√	√	
			TL52W		03.06 --	√	√	√	√	√	
			TD62W		03.06 --	√	√	√	√	√	
	<b>X-90</b>	<b>ENGINE</b>	LB11S	G16A	95.10 -- 97.11	√	√	√	√		
					96.02 -- 97.05	√	√	√	√		
			GA11S	G13B	97.05 -- 98.05( Only MT,CVT)	√	√	√	√		

## Suzuki **V36.61** Diagnostics List (Note:For reference only)

Areas	Vehicle		Type	Engine model	Year	Functions					
						Sys. Info.	Read code	Clear code	Data stream	Actua tion	Special functions
					97.05 -- 98.05(3AT)	√	√	√	√		
		<b>ENGINE</b>	GC21S	G15A	96.02 -- 97.05	√	√	√	√		
			GC21W	G15A	96.02 -- 97.05	√	√	√	√		
			GD31S	G16A	96.02 -- 97.05	√	√	√	√		
			GD31W	G16A	96.02 -- 97.05	√	√	√	√		
			GB31S	G16A	96.02 -- 97.05	√	√	√	√		
			GC41W	J18A	96.02 -- 02.07	√	√	√	√		
			GA21S	G15A	97.05 -- 98.05	√	√	√	√		
			GB21S	G15A	97.05 -- 98.05	√	√	√	√		
			GC21S	G16A	97.05 -- 98.05	√	√	√	√		
			GD21S	G16A	97.05 -- 98.05	√	√	√	√		
		<b>A/T</b>	GB31S		96.02 -- 98.05	√	√	√	√		
			GC21S		96.02 -- 98.05	√	√	√	√		
			GD31S		96.02 -- 98.05	√	√	√	√		
			GC21W		96.02 -- 98.05	√	√	√	√		
			GD31W		96.02 -- 98.05	√	√	√	√		
			GC41W		96.02 -- 02.07	√	√	√	√		
			GA11S		96.10 -- 99.06	√	√	√	√		
				98.05 -- 99.06	√	√	√	√			
		<b>ABS</b>			96.02 -- 97.05	√	√	√	√		
					97.05 -- 00.04	√	√	√	√		
		<b>EPS</b>	GA11S		97.05 -- 00.04	√	√	√	√		
		<b>SRS</b>	all vehicles		97.05 -- 02.07	√	√	√	√		
			GA11S	G13B	98.05 -- 00.04( only MT CVT)	√	√	√	√		

## Suzuki **V36.61** Diagnostics List (Note: For reference only)

Areas	Vehicle		Type	Engine model	Year	Functions						
						Sys. Info.	Read code	Clear code	Data stream	Action	Special functions	
CULTUS	ENGINE				98.05 -- 00.04	√	√	√	√			
		GC21S	G15A		98.05 -- 01.10	√	√	√	√			
		GC21W	G15A		98.05 -- 02.07	√	√	√	√			
		GD31S	G16A		98.05 -- 01.10	√	√	√	√			
		GB31S	G16A		98.05 -- 01.10	√	√	√	√			
		GD31W	G16A		98.05 -- 02.07	√	√	√	√			
		A/T	GC21S			98.05 -- 01.10	√	√	√	√		
			GD31S			98.05 -- 01.10	√	√	√	√		
			GB31S			98.05 -- 01.10	√	√	√	√		
			GC21W			98.05 -- 02.07	√	√	√	√		
	GD31W				98.05 -- 02.07	√	√	√	√			
	ABS	GC21S			00.04 -- 01.10	√	√	√	√	√		
		GC21W			00.04 -- 02.07	√	√	√	√	√		
		GC41W			00.04 -- 02.07	√	√	√	√	√		
		GD31S			00.04 -- 01.10	√	√	√	√	√		
		GD31W			00.04 -- 02.07	√	√	√	√	√		
	WAGON R WIDE	ENGINE	MA61S	K10A-NA TURBO		97.02 -- 99.05	√	√	√	√		
			MB61S	K10A-NA TURBO		97.02 -- 99.05	√	√	√	√		
		A/T	MA61S			97.02 -- 99.05	√	√	√	√		
						98.08 -- 99.05	√	√	√	√		
MB61S					97.02 -- 99.05	√	√	√	√			
					98.08 -- 99.05	√	√	√	√			
ABS		MA61S			97.02 -- 99.05	√	√	√	√			
		MB61S			97.02 -- 99.05	√	√	√	√			
SRS		MA61S			97.02 -- 99.06	√	√	√	√			
		MB61S			97.02 -- 99.06	√	√	√	√			



## Suzuki **V36.61** Diagnostics List (Note:For reference only)

Areas	Vehicle		Type	Engine model	Year	Functions					
						Sys. Info.	Read code	Clear code	Data stream	Action	Special functions
	EVERY <sup>+</sup>	ENGINE	DA32W	G13B	99.06 -- 01.05	√	√	√	√		
		A/T	DA32W		99.06 -- 01.05	√	√	√	√		
		ABS	DA32W`		99.06 -- 01.05	√	√	√	√		
		EPS	DA32W		99.06 -- 01.05	√	√	√	√		
		SRS	DA32W		99.06 -- 01.05	√	√	√	√		
	SWIFT	ENGINE	HT51S	M13A-NA-VVT	00.01 -- 03.06	√	√	√	√	√	
					00.01 -- (4WD AT)	√	√	√	√	√	
			M13A-NA-VVT U-LEV	03.06 -- (4WD,AT)	√	√	√	√	√		
		HT81S	M15A-NA-VVT	03.06 --	√	√	√	√	√		
		A/T	HT51S		00.01 -- 01.04	√	√	√	√		
					01.04 --	√	√	√	√		
		ABS	HT51S		00.01 --	√	√	√	√	√	
		EPS	HT51S		00.01 --	√	√	√	√		
		SRS	HT51S		00.01 --	√	√	√	√		
	WAGON R SOLIO	ENGINE	MA34S	M13A-NA-VVT	00.11 --	√	√	√	√	√	
			MA64S	K10A-NA-VVT	00.11 -- 02.10	√	√	√	√	√	
		A/T	MA64S		00.11 -- 02.10	√	√	√	√		
			MA34S		00.11 --	√	√	√	√		
		ABS	MA34S		00.11 --	√	√	√	√	√	
			MA64S		00.11 -- 02.10	√	√	√	√	√	
EPS		MA34S		00.11 --	√	√	√	√			
		MA64S		00.11 -- 02.10	√	√	√	√			
SRS		MA34S		00.11 --	√	√	√	√			
	MA64S		00.11 -- 02.10	√	√	√	√				

## Suzuki **V36.61** Diagnostics List (Note: For reference only)

Areas	Vehicle		Type	Engine model	Year	Functions					
						Sys. Info.	Read code	Clear code	Data stream	Actua tion	Special functions
GRAND ESCUDO	ENGINE	TX92W	H27A	00.12 -- 03.06	√	√	√	√	√		
			H27A U-LEV	03.06 --	√	√	√	√	√		
		A/T	TX92W		03.06 --	√	√	√	√		
		ABS	TX92W		00.12 --	√	√	√	√	√	
		SRS	TX92W		00.12 --	√	√	√	√		
		A/C	TX92W		02.11 --	√	√	√	√		
		BCM	TX92W		02.11 -- 03.06	√	√	√	√	√	
				03.06 --	√	√	√	√			
	4WD	TX92W		03.06 --	√	√	√	√			
	AERIO	ENGINE	RB21S	M15A-NA-VVT	01.01 --	√	√	√	√	√	
			RA21S	M15A-NA-VVT	01.11 --	√	√	√	√	√	
			RC51S	M18A-NA-VVT	03.01 --	√	√	√	√	√	
			RD51S	M18A-NA-VVT	03.01 --	√	√	√	√	√	
		A/T	RA21S		01.11 --	√	√	√	√		
RB21S				01.11 --	√	√	√	√			
				01.01 -- 01.11	√	√	√	√			
RC51S				03.01 --	√	√	√	√			
RD51S			03.01 --	√	√	√	√				
ABS		RB21S		01.01 --	√	√	√	√	√		
		RA21S		01.11 --	√	√	√	√	√		
		RC51S		03.01 --	√	√	√	√	√		
		RD51S		03.01 --	√	√	√	√	√		
SRS		RB21S		01.01 --	√	√	√	√			
		RA21S		01.11 --	√	√	√	√			
		RC51S		03.01 --	√	√	√	√			
		RD51S		03.01 --	√	√	√	√			

## Suzuki **V36.61** Diagnostics List (Note: For reference only)

Areas	Vehicle		Type	Engine model	Year	Functions					
						Sys. Info.	Read code	Clear code	Data stream	Actua tion	Special functions
		A/C	RB21S		02.10 --	√	√	√	√		
			RA21S		02.10 --	√	√	√	√		
			RC51S		03.01 --	√	√	√	√		
			RD51S		03.01 --	√	√	√	√		
EVERY LANDY	ENGINE	DA32W	G13B	01.05 --	√	√	√	√	√		
		A/T	DA32W	01.05 --	√	√	√	√			
		ABS	DA32W	01.05 --	√	√	√	√	√		
		EPS	DA32W	01.05 --	√	√	√	√			
		SRS	DA32W	01.05 --	√	√	√	√			
CHEVROLE T CRUZE	ENGINE	HR51S	M13A-NA-VVT	01.11 --	√	√	√	√	√		
		HR81S	M15A-NA-VVT	02.12 --	√	√	√	√	√		
	A/T	HR51S		01.11 --	√	√	√	√			
		HR81S		02.12 --	√	√	√	√			
	ABS	HR51S		01.11 --	√	√	√	√	√		
		HR81S		02.12 --	√	√	√	√	√		
	EPS	HR51S		01.11 --	√	√	√	√			
		HR81S		02.12 --	√	√	√	√			
	SRS	HR51S		01.11 --	√	√	√	√			
		HR81S		02.12 --	√	√	√	√			
EMCD	HR51S		01.11 --	√	√	√	√				
WAGON R <sup>+</sup>	ENGINE	MA63S	K10A-NA-VVT	99.05 -- 00.11	√	√	√	√			
			K10A-TURBO-VVT	99.05 -- 00.11	√	√	√	√			
	A/T	MA63S		99.05 -- 00.11	√	√	√	√			
	ABS	MA63S		99.05 -- 00.11	√	√	√	√			
	EPS	MA63S		99.05 -- 00.11	√	√	√	√			
	SRS	MA63S		99.05 -- 00.11	√	√	√	√			



## Suzuki **V36.61** Diagnostics List (Note:For reference only)

Areas	Vehicle		Type	Engine model	Year	Functions						
						Sys. Info.	Read code	Clear code	Data stream	Actua tion	Special functions	
OTHER THAN NORTH AMERI CA	ALTO	SRS					√	√	√			
	JIMNY	ENGINE					√	√	√	√	ECM Setting	
		AT						√	√	√		
		ABS						√	√	√	√	
	MR WAGON	ENGINE									√	
		ABS						√	√	√	√	
		SRS						√	√	√		
	EVERY+/LA NDY	ENGINE						√	√	√		
		AT						√	√	√		
		ABS						√	√	√		
	CARRY	ENGINE						√	√	√		
		AT						√	√	√		
		ABS						√	√	√		
	SX4	ENGINE						√	√	√	√	1 ECM Setting 2 Reset oil pressure
		AT						√	√	√		
		ABS						√	√	√	√	
		SRS						√	√	√		
			esp					√	√	√	√	1 Sensor calibration
			ENGINE					√	√	√	√	1 Readiness Test

## Suzuki **V36.61** Diagnostics List (Note:For reference only)

Areas	Vehicle		Type	Engine model	Year	Functions						
						Sys. Info.	Read code	Clear code	Data stream	Actua tion	Special functions	
	GRAND VITARA(JB Series)	AT					√	√	√	√		
		SRS					√	√	√			
		BCM					√	√		√		
		HVAC					√	√				
		ABS					√	√	√	√		
		4WD					√	√				
		ESP						√	√		√	1 Sensor calibration 2 ESP Function setting
	SAMURAI	ENGINE						√	√	√		
		ABS						√	√	√		
	LIANA(AER IO)	ENGINE						√	√	√		
		AT						√	√	√		
		ABS						√	√	√		
		SRS						√	√	√		
		HVAC						√	√	√		
	GRAND VITARA/XL -7	ENGINE						√	√	√	√	Readiness
		AT						√	√	√		
		SRS						√	√	√		
		BCM						√	√	√	√	
		HVAC						√	√	√		
		ABS						√	√	√	√	
		Immobilizer						√	√			

## Suzuki **V36.61** Diagnostics List (Note:For reference only)

Areas	Vehicle		Type	Engine model	Year	Functions						
						Sys. Info.	Read code	Clear code	Data stream	Actua tion	Special functions	
	Equator -1	ENGINE			2009-2013	√	√	√	√	√		
		AT			2009-2013	√	√	√	√			
		ABS			2009-2013	√	√	√	√	√		
		Airbag			2009-2013		√	√				
		Wheel Alignment			2009-2011					√		
	Equator -2	ENGINE				2009-2013	√	√	√	√	√	
		AT				2009-2013	√	√	√	√		
		ABS				2009-2013	√	√	√	√	√	
		Airbag				2009-2013		√	√			
	Grand Vitara(RWD)-T	ENGINE				2006-2013	√	√	√	√	√	
		AT				2006-2013	√	√	√	√		
		ABS				2006-2013	√	√	√	√	√	
		Airbag				2006-2013	√	√	√	√		
		TPMS				2006-2013		√	√	√		
		HVAC				2006-2013	√	√	√	√		
	Grand Vitara(4WD)-T	ENGINE				2006-2013	√	√	√	√	√	
		AT				2006-2013	√	√	√	√		
		ABS				2006-2013	√	√	√	√	√	
		Airbag				2006-2013	√	√	√	√		
		HVAC				2006-2013	√	√	√	√		
TPMS					2006-2013		√	√	√			
		ENGINE			2010-2013	√	√	√	√	√		
		AT			2010-2013	√	√	√	√			
		ABS			2010-2013		√	√	√	√		
		Airbag			2010-2013	√	√	√	√			

## Suzuki **V36.61** Diagnostics List (Note: For reference only)

Areas	Vehicle		Type	Engine model	Year	Functions						
						Sys. Info.	Read code	Clear code	Data stream	Action	Special functions	
	Kizashi-R	BCM			2010-2013		√	√	√	√		
		EPS			2010-2013		√	√	√			
		FWD			2010-2013		√	√	√			
		HVAC			2010-2013	√	√	√	√			
		TPMS			2010-2013		√	√	√			
	Swift+ - T	ENGINE				2006-2013	√	√	√	√	√	
		AT				2006-2013	√	√	√	√		
		ABS				2006-2013	√	√	√	√	√	
	SX4-Y	ENGINE				2007-2013	√	√	√	√	√	
		AT				2007-2013	√	√	√	√		
		Airbag				2007-2013	√	√	√	√		
		BCM				2007-2013		√	√	√	√	
		FWD				2007-2013		√	√	√		
		TPMS				2007-2013		√	√	√		
	XL-7(FWD)-D	ENGINE				2007-2009		√	√	√	√	
		ABS				2007-2009		√	√	√	√	
		AIRBAG				2007-2009		√	√	√		
		BCM				2007-2009		√	√	√		
	XL-7(4WD)-D	ENGINE				2009		√	√	√	√	
		ABS				2009		√	√	√	√	
		Airbag				2009		√	√	√		
BCM					2009		√	√	√			
TPMS					2009		√	√	√	√		
	ENGINE				2007-2008		√	√	√	√		
	AT				2007-2008		√	√	√			
	ABS				2007-2008		√	√	√	√		



## Suzuki **V36.61** Diagnostics List (Note:For reference only)

Areas	Vehicle		Type	Engine model	Year	Functions						
						Sys. Info.	Read code	Clear code	Data stream	Actua tion	Special functions	
	XL-7(AWD)-D	Airbag			2007-2008		√	√	√			
		BCM			2007-2008		√	√	√			
		HVAC			2007-2008		√	√	√	√		
		PPS			2007-2008		√	√	√			
		TPMS			2007-2008		√	√	√	√		
	Forenza-J	ENGINE				2006-2008		√	√	√	√	
		AT				2006-2008		√	√	√	√	
		ABS				2006-2008		√	√	√		
		TPMS				2007-2008		√	√	√		
	Reno-J	ENGINE				2006-2008		√	√	√	√	
		AT				2006-2008		√	√	√	√	
		ABS				2006-2008		√	√	√		
		TPMS				2007-2008		√	√	√		
	VERONA	ENGINE				2004-2006		√	√	√		
		AT						√	√	√		
		ABS				2004-2006		√	√	√		
		SRS						√	√	√		
		ISU						√	√	√		
		SSPS						√	√			
		TPMS						√	√	√		
SWIFT	ENGINE				1996-2001		√	√				
ESTEEM	ENGINE				1996-2002		√	√				
	AT						√	√				
	AIR BAG						√	√				
	ABS				1996-2002		√	√				

## Suzuki **V36.61** Diagnostics List (Note:For reference only)

Areas	Vehicle		Type	Engine model	Year	Functions						
						Sys. Info.	Read code	Clear code	Data stream	Action	Special functions	
NORTH AMERICA	FORENZA/ RENO	ENGINE			2004-2007		√	√		√	1 TEC Learn of CKP sensor(2004-2005) 2 TEC	
		AT					√	√		√		
		ABS			2004-2007		√	√				
		SRS					√	√				
		TPMS						√	√	√	√	TPMS ID registration with LF tool
		SSPS						√	√			
	X-90	ENGINE			1996-1998		√	√				
	AERIO	ENGINE			2002-2007		√	√				
		AT			2002-2007		√	√				
		SRS			2002-2007		√	√	√	√	System Rezero setting	
		HVAC			2003-2007		√	√				
		ABS			2002-2007		√	√				

## Suzuki **V36.61** Diagnostics List (Note:For reference only)

Areas	Vehicle		Type	Engine model	Year	Functions					
						Sys. Info.	Read code	Clear code	Data stream	Actua tion	Special functions
SWIFT+	ENGINE				2004-2007		√	√		√	1 TEC Learn of CKP sensor(2004-2005) 2 TEC Learn of CKP sensor(2006-2007) 3 MEC Clear(2007 )
	AT				2004-2007		√	√		√	AT learned initialize
	ABS				2004-2007		√	√		√	
	SRS				2004-2007		√	√			
SX4	ENGINE						√	√	√		
	SRS						√	√	√		
	BCM						√	√	√	√	
	HVAC						√	√	√		
	ABS						√	√			
	4WD						√	√	√		
	ESP						√	√	√		

## Suzuki **V36.61** Diagnostics List (Note:For reference only)

Areas	Vehicle		Type	Engine model	Year	Functions					
						Sys. Info.	Read code	Clear code	Data stream	Actua tion	Special functions
GRAND VITARA(JB Series)	ENGINE				2006-2007		√	√	√	√	1.Readiness Test 2 Keyless start registration
	AT						√	√		√	AT learned initialize
	SRS						√	√			
	BCM						√	√		√	
	HVAC						√	√			
	ABS						√	√		√	
	4WD						√	√			
	ESP							√	√		√
	ENGINE				1999-2006		√	√	√	√	1Readiness Test 2 Keyless
	AT				2007-2009	√	√	√	√	√	1.Fast Learn
	SRS				1999-2006		√	√	√	√	System Rezero -----

## Suzuki **V36.61** Diagnostics List (Note: For reference only)

Areas	Vehicle		Type	Engine model	Year	Functions						
						Sys. Info.	Read code	Clear code	Data stream	Action	Special functions	
	XL-7/GRAND VITARA/VITARA	BCM			2003-2007-2009		√	√	√	√		
		HVAC					√	√	√			
		TPMS					√	√	√	√	TPMS ID registration with LF tool	
		ABS				1999-2006		√	√	√		
		4WD						√	√	√	√	
		DRR				2007-2009		√	√	√	√	
		HSM				2007-2009		√	√	√	√	
		IPC				2007-2009		√	√	√	√	1. IPC Setup
		PPS				2007-2009		√	√	√	√	
		TDM				2007-2009	√	√	√	√		
		EBCM				2007-2009		√	√	√	√	
		RFA				2009				√	√	1. Automated Bleed 2. Program Key Fobs
		SIR				2007-2009	√	√	√	√		1. Setup New ROS

## Suzuki **V36.61** Diagnostics List (Note:For reference only)

Areas	Vehicle		Type	Engine model	Year	Functions						
						Sys. Info.	Read code	Clear code	Data stream	Actuation	Special functions	
		RCDLR			2007-2008	√	√	√	√	√	1.Program Key Fobs 2.Tire Type/Pressure Selection 3.TPM Learn Mode	
		RS			2007-2009	√	√	√	√	√	1. Setup New ROS	
		VCS			2008	√	√	√				
	SIDE KICK/SIDE	ENGINE			1996-1998		√	√				
		ABS					√	√				
GST mode		ENGINE		V6 Engine			√	√	√			
				Inline Engine			√	√	√			
				Diesel Engine (Z13DT)				√	√	√		
				Diesel Engine (K9K)				√	√	√		
				Diesel Engine (DV4)				√	√	√		
				Diesel Engine (RHZ/RHW)					√	√	√	

(\*) :Tested;

(?):Manual on website([www.x431.com](http://www.x431.com))

Note:The final interpretation of the products belongs to LAUNCH TECH CO.,LTD.