

Daewoo **V26.92** Diagnostics List (Note:For reference only)

Vehicles	System	Sub System	Sub System	functions						
				System Info.	Read Dtc	Clear Dtc	Data Stream	Actuation	Special Functions	
Lemans/Racer	ENGINE SOHC	1.5 MPI			√	√	√	√		
	ENGINE DOHC	1.5 MPI			√	√	√	√		
Espero	ENGINE SOHC	1.5 MPI(BEFORE 93MY)			√	√	√	√		
		1.5 MPI(AFTER 93MY)			√	√	√	√		
		1.8 MPI			√	√	√	√		
		2.0 MPI			√	√	√	√		
		2.0 TBI			√	√	√	√		
	ENGINE DOHC	1.5 MPI(BEFORE 93MY)				√	√	√	√	
		1.5 MPI(AFTER 93MY)				√	√	√	√	
		1.5 MPFI(BEFORE 93MY)				√	√	√	√	
		1.5 MPFI(AFTER 93MY)				√	√	√	√	
	ATUTOMATIC TRANSAXLE				√	√	√			
ANTI-LOCK BRAKE SYSTEM				√	√	√				
SRS-AIRBAG				√	√					
Prince	ENGINE SOHC	1.8 MPFI			√	√	√	√		
		2.0 MPFI			√	√	√	√		
		LPG			√	√				
		2.0 (rus)			√	√	√	√		
		2.2L MPFI			√	√	√	√		
	ANTI-LOCK BRAKE SYSTEM			√	√	√	√			
Super Salon	ENGINE SOHC	1.8 MPI			√	√	√	√		
		2.0 MPI			√	√	√	√		
	ANTI-LOCK BRAKE SYSTEM			√	√	√	√			
Cielo	ENGINE SOHC	UNLEAD 1.5L			√	√	√	√		
		UNLEAD 1.8L			√	√	√			
	ENGINE DOHC	UNLEAD 1.5L			√	√	√	√		
	AUTOMATIC TRANSAXLE			√	√	√				
	ANTI-LOCK BRAKE SYSTEM			√	√	√				
	SRS-AIRBAG			√	√					
		UNLEAD 1.5L			√	√	√	√		

Daewoo **V26.92** Diagnostics List (Note:For reference only)

Vehicles	System	Sub System	Sub System	functions					
				System Info.	Read Dtc	Clear Dtc	Data Stream	Actuation	Special Functions
Nexia	ENGINE SOHC	UNLEAD 1.8L			√	√	√		
		LEAD 1.5			√	√	√	√	
		1.5(rus)			√	√	√	√	
	ENGINE DOHC	UNLEAD 1.5L			√	√	√	√	
		LEAD 1.5L			√	√	√	√	
	AUTOMATIC TRANSAXLE				√	√	√		
	ANTI-LOCK BRAKE SYSTEM				√	√	√		
SRS-AIRBAG				√	√				
New-Nexia	01. ENGINE CONTROL	01.1.5 SOHC			√	√	√	√	1.CRANK ANGLE TEC LEARN 2.EVAP.LEAK 3.ECU INFORMATION
		02.1.6 SOHC			√	√	√	√	1.EVAP.LEAK 2.ADAPTION RESET
	02. AUTOMATIC TRANSAXLE				√	√	√		
	03. ANTI-LOCK BRAKE SYSTEM				√	√	√		
New Prince	ENGINE SOHC				√	√	√	√	
	ENGINE DOHC				√	√	√	√	
	ANTI-LOCK BRAKE SYSTEM			√	√	√	√		
New-Brougham	ENGINE SOHC				√	√	√	√	
	ENGINE DOHC				√	√	√	√	
	ANTI-LOCK BRAKE SYSTEM			√	√	√	√		
Lanos	ENGINE SOHC	1.3L			√	√	√	√	
		1.5L			√	√	√	√	
	ENGINE DOHC	1.5L			√	√	√	√	
		1.6L			√	√	√	√	
	AUTOMATIC TRANSAXLE				√	√	√		
	ANTI-LOCK BRAKE SYSTEM	01.DELPHI				√	√	√	√
		02.BOSCH				√	√	√	√
SRS-AIRBAG				√	√				

Daewoo **V26.92** Diagnostics List (Note:For reference only)

Vehicles	System	Sub System	Sub System	functions					
				System Info.	Read Dtc	Clear Dtc	Data Stream	Actuation	Special Functions
New-Lanos	01. ENGINE CONTROL	01.1.5 SOHC			√	√	√	√	1.CRANK ANGLE TEC LEARN 2.EVAP.LEAK 3.ECU INFORMATION
	02. AUTOMATIC TRANSAXLE				√	√	√		
	03. ANTI-LOCK BRAKE SYSTEM				√	√	√		
Nubira	ENGINE SOHC	1.5L			√	√	√	√	
	ENGINE DOHC	1.5L			√	√	√	√	
		1.8L			√	√	√	√	
		2.0L			√	√	√	√	
	AUTOMATIC TRANSAXLE				√	√	√		
	ANTI-LOCK BRAKE SYSTEM				√	√	√		
SRS-AIRBAG				√	√	√			
Leganza	ENGINE SOHC	1.8L			√	√	√	√	
		LPG			√	√			
		2.0L			√	√	√	√	
	ENGINE DOHC	1.8L			√	√	√	√	
		2.0L			√	√	√	√	
		2.2L			√	√	√	√	
	LPG				√	√			
	AUTOMATIC TRANSAXLE	LPG			√	√	√		
	ANTI-LOCK BRAKE SYSTEM			√	√	√	√	√	Air Bleed
SRS-AIRBAG				√	√	√			
Matiz/Spark	ENGINE CONTORL	01.0.8L		√	√	√	√	√	ADAPTION RESET
		02.1.0L		√	√	√	√	√	ADAPTION RESET
		03.LEAD			√	√	√		
		Unlead			√	√	√		
	ANTI-LOCK BRAKE SYSTEM				√	√	√	√	
SRS-AIRBAG				√	√				
	ENGINE SOHC	2.0 L			√	√	√	√	
		1.5 L			√	√	√	√	

Daewoo **V26.92** Diagnostics List (Note:For reference only)

Vehicles	System	Sub System	Sub System	functions						
				System Info.	Read Dtc	Clear Dtc	Data Stream	Actuation	Special Functions	
Nubira II	ENGINE DOHC	1.6 L			√	√	√			
		2.0 L			√	√	√	√		
	AUTOMATIC TRANSAXLE				√	√	√			
	ANTI-LOCK BRAKE SYSTEM				√	√	√	√		
	SRS-AIRBAG				√	√	√			
Magnus	ENGINE CONTROL	GASOLINE(L4)			√	√	√	√		
		XK(SIEMENS L6)			√	√	√			
		LPG			√	√				
	AUTOMATIC TRANSAXLE	GASOLINE(~2002MY)				√	√	√	√	
		GASOLINE(2002MY~)				√	√	√	√	
		LPG				√	√	√	√	
	ANTI-LOCK BRAKE SYSTEM				√	√	√	√		
SRS-AIRBAG				√	√					
ISC				√	√	√	√			
Rezzo/Tacuma	ENGINE CONTROL	UNLEADED			√	√	√	√		
		LPG	NIKKI LPG ENGINE			√	√	√		
			LPG			√	√			
		GASOLINE BEFORE 2005	01.SOHC			√	√	√	√	
			02.1.6 DOHC			√	√	√	√	ADAPTION RESET WHEEL ADAPTATION VALUE
			03.1.8DOHC			√	√	√	√	ADAPTION RESET WHEEL ADAPTATION VALUE
	GASOLINE AFTER 2005	01.SOHC			√	√	√	√		
		02.1.6 DOHC			√	√	√	√	ADAPTION RESET	
		03.1.8DOHC			√	√	√	√	ADAPTION RESET	
		04.2.0 DOHC			√	√	√	√		
	AUTOMATIC TRANSAXLE	GASOLINE				√	√	√	√	
		LPG				√	√	√	√	
		4HP16				√	√	√	√	
SAISIN					√	√	√	√		

Daewoo **V26.92** Diagnostics List (Note:For reference only)

Vehicles	System	Sub System	Sub System	functions					
				System Info.	Read Dtc	Clear Dtc	Data Stream	Actuation	Special Functions
	ANTI-LOCK BRAKE SYSTEM				√	√	√	√	HCU AIRBREEDING
	SRS-AIRBAG				√	√	√		
Kalos/Aveo(~05MY)	ENGINE CONTROL	SOHC			√	√	√	√	
		1.2 SOHC (SIEMENS)			√	√	√	√	ADAPTION RESET
		1.5 SOHC (DELPHI)			√	√	√	√	
		1.6 SOHC (DELPHI)			√	√	√	√	
	AUTOMATIC TRANSAXLE				√	√	√	√	
	ANTI-LOCK BRAKE SYSTEM				√	√	√	√	HCU AIRBREEDING
	SRS-AIRBAG				√	√			
Damas/Rabo	ENGINE CONTROL	0.8L LPG			√	√	√	√	
		0.8L LPGi(MAIN MODULE)			√	√	√		
		0.8L LPGi(INTERFACE MODULE)			√	√	√		
Lacetti/Optra/Excelle(~05MY)	ENGINE CONTROL	1.5L			√	√	√		1. Learning value initialization(All) 2. MTIA learning value initalization 3. Air controlled quantity learning value
		1.6L			√	√	√	√	
	AUTOMATIC TRANSAXLE				√	√	√	√	
	ANTI-LOCK BRAKE SYSTEM				√	√	√	√	
	SRS-AIRBAG				√	√			
Kalos/Aveo/Barina (06MY~)	ENGINE CONTROL	1.2 SOHC(SIEMENS)			√	√	√	√	ADAPTION RESET
		1.5 SOHC(DELPHI)			√	√	√	√	
		1.6 DOHC(DELPHI)			√	√	√	√	
		1.8 DOHC (DELPHI)			√	√	√	√	
	AUTOMATIC TRANSAXLE				√	√	√	√	
	ANTI-LOCK BRAKE SYSTEM				√	√	√	√	
	SRS-AIRBAG				√	√			

Daewoo **V26.92** Diagnostics List (Note:For reference only)

Vehicles	System	Sub System	Sub System	functions						
				System Info.	Read Dtc	Clear Dtc	Data Stream	Actuation	Special Functions	
Lacetti/Optra/Excell/Viva (06MY~)	ENGINE CONTROL	1.5 DOHC (SIEMENS)			√	√	√	√	ADAPTION RESET	
		1.6 DOHC (SIEMENS)			√	√	√		ADAPTION RESET EVAP.LEAK	
		2.0L DIESEL			√	√				
		1.8 DOHC (SIEMENS)			√	√				
		1.8 DOHC (DELPHI)			√	√	√	√		
	AUTOMATIC TRANSAXLE	AISIN TCU (GASOLINE)				√	√	√	√	
		AISIN TCU (DIESEL)				√	√	√		LEARNING DATA RESET
		AISIN 4GEAR(GAS 1.8L)				√	√			
	ANTI-LOCK BRAKE SYSTEM				√	√	√	√		
SRS-AIRBAG				√	√					
Matiz(M200)	ENGINE CONTROL	0.8 SOHC			√	√	√			
		0.8 SOHC KOB(2007MY)			√	√	√		ADAPTION RESET EVAP.LEAK	
		1.0 SOHC(EURO-II)			√	√	√		ADAPTION RESET	
		1.0 SOHC(EURO-III&IV)			√	√	√		ADAPTION RESET	
	AUTOMATIC TRANSAXLE				√	√	√	√		
	ANTI-LOCK BRAKE SYSTEM				√	√	√			
	SRS-AIRBAG				√	√				
Matiz(M300)/Spark	01.POWER TRAIN	01.ENG.CONTROL MOD.(ECU-D52)			√	√	√	√	1.ADAPTION RESET 2.EVAP.LEAK	
		02.LPG CONTROL MOD.(ICM-LPGI)			√	√	√			
		03.A/T CONTROL MODULE			√	√	√			
	02.CHASSIS	01.BRAKE CONTROL MODULE(EBCM)				√	√	√		1.SAS SENSOR ZERO SETTING 2.WRITE VIN
		03.BODY	01.AIRBAG CONTROL MODULE(SDM)			√	√	√		1.NEW SDM APPLIED SETUP 2.SDM RESET 3.WRITE VIN
			02.INS.CLUSTER CTRL MOD(IPC)			√	√	√		
		GASOLINE 1.8L			√	√	√		LEARNING DATA RESET	

Daewoo **V26.92** Diagnostics List (Note:For reference only)

Vehicles	System	Sub System	Sub System	functions						
				System Info.	Read Dtc	Clear Dtc	Data Stream	Actuation	Special Functions	
Tosca/Epica	ENGINE CONTROL	GASOLINE 2.0L/2.5L			√	√	√		LEARNING DATA RESET	
		LPI(EMS ECU)			√	√	√	√		
		LPI(IFB ECU)				√	√	√	√	
		LPG 2.0L(MAIN)				√	√	√		LEARNING DATA RESET
		LPG 2.0L(INTERFACE)				√	√	√		
		2.0L DIESEL				√	√	√		LEARNING DATA RESET
		LPG 2.0L(MAIN)-KULEV				√	√	√		
		LPG 2.0L(MAIN)-6 AT				√	√	√		
	AUTOMATIC TRANSAXLE	AISIN 4 GEAR(GAS 1.8L)				√	√	√		
		AISIN 4 GEAR(LPG 2.0L)				√	√	√		
		AISIN 5GEAR(GAS 2.0/2.5L)				√	√	√		
		AISIN TCU(DIESEL)				√	√	√		
	ANTI-LOCK BRAKE SYSTEM				√	√	√			
SRS-AIRBAG				√	√	√				
ISU				√	√	√				
Lacetti Premiere/Cruze	01. ENGINE CONTROL	01.ECM-GEN3 1.6D&1.8D				√	√		√	RESET TPS LEARN VALUE ECM LEARN RESET CLUTCH PEDAL LEARN(M/T) WRITE VIN
		02.ECM-DIESEL				√	√	√	√	
		03.ECM-FAM 1				√	√			
	02. AUTOMATIC TRANSAXLE	01.TCM-GF6				√	√		√	
	03.CHASSIS	01.ABS				√	√			
Gentra	ENGINE CONTROL	1.2 SOHC (SIEMENS)			√	√	√			ADAPTION RESET
		1.6 DOHC (DELPHI)			√	√	√			
		1.5 SOHC				√	√	√	√	
		1.2 DOHC (SIEMENS)				√	√	√	√	ADAPTION RESET EVAP.LEAK
		1.5 SOHC (DELPHI)				√	√	√	√	
		1.4/1.6 DOHC (DELPHI)				√	√	√	√	

Daewoo **V26.92** Diagnostics List (Note:For reference only)

Vehicles	System	Sub System	Sub System	functions						
				System Info.	Read Dtc	Clear Dtc	Data Stream	Actuation	Special Functions	
	AUTOMATIC TRANSAXLE				√	√				
	ANTI-LOCK BRAKE SYSTEM				√	√	√	√		
	SRS-AIRBAG				√	√	√			
Stateman	ENGINE CONTROL	V6			√	√	√	√		
		V6 OBD			√	√	√			
	AUTOMATIC TRANSAXLE				√	√	√	√		
	ANTI-LOCK BRAKE SYSTEM	ABS				√	√	√	√	
		ABS/ETC(DISABLE)				√	√	√		
	SRS-AIRBAG				√	√	√			
	BODY CONTROL SYSTEM	INSTRUMENT				√	√	√		
TRIP COMPUTER					√	√	√			
INSTRUMENT - CONFIG					√	√	√			
Winstorm/Captiva /Antaba	ENGINE CONTROL	01.ECM(DIESEL)				√	√	√		LEARNING DATA RESET
		02.2.4 DOHC(GASOLINE)				√	√		√	WHEEL CIRCUMFERENCE
		03.3.2 DOHC(GASOLINE)				√	√		√	ENGINE OIL REMAINING LIFE ECM IMMOBILIZER LEARNING
	AUTOMATIC TRANSAXLE	TCM(AISIN CAN)				√	√	√		LEARNING DATA RESET
	CHASSIS	01.ABS				√	√		√	SAS SEN SOR ZERO SETTING
		02.TCCM				√	√	√	√	BANK INFORMATION PROGRAM
BODY	BCM				√	√	√	√	WRITE VIN	
Cruze	01.ENGINE CONTROL	01.1.6L GASOLINE(LXT)				√	√		√	HO2S HEATER LEARN IDLE LEARN FUEL TRIM RESET
		02.1.6L GASOLINE(LXV)				√	√		√	ENGINE OIL REMAINING LIFE FUEL TRIM RESET
		03.1.8L GASOLINE(2H0)				√	√		√	ENGINE OIL REMAINING LIFE FUEL TRIM RESET
		04.2.0L DIESEL(LLW)				√	√		√	LEARN FUNCTION RESET FUNCTION
		01.1.6L(LXT)				√	√		√	ADAPTIVE VALUES LEARN

Daewoo **V26.92** Diagnostics List (Note:For reference only)

Vehicles	System	Sub System	Sub System	functions						
				System Info.	Read Dtc	Clear Dtc	Data Stream	Actuation	Special Functions	
	02.AUTOMATIC TRANSAXLE	02.1.6L(LXV)			√	√		√	ADAPTIVE VALUES LEARN	
		03.1.8L(2H0)			√	√		√	ADAPTIVE VALUES LEARN	
		04.2.0L(LLW)				√	√		√	ADAPTIVE VALUES LEARN
	03.CHASSIS CONTROL SYSTEM	01.ABS	STABILITY SYSTEM(EQUIP)			√	√		√	BRAKE PRESSURE SENSOR CAL. STEERING ANGLE SENSOR LEARN
			STABILITY SYSTEM(NOTEQUIP)			√	√		√	STEERING ANGLE SENSOR LEARN
	04.BODY CONTROL SYSTEM	BCM(BODY CONTROL)				√	√		√	

(*):Tested;

(?):Manual on website(www.x431.com)

Note:The final interpretation of the products belongs to LAUNCH TECH CO.,LTD.

CONNECTOR	X431	DIAGUN
SMART OBD	Use for the cars of 16-PIN Diagnostic	N/A
DAEWOO-12	Use for the cars of 12PIN Diagnostic	Use for the cars of 12PIN Diagnostic socket
OBD 16C	N/A	N/A
CANBUS II	N/A	N/A
diagun connector	N/A	Use for the cars of 16-PIN Diagnostic socket
SUPER 16	Use for the cars of 16-PIN Diagnostic	N/A

CONNECTOR	X431	DIAGUN
SMART OBD	Use for the cars of 16-PIN Diagnostic socket	N/A
DAEWOO-12	Use for the cars of 12PIN Diagnostic socket	Use for the cars of 12PIN Diagnostic socket
OBD 16C	N/A	N/A
CANBUS II	N/A	N/A
diagun connector	N/A	Use for the cars of 16-PIN Diagnostic socket
SUPER 16	Use for the cars of 16-PIN Diagnostic socket	N/A